

GT86 ZN6 ALE8 MTM 6F LHD EUR


Exploded Views and Part List

Concerned model


2012 – 2015 GT86 ZN6 ALE8
FA20 : 2000CC 16-VALVE DOHC
HI : HIGH TYPE
MTM : MANUAL TRANSMISSION
6F : MTM, 6-SPEED FLOOR SHIFT
LHD : LEFT-HAND DRIVE VEHICLES
EUR : EUROPE



Outer appearance and dimensions



Content illustration



GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

1	Illustrations	6
2	Body	11
2.1	ACCELERATOR LINK(7801)	11
2.2	ARMREST & VISOR(7401).....	12
2.3	ASH RECEPTACLE(7404)	14
2.4	BATTERY CARRIER(7402).....	15
2.5	CAUTION PLATE (EXTERIOR & INTERIOR)(7403).....	16
2.6	CONSOLE BOX & BRACKET(5806)	21
2.7	COWL PANEL & WINDSHIELD GLASS(5503).....	23
2.8	EMBLEM & NAME PLATE (EXTERIOR & INTERIOR)(7501).....	26
2.9	FLOOR INSULATOR(5802)	33
2.10	FLOOR PAN & LOWER BACK PANEL(5801).....	34
2.11	FLOOR SIDE MEMBER(5305).....	44
2.12	FRONT BUMPER & BUMPER STAY(5201).....	48
2.13	FRONT DOOR LOCK & HANDLE(6703).....	51
2.14	FRONT DOOR PANEL & GLASS(6701).....	52
2.15	FRONT DOOR WINDOW REGULATOR & HINGE(6704)	58
2.16	FRONT FENDER APRON & DASH PANEL(5304)	61
2.17	FRONT SEAT & SEAT TRACK(7101).....	71
2.18	FUEL TANK & TUBE(7701).....	75
2.19	HOLE PLUG(5701)	85
2.20	HOOD & FRONT FENDER(5302)	89
2.21	HOOD LOCK & HINGE(5303)	94
2.22	INSIDE TRIM BOARD & DOOR OPENING TRIM MOULDING(6401)	97
2.23	INSTRUMENT PANEL & GLOVE COMPARTMENT(5501)	101
2.24	LOCK CYLINDER SET(6712).....	108
2.25	LUGGAGE COMPARTMENT DOOR & LOCK(6105).....	110
2.26	MAT & CARPET(5804)	112
2.27	MUDGUARD & SPOILER(7601).....	117
2.28	PACKAGE TRAY PANEL & LUGGAGE COMPARTMENT MAT(6403)	121
2.29	QUARTER WINDOW(6103)	124
2.30	REAR BUMPER & BUMPER STAY(5202)	125
2.31	REAR MOULDING(7504).....	128
2.32	REAR SEAT & SEAT TRACK(7102)	131
2.33	ROOF HEADLINING & SILENCER PAD(6402).....	134
2.34	ROOF PANEL & BACK WINDOW GLASS(6104)	135

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.35	ROOF SIDE VENTILATOR(6102)	138
2.36	SEAT BELT & CHILD RESTRAINT SEAT(7104)	139
2.37	SIDE MEMBER(6101).....	143
2.38	SIDE MOULDING(7503).....	149
2.39	SPARE WHEEL CARRIER(5104)	158
2.40	SUSPENSION CROSSMEMBER & UNDER COVER(5102)	159
3	Electrical.....	164
3.1	ABS & VSC(8414).....	164
3.2	AIR BAG(8421).....	166
3.3	ANTENNA(8604).....	167
3.4	BACK UP LAMP(8112)	168
3.5	BATTERY & BATTERY CABLE(8201)	169
3.6	CENTER STOP LAMP(8117)	171
3.7	CRUISE CONTROL (AUTO DRIVE)(8408)	172
3.8	DAYTIME RUNNING LAMP OR ILLUMINATION LAMP(8119)	175
3.9	ELECTRONIC FUEL INJECTION SYSTEM(8404)	176
3.10	ELECTRONIC HEIGHT CONTROL(8418).....	180
3.11	FOG LAMP(8102).....	181
3.12	FRONT TURN SIGNAL LAMP(8103)	182
3.13	HEADLAMP CLEANER(8505).....	183
3.14	HEADLAMP(8101)	184
3.15	HEATING & AIR CONDITIONING.....	186
3.16	HORN(8611)	200
3.17	INTERIOR LAMP(8121)	201
3.18	METER(8301)	204
3.19	MIRROR(8701)	205
3.20	RADIO RECEIVER & AMPLIFIER & CONDENSER(8601)	207
3.21	REAR COMBINATION LAMP(8111).....	211
3.22	REAR LICENSE PLATE LAMP(8113)	212
3.23	REFLEX REFLECTOR(8115).....	213
3.24	SIDE TURN SIGNAL LAMP & OUTER MIRROR LAMP(8106).....	214
3.25	SPEAKER(8602).....	215
3.26	SWITCH & RELAY(8401)	216
3.27	WINDSHIELD WASHER(8503).....	229
3.28	WINDSHIELD WIPER(8501)	231
3.29	WIRELESS DOOR LOCK(8420).....	232

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.30	WIRING & CLAMP(8202)	234
4	Power train,Chassis	249
4.1	BRAKE BOOSTER & VACUUM TUBE(4703)	249
4.2	BRAKE MASTER CYLINDER(4702)	251
4.3	BRAKE PEDAL & BRACKET(4701)	252
4.4	BRAKE TUBE & CLAMP(4708)	253
4.5	CLUTCH & RELEASE FORK(3101)	257
4.6	CLUTCH HOUSING & TRANSMISSION CASE (MTM)(3302)	259
4.7	CLUTCH MASTER CYLINDER(3103)	266
4.8	CLUTCH PEDAL & FLEXIBLE HOSE(3102)	267
4.9	CLUTCH RELEASE CYLINDER(3105)	269
4.10	DISC WHEEL & WHEEL CAP(4103)	270
4.11	EXTENSION HOUSING (MTM)(3303)	274
4.12	FRONT AXLE ARM & STEERING KNUCKLE(4802)	275
4.13	FRONT AXLE HUB(4303)	277
4.14	FRONT DISC BRAKE CALIPER & DUST COVER(4705)	281
4.15	FRONT SPRING & SHOCK ABSORBER(4803)	283
4.16	FRONT STEERING GEAR & LINK(4505)	285
4.17	GEAR SHIFT FORK & LEVER SHAFT (MTM)(3307)	287
4.18	PARKING BRAKE & CABLE(4601)	292
4.19	PROPELLER SHAFT & UNIVERSAL JOINT(3701)	294
4.20	REAR AXLE HOUSING & DIFFERENTIAL(4101)	295
4.21	REAR AXLE SHAFT & HUB(4102)	298
4.22	REAR DISC BRAKE CALIPER & DUST COVER(4707)	303
4.23	REAR SPRING & SHOCK ABSORBER(4804)	304
4.24	SHIFT LEVER & RETAINER(3312)	308
4.25	STEERING COLUMN & SHAFT(4501)	310
4.26	STEERING WHEEL(4504)	313
4.27	TRANSAXLE OR TRANSMISSION ASSY & GASKET KIT (MTM)(3301)	316
4.28	TRANSMISSION GEAR (MTM)(3305)	317
5	Tool,Engine,Fuel	321
5.1	AIR CLEANER(1703)	321
5.2	ALTERNATOR(1903)	323
5.3	CAMSHAFT & VALVE(1302)	325
5.4	CAUTION PLATE & NAME PLATE (ENGINE)(1709)	328
5.5	CRANKSHAFT & PISTON(1301)	329

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.6	CYLINDER BLOCK(1105)	332
5.7	CYLINDER HEAD(1104).....	339
5.8	ENGINE OIL PUMP(1501)	346
5.9	ENGINE OVERHAUL GASKET KIT(1103)	347
5.10	EXHAUST PIPE(1702).....	348
5.11	FUEL INJECTION SYSTEM(2211)	350
5.12	IGNITION COIL & SPARK PLUG(1901).....	354
5.13	MANIFOLD(1701).....	355
5.14	MOUNTING(1107).....	361
5.15	OIL FILTER(1502)	363
5.16	RADIATOR & WATER OUTLET(1603).....	365
5.17	SHORT BLOCK ASSEMBLY(1102)	369
5.18	STANDARD TOOL(0901)	370
5.19	STARTER(1904).....	373
5.20	TIMING GEAR COVER & REAR END PLATE(1106).....	374
5.21	V	375
5.22	VACUUM PIPING(1708).....	376
5.23	VACUUM PUMP(1905).....	378
5.24	VENTILATION HOSE(1201)	379
5.25	WATER PUMP(1601)	380



1 Illustrations




GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views



GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views



GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views



GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views




GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2 Body

2.1 ACCELERATOR LINK(7801)

2.1.1 Body - ACCELERATOR LINK(7801) - 1




781378

PNC	Original P/N	Description
78110H	SU00300986	COVER (FOR ACCELERATOR PEDAL ROD)
78110K	SU00300953	SENSOR ASSY, ACCELERATOR PEDAL
78119	SU00300976	STOPPER, ACCELERATOR PEDAL ROD
SU00302874	SU00302874	** Std part
SU00302971	SU00302971	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.2 ARMREST & VISOR(7401)

2.2.1 Body - ARMREST & VISOR(7401) - 1




743347

PNC	Original P/N	Description
74310	SU00303163	VISOR ASSY, RH
74320	SU00303164	VISOR ASSY, LH
74348	SU00303180	HOLDER, VISOR
8121		Ref to 8121
SU00302923	SU00302923	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.2.2 Body - ARMREST & VISOR(7401) - 2




743394

PNC	Original P/N	Description
6701		Ref to 6701
6703		Ref to 6703
74210	SU00304449	ARMREST ASSY, FRONT, RH
74220	SU00304450	ARMREST ASSY, FRONT, LH
74221	SU00303268	COVER, DOOR ARMREST, RH
74222	SU00303269	COVER, DOOR ARMREST, LH
74231	SU00304443	PANEL, FRONT ARMREST BASE, UPPER RH
74232	SU00304444	PANEL, FRONT ARMREST BASE, UPPER LH
74603A	SU00302591	GROMMET (FOR FRONT ASSIST GRIP)
74630C	SU00304424	GRIP ASSY, DOOR ASSIST, RH
74640C	SU00304426	GRIP ASSY, DOOR ASSIST, LH
8115		Ref to 8115
8121		Ref to 8121
8401		Ref to 8401
SU00300063	SU00300063	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.4 BATTERY CARRIER(7402)

2.4.1 Body - BATTERY CARRIER(7402) - 1



N04:この部品については補給していません
N04:This part is not available for service


743370

PNC	Original P/N	Description
74404A	SU00302417	CLAMP SUB-ASSY, BATTERY
74431	SU00302411	TRAY, BATTERY
74451B	SU00302415	BOLT, BATTERY CLAMP
74452A	SU00302416	BOLT, BATTERY CLAMP, NO.2
8201		Ref to 8201
8202		Ref to 8202
SU00300051	SU00300051	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.5 CAUTION PLATE (EXTERIOR & INTERIOR)(7403)

2.5.1 Body - CAUTION PLATE (EXTERIOR & INTERIOR)(7403) - 1




743372

PNC	Original P/N	Description
4504		Ref to 4504
5501		Ref to 5501
6401		Ref to 6401
7101		Ref to 7101
74596A	SU00303431	LABEL, SIDE AIR BAG CAUTION

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.5.2 Body - CAUTION PLATE (EXTERIOR & INTERIOR)(7403) - 2




743383

PNC	Original P/N	Description
11285A	SU00301198	LABEL, COOLANT SYSTEM NOTICE
1603		Ref to 1603
1709		Ref to 1709
5304		Ref to 5304

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.5.3 Body - CAUTION PLATE (EXTERIOR & INTERIOR)(7403) - 3




743356

PNC	Original P/N	Description
6701		Ref to 6701
6704		Ref to 6704
74582D	N/A	LABEL, SAFETY CAUTION

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.5.5 Body - CAUTION PLATE (EXTERIOR & INTERIOR)(7403) - 5




743349A

PNC	Original P/N	Description
74511B	N/A	PLATE, NAME
74511F	SU00304480	LABEL, NAME (IDENTIFICATION LASER LABEL)
74579A	SU00300084	LABEL, UNLEADED FUEL INFORMATION
74751	SU00300775	LABEL, TIRE PRESSURE INFORMATION

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.6 CONSOLE BOX & BRACKET(5806)

2.6.1 Body - CONSOLE BOX & BRACKET(5806) - 1




584465

PNC	Original P/N	Description
55620A	SU00303213	CUSHION(FOR CUP HOLDER)
55620B	SU00303208	HOLDER, INSTRUMENT PANEL CUP
58810J	SU00303188	BOX ASSY, CONSOLE
58815F	SU00303212	CARPET, CONSOLE BOX
58818A	SU00303206	COVER, CONSOLE BOX, FR
58836B	SU00303209	PAD, CONSOLE BOX SILENCER, NO.1
58941A	SU00303201	COVER, PARKING BRAKE HOLE
58995A	SU00303214	BRACKET, CONSOLE BOX MOUNTING, NO.1
58996A	SU00303215	BRACKET, CONSOLE BOX MOUNTING, NO.2
7404		Ref to 7404
8401		Ref to 8401
8420		Ref to 8420
8601		Ref to 8601
SU00300013	SU00300013	** Std part
SU00300064	SU00300064	** Std part
SU00300068	SU00300068	** Std part
SU00302919	SU00302919	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.6.2 Body - CONSOLE BOX & BRACKET(5806) - 2



← FRONT


584467

PNC	Original P/N	Description
3312		Ref to 3312
58804A	SU00303191	PANEL SUB-ASSY, CONSOLE, UPPER
58808	SU00303197	COVER SUB-ASSY, SHIFTING HOLE
58811D	SU00302967	CLIP(FOR CONSOLE BOX)
8401		Ref to 8401
SU00302919	SU00302919	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.7 COWL PANEL & WINDSHIELD GLASS(5503)

2.7.1 Body - COWL PANEL & WINDSHIELD GLASS(5503) - 1




552919

PNC	Original P/N	Description
5304		Ref to 5304
55700	SU00301236	PANEL ASSY, FRONT
55705B	SU00301237	PANEL SUB-ASSY, COWL TOP SIDE, RH
55706B	SU00301238	PANEL SUB-ASSY, COWL TOP SIDE, LH

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.7.2 Body - COWL PANEL & WINDSHIELD GLASS(5503) - 2




552956

PNC	Original P/N	Description
56111	SU003G0007	GLASS, WINDSHIELD
56115A	SU00301888	STOPPER, WINDSHIELD GLASS, NO.1
56116C	SU00301889	STOPPER, WINDSHIELD GLASS, NO.2
56117A	SU00301890	DAM, WINDOW GLASS ADHESIVE
56117E	SU00301892	DAM, WINDOW GLASS ADHESIVE
56119	SU00301894	SEAL, WINDSHIELD GLASS
56119C	SU00301895	SEAL, WINDSHIELD GLASS
75533G	SU00301893	MOULDING, WINDSHIELD, OUTSIDE
8701		Ref to 8701

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.7.3 Body - COWL PANEL & WINDSHIELD GLASS(5503) - 3



552910


PNC	Original P/N	Description
5302		Ref to 5302
53383B	SU00303137	SEAL, HOOD TO COWL TOP
53866J	SU00303135	SEAL, FRONT FENDER TO COWL SIDE, RH
53867H	SU00303136	SEAL, FRONT FENDER TO COWL SIDE, LH
55781	SU00303134	LOUVER, COWL VENTILATOR
55781G	SU00303141	CLIP, COWL TOP VENTILATOR LOUVER
55787	SU00302987	CLIP, COWL VENTILATOR LOUVER, INNER
55799C	SU00303140	CLIP, COWL TOP VENTILATOR LOUVER
8503		Ref to 8503

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.8 EMBLEM & NAME PLATE (EXTERIOR & INTERIOR)(7501)

2.8.1 Body - EMBLEM & NAME PLATE (EXTERIOR & INTERIOR)(7501) - 1

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views



752670


PNC	Original P/N	Description
-----	--------------	-------------

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

75311	SU00303216	EMBLEM, RADIATOR GRILLE (OR FRONT PANEL)
75441D	SU00304072	PLATE, LUGGAGE COMPARTMENT DOOR NAME, NO.1
SU00304224	SU00304224	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.8.2 Body - EMBLEM & NAME PLATE (EXTERIOR & INTERIOR)(7501) - 2




752671

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

PNC	Original P/N	Description
75741E	SU00303219	EMBLEM, SYMBOL

2.8.3 Body - EMBLEM & NAME PLATE (EXTERIOR & INTERIOR)(7501) - 3




GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

PNC	Original P/N	Description
7503		Ref to 7503
75351A	SU00303126	EMBLEM, FRONT FENDER

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.9 FLOOR INSULATOR(5802)

2.9.1 Body - FLOOR INSULATOR(5802) - 1




584460

PNC	Original P/N	Description
58327B	SU00301546	INSULATOR, MAIN MUFFLER HEAT
SU00302932	SU00302932	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.10 FLOOR PAN & LOWER BACK PANEL(5801)

2.10.1 Body - FLOOR PAN & LOWER BACK PANEL(5801) - 1




584455

PNC	Original P/N	Description
5305		Ref to 5305
57051A	SU00301328	MEMBER SUB-ASSY, FRONT FLOOR CROSS, RH
57052A	SU00301329	MEMBER SUB-ASSY, FRONT FLOOR CROSS, LH
57053	SU00301332	REINFORCEMENT SUB-ASSY, FRONT FLOOR CROSS MEMBER, RH
57054A	SU00301333	REINFORCEMENT SUB-ASSY, FRONT FLOOR CROSS MEMBER, LH
57169C	SU00301350	PATCH, FRONT FLOOR, REAR
57407C	SU00301326	MEMBER SUB-ASSY, CENTER FLOOR CROSS, NO.1
57423	SU00301338	BRACKET, FRONT FLOOR REINFORCEMENT, RH
57424	SU00301339	BRACKET, FRONT FLOOR REINFORCEMENT, LH
57427D	SU00301341	REINFORCEMENT, FRONT FLOOR, NO.3 RH
57428C	SU00301341	REINFORCEMENT, FRONT FLOOR, NO.3 LH
57451A	SU00301330	MEMBER, FRONT FLOOR CROSS, RH
57452C	SU00301331	MEMBER, FRONT FLOOR CROSS, LH
57455A	SU00301351	BRACKET, FRONT FLOOR CROSSMEMBER
57663C	SU00301327	MEMBER, REAR FLOOR CROSS, CENTER
58111A	SU00301317	PAN, FRONT FLOOR, RH
58112A	SU00301318	PANEL, FRONT FLOOR, LH
58113A	SU00301316	PANEL, FRONT FLOOR, CENTER
58278D	SU00301324	PROTECTOR, FUEL TANK, UPPER
58279C	SU00301325	PROTECTOR, FUEL TANK, UPPER NO.2
6101		Ref to 6101
SU00301354	SU00301354	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.10.2 Body - FLOOR PAN & LOWER BACK PANEL(5801) - 2




GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

PNC	Original P/N	Description
58192	SU00301362	PANEL, FOOTREST
SU00300051	SU00300051	** Std part
SU00303000	SU00303000	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.10.3 Body - FLOOR PAN & LOWER BACK PANEL(5801) - 3




584473

PNC	Original P/N	Description
0901		Ref to 0901
5305		Ref to 5305
57407E	SU00301334	MEMBER SUB-ASSY, CENTER FLOOR CROSS
57653D	SU00301337	MEMBER, REAR FLOOR CROSS, NO.2
58241C	SU00301342	PANEL, FLOOR SIDE, RH
58242C	SU00301343	PANEL, FLOOR SIDE, LH
58273C	SU00301340	REINFORCEMENT, BELT ANCHOR TO CENTER FLOOR
58305	SU00301355	BRACKET SUB-ASSY, SPARE WHEEL CLAMP
58311	SU00301321	PAN, REAR FLOOR
58313	SU00301346	PANEL, REAR FLOOR SIDE, RH
58313F	SU00301322	EXTENSION, REAR FLOOR PAN TO QUARTER PANEL, RH
58313K	SU00301319	PANEL, REAR FLOOR, RH
58314	SU00301347	PANEL, REAR FLOOR SIDE, LH
58314F	SU00301323	EXTENSION, REAR FLOOR PAN TO QUARTER PANEL, LH
58314H	SU00301320	PANEL, REAR FLOOR, LH

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.10.4 Body - FLOOR PAN & LOWER BACK PANEL(5801) - 4




584457

PNC	Original P/N	Description
58307	SU00301363	PANEL SUB-ASSY, BODY LOWER BACK

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.10.5 Body - FLOOR PAN & LOWER BACK PANEL(5801) - 5




584490

PNC	Original P/N	Description
5304		Ref to 5304
5804		Ref to 5804
58261A	SU00302953	COVER, TRANSMISSION
SU00302817	SU00302817	** Std part
SU00302900	SU00302900	** Std part
SU00303011	SU00303011	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.10.6 Body - FLOOR PAN & LOWER BACK PANEL(5801) - 6




584456

PNC	Original P/N	Description
58311E	SU00303350	COVER, REAR FLOOR SERVICE HOLE
58311F	SU00303351	COVER, REAR FLOOR SERVICE HOLE, NO.2

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.10.7 Body - FLOOR PAN & LOWER BACK PANEL(5801) - 7




584458

PNC	Original P/N	Description
SU00302851	SU00302851	** Std part
SU00302939	SU00302939	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views

2.10.8 Body - FLOOR PAN & LOWER BACK PANEL(5801) - 8




584491

PNC	Original P/N	Description
6105		Ref to 6105
SU00303023	SU00303023	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.11 FLOOR SIDE MEMBER(5305)

2.11.1 Body - FLOOR SIDE MEMBER(5305) - 1




533717

PNC	Original P/N	Description
0901		Ref to 0901
5304		Ref to 5304
57101E	SU00301295	MEMBER SUB-ASSY, FRONT SIDE, INNER RH
57102C	SU00301296	MEMBER SUB-ASSY, FRONT SIDE, INNER LH
57197	SU00301306	BOX, TORQUE, FRONT RH
57198	SU00301307	BOX, TORQUE, FRONT LH
6101		Ref to 6101

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.11.2 Body - FLOOR SIDE MEMBER(5305) - 2




533693

PNC	Original P/N	Description
57027B	SU00301297	MEMBER SUB-ASSY, FRONT SIDE, INNER RH
57028B	SU00301298	MEMBER SUB-ASSY, FRONT SIDE, INNER LH
57101	SU00301293	MEMBER SUB-ASSY, FRONT SIDE, RH
57102	SU00301294	MEMBER SUB-ASSY, FRONT SIDE, LH
57115A	SU00301291	PLATE, FRONT SIDE MEMBER, OUTER RH
57116A	SU00301292	PLATE, FRONT SIDE MEMBER, OUTER LH
57151A	SU00301304	REINFORCEMENT, FRONT SIDE MEMBER, NO.1 RH
57152	SU00301305	REINFORCEMENT, FRONT SIDE MEMBER, NO.1 LH
57455D	SU00301302	GUSSET, FRONT FLOOR CROSSMEMBER, RH
57456C	SU00301303	GUSSET, FRONT FLOOR CROSSMEMBER, LH

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.11.3 Body - FLOOR SIDE MEMBER(5305) - 3




533719

PNC	Original P/N	Description
57401	SU00301239	MEMBER SUB-ASSY, MAIN FLOOR SIDE, RH
57402	SU00301240	MEMBER SUB-ASSY, MAIN FLOOR SIDE, LH
5801		Ref to 5801
6101		Ref to 6101

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.11.4 Body - FLOOR SIDE MEMBER(5305) - 4




533694A

PNC	Original P/N	Description
0901		Ref to 0901
57075A	SU00301352	BRACKET SUB-ASSY, REAR SUSPENSION ARM, RH
57076A	SU00301353	BRACKET SUB-ASSY, REAR SUSPENSION ARM, LH
57167E	SU00301358	GUSSET, FRONT CROSSMEMBER SIDE, RH
57168E	SU00301359	GUSSET, FRONT CROSSMEMBER SIDE, LH
57403A	SU00301335	MEMBER SUB-ASSY, CENTER FLOOR CROSS, NO.3
57601	SU00301348	MEMBER SUB-ASSY, REAR FLOOR SIDE, RH
57602	SU00301349	MEMBER SUB-ASSY, REAR FLOOR SIDE, LH
57606C	SU00301336	MEMBER SUB-ASSY, REAR FLOOR CROSS, NO.2
57611A	SU00301356	MEMBER, REAR FLOOR SIDE, RH
57612A	SU00301357	MEMBER, REAR FLOOR SIDE, LH
57803A	SU00301344	REINFORCEMENT SUB-ASSY, REAR FLOOR SIDE MEMBER, REAR RH
57804	SU00301345	REINFORCEMENT SUB-ASSY, REAR FLOOR SIDE MEMBER, REAR LH
5801		Ref to 5801
58323B	SU00304256	REINFORCE, REAR BUMPER ARM SUPPORT, RH
58324B	SU00304256	REINFORCE, REAR BUMPER ARM SUPPORT, LH

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.12 FRONT BUMPER & BUMPER STAY(5201)

2.12.1 Body - FRONT BUMPER & BUMPER STAY(5201) - 1



522622A


PNC	Original P/N	Description
0901		Ref to 0901
52021	SU00301508	REINFORCEMENT SUB-ASSY, FRONT BUMPER
52114A	SU00301540	BRACKET, FRONT BUMPER EXTENTION MOUNTING
52115A	SU00301496	SUPPORT, FRONT BUMPER SIDE, RH
52115D	SU00301498	SUPPORT, FRONT BUMPER SIDE, NO.2 RH
52116A	SU00301497	SUPPORT, FRONT BUMPER SIDE, LH
52116D	SU00301499	SUPPORT, FRONT BUMPER SIDE, NO.2 LH
52119A	SU00301482	COVER, FRONT BUMPER
52123B	SU00301537	PLATE, FRONT BUMPER REINFORCEMENT, RH
52124B	SU00301538	PLATE, FRONT BUMPER REINFORCEMENT, LH
52127C	SU00301520	COVER, FRONT BUMPER HOLE
52129B	SU00304308	COVER, FRONT BUMPER, LOWER
52141B	SU00301511	STAY, FRONT BUMPER
52161C	SU00302984	PIECE, FRONT BUMPER
52161T	SU00302974	PIECE, FRONT BUMPER
52521B	SU00301515	RETAINER, FRONT BUMPER, UPPER
52535	SU00301505	RETAINER, FRONT BUMPER SIDE, RH
52536	SU00301506	RETAINER, FRONT BUMPER SIDE, LH
52611	SU00301495	ABSORBER, FRONT BUMPER ENERGY
53112E	SU00301532	GRILLE, RADIATOR, LOWER NO.1
53293	SU00301500	BRACKET, FRONT BUMPER STAY
53395E	SU00301534	SEAL, HOOD TO FRONT END PANEL
81481E	SU00301518	COVER, FOG LAMP, RH
81482C	SU00301519	COVER, FOG LAMP, LH
SU00300063	SU00300063	** Std part
SU00301514	SU00301514	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

SU00301535	SU00301535	** Std part
SU00302786	SU00302786	** Std part
SU00302793	SU00302793	** Std part
SU00302799	SU00302799	** Std part
SU00302826	SU00302826	** Std part
SU00302940	SU00302940	** Std part
SU00302985	SU00302985	** Std part
SU00303352	SU00303352	** Std part
SU00304133	SU00304133	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views

2.12.2 Body - FRONT BUMPER & BUMPER STAY(5201) - 2




522856

PNC	Original P/N	Description
52119A	SU00301482	COVER, FRONT BUMPER
7601		Ref to 7601

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.13 FRONT DOOR LOCK & HANDLE(6703)

2.13.1 Body - FRONT DOOR LOCK & HANDLE(6703) - 1




677365

PNC	Original P/N	Description
6701		Ref to 6701
69201A	SU00301584	FRAME SUB-ASSY, FRONT DOOR OUTSIDE HANDLE, RH
69202A	SU00301585	FRAME SUB-ASSY, FRONT DOOR OUTSIDE HANDLE, LH
69205	SU00301564	HANDLE SUB-ASSY, FRONT DOOR INSIDE, RH
69206B	SU00301565	HANDLE SUB-ASSY, FRONT DOOR INSIDE, LH
69210	SU00301594	HANDLE ASSY, FRONT DOOR, OUTSIDE RH
69217E	SU00301575	COVER, FRONT DOOR OUTSIDE HANDLE, RH
69217F	SU00301568	COVER, FRONT DOOR OUTSIDE HANDLE, LH
69220	SU00301594	HANDLE ASSY, FRONT DOOR OUTSIDE, LH
69241H	SU00301614	PAD, FRONT DOOR OUTSIDE HANDLE, FRONT
69242E	SU00301615	PAD, FRONT DOOR OUTSIDE HANDLE, REAR
69283	SU00301566	PLUG, FRONT DOOR INSIDE HANDLE BEZEL, RH
69284C	SU00301566	PLUG, FRONT DOOR INSIDE HANDLE BEZEL, LH
69310	SU00304110	LOCK ASSY, FRONT DOOR, RH
69320	SU00304111	LOCK ASSY, FRONT DOOR, LH
69410	SU00304119	PLATE ASSY, FRONT DOOR LOCK STRIKER
SU00300063	SU00300063	** Std part
SU00302591	SU00302591	** Std part
SU00302913	SU00302913	** Std part
SU00302934	SU00302934	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.14 FRONT DOOR PANEL & GLASS(6701)

2.14.1 Body - FRONT DOOR PANEL & GLASS(6701) - 1




677366

PNC	Original P/N	Description
67001	SU00301558	PANEL SUB-ASSY, FRONT DOOR, RH
67001A	SU00304136	CUSHION, FRONT DOOR PANEL
67002	SU00301559	PANEL SUB-ASSY, FRONT DOOR, LH
6704		Ref to 6704
68610B	SU00301567	CHECK ASSY, FRONT DOOR, RH
68620	SU00301567	CHECK ASSY, FRONT DOOR, LH
SU00300051	SU00300051	** Std part
SU00302825	SU00302825	** Std part
SU00302909	SU00302909	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.14.2 Body - FRONT DOOR PANEL & GLASS(6701) - 2




677370

PNC	Original P/N	Description
62616	SU00304118	STOPPER, FRONT DOOR SASH
6704		Ref to 6704
67403F	SU00301608	FRAME SUB-ASSY, FRONT DOOR, REAR LOWER RH
67404F	SU00301609	FRAME SUB-ASSY, FRONT DOOR, REAR LOWER LH
67469	SU00301625	PROTECTOR, FRONT DOOR GUIDE
67811C	SU00301604	COVER, FRONT DOOR HOLE
67831	SU00301610	COVER, FRONT DOOR SERVICE HOLE, RH
67832	SU00301611	COVER, FRONT DOOR SERVICE HOLE, LH
68160C	SU00304334	WEATHERSTRIP ASSY, FRONT DOOR GLASS, OUTER RH
68210C	SU00304335	WEATHERSTRIP ASSY, FRONT DOOR GLASS, OUTER LH
SU00300051	SU00300051	** Std part
SU00301624	SU00301624	** Std part
SU00302874	SU00302874	** Std part
SU00302894	SU00302894	** Std part
SU00302920	SU00302920	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.14.3 Body - FRONT DOOR PANEL & GLASS(6701) - 3




677368

PNC	Original P/N	Description
6704		Ref to 6704
68101	SU003G0001	GLASS SUB-ASSY, FRONT DOOR, RH
68102	SU003G0002	GLASS SUB-ASSY, FRONT DOOR, LH
68125	SU003G0010	GLASS, FRONT DOOR FIX WINDOW, RH
68126	SU003G0011	GLASS, FRONT DOOR FIX WINDOW, LH
7403		Ref to 7403

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.14.4 Body - FRONT DOOR PANEL & GLASS(6701) - 4




677309

PNC	Original P/N	Description
67861	SU00301631	WEATHERSTRIP, FRONT DOOR, RH
67862	SU00301632	WEATHERSTRIP, FRONT DOOR, LH
67867C	SU00304052	RETAINER, FRONT DOOR WEATHERSTRIP, RH
67868C	SU00304050	RETAINER, FRONT DOOR WEATHERSTRIP, LH
67869B	SU00304054	CLIP, FRONT DOOR WEATHERSTRIP
67869E	SU00304053	CLIP, FRONT DOOR WEATHERSTRIP
7503		Ref to 7503

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views

2.14.5 Body - FRONT DOOR PANEL & GLASS(6701) - 5




677311

PNC	Original P/N	Description
67835	N/A	COVER, FRONT DOOR SPEAKER HOLE
8602		Ref to 8602

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.14.6 Body - FRONT DOOR PANEL & GLASS(6701) - 6




677314

PNC	Original P/N	Description
6703		Ref to 6703
67601	SU00304420	BOARD SUB-ASSY, FRONT DOOR TRIM, RH
67601B	SU00302981	CLIP(FOR FRONT DOOR TRIM BOARD)
67601F	SU00302917	SCREW(FOR FRONT DOOR TRIM BOARD)
67601L	SU00302986	CLIP(FOR FRONT DOOR TRIM BOARD)
67602	SU00304421	BOARD SUB-ASSY, FRONT DOOR TRIM, LH
67625A	SU00304141	BRACKET, FRONT DOOR TRIM, NO.1
67637	SU00303288	PLATE, FRONT DOOR TRIM
67651H	SU00304432	GRILLE, SPEAKER DOOR, RH
67652C	SU00304433	GRILLE, SPEAKER DOOR, LH
67688B	SU00303286	GRILLE, SPEAKER DOOR, NO.2 RH
67689B	SU00303287	GRILLE, SPEAKER DOOR, NO.2 LH
67705	SU00304430	ORNAMENT SUB-ASSY, FRONT DOOR TRIM, RH
67706	SU00304431	ORNAMENT SUB-ASSY, FRONT DOOR TRIM, LH
67735	SU00304436	PAD, FRONT DOOR TRIM, LOWER RH
67736	SU00304437	PAD, FRONT DOOR TRIM, LOWER LH
68171B	SU00301621	WEATHERSTRIP, FRONT DOOR GLASS, INNER RH
68172A	SU00301622	WEATHERSTRIP, FRONT DOOR GLASS, INNER LH
7401		Ref to 7401
8115		Ref to 8115
8121		Ref to 8121
8401		Ref to 8401
SU00302942	SU00302942	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.15 FRONT DOOR WINDOW REGULATOR & HINGE(6704)

2.15.1 Body - FRONT DOOR WINDOW REGULATOR & HINGE(6704) - 1




677293

PNC	Original P/N	Description
6701		Ref to 6701
69801	SU00301606	REGULATOR SUB-ASSY, FRONT DOOR WINDOW, RH
69802	SU00301607	REGULATOR SUB-ASSY, FRONT DOOR WINDOW, LH
7403		Ref to 7403
85710E	SU00301602	MOTOR ASSY, POWER WINDOW REGULATOR, RH
85720D	SU00301603	MOTOR ASSY, POWER WINDOW REGULATOR, LH
SU00300051	SU00300051	** Std part
SU00302779	SU00302779	** Std part
SU00302892	SU00302892	** Std part
SU00302925	SU00302925	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.15.2 Body - FRONT DOOR WINDOW REGULATOR & HINGE(6704) - 2




677292

PNC	Original P/N	Description
6701		Ref to 6701
68710	SU00301560	HINGE ASSY, FRONT DOOR, UPPER RH
68720	SU00301561	HINGE ASSY, FRONT DOOR, UPPER LH
68730	SU00301561	HINGE ASSY, FRONT DOOR, LOWER RH
68740	SU00301560	HINGE ASSY, FRONT DOOR, LOWER LH
SU00302784	SU00302784	** Std part
SU00302811	SU00302811	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views

2.15.3 Body - FRONT DOOR WINDOW REGULATOR & HINGE(6704) - 3




677294

PNC	Original P/N	Description
6701		Ref to 6701
67241A	SU00301617	STABILIZER, DOOR GLASS, INNER
67255A	SU00301616	STABILIZER, FRONT DOOR GLASS, OUTER
SU00302799	SU00302799	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.16 FRONT FENDER APRON & DASH PANEL(5304)

2.16.1 Body - FRONT FENDER APRON & DASH PANEL(5304) - 1




533688

PNC	Original P/N	Description
53201	SU00301364	SUPPORT SUB-ASSY, RADIATOR
53202	SU00301368	SUPPORT SUB-ASSY, RADIATOR, RH
53203	SU00301369	SUPPORT SUB-ASSY, RADIATOR, LH
53208	SU00301365	SUPPORT SUB-ASSY, RADIATOR GRILLE, CENTER
53213A	SU00301366	SUPPORT, RADIATOR, UPPER RH
53214A	SU00301367	SUPPORT, RADIATOR, UPPER LH
57104A	SU00301372	MEMBER SUB-ASSY, FRONT CROSS
57117E	SU00301370	RETAINER, FRONT BUMPER ARM, RH
57118D	SU00301371	RETAINER, FRONT BUMPER ARM, LH
SU00300002	SU00300002	** Std part
SU00302822	SU00302822	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.16.2 Body - FRONT FENDER APRON & DASH PANEL(5304) - 10




533704A

PNC	Original P/N	Description
5801		Ref to 5801

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.16.3 Body - FRONT FENDER APRON & DASH PANEL(5304) - 2




533739A

PNC	Original P/N	Description
1703		Ref to 1703
2211		Ref to 2211
53291B	SU00301221	PLATE, RADIATOR COVER
53291K	SU00302984	CLIP, RADIATOR COVER PLATE

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.16.6 Body - FRONT FENDER APRON & DASH PANEL(5304) - 5




533691

PNC	Original P/N	Description
5503		Ref to 5503
55101	SU00301361	PANEL SUB-ASSY, DASH

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.16.7 Body - FRONT FENDER APRON & DASH PANEL(5304) - 6




533743

PNC	Original P/N	Description
1603		Ref to 1603
55137C	N/A	BRACKET, TOE BOARD, NO.2
7403		Ref to 7403
8715		Ref to 8715
8718		Ref to 8718
SU00302874	SU00302874	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views

2.16.8 Body - FRONT FENDER APRON & DASH PANEL(5304) - 7




533715

PNC	Original P/N	Description
55210	SU00302955	INSULATOR ASSY, DASH PANEL
5801		Ref to 5801
5804		Ref to 5804
SU00303001	SU00303001	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.16.9 Body - FRONT FENDER APRON & DASH PANEL(5304) - 8



533692

PNC	Original P/N	Description
53607	SU00301232	BRACE SUB-ASSY, FRONT SUSPENSION UPPER TO COWL, RH
53608	SU00301233	BRACE SUB-ASSY, FRONT SUSPENSION UPPER TO COWL, LH
53739	SU00301234	BRACKET, BATTERY SUPPORT
55137A	SU00301226	BRACE, DASH TO FRAME, RH
55138A	SU00301227	BRACE, DASH TO FRAME, LH
55184A	SU00301229	BRACKET, DASH PANEL
SU00300005	SU00300005	** Std part
SU00300053	SU00300053	** Std part
SU00302821	SU00302821	** Std part
SU00302885	SU00302885	** Std part
SU00304076	SU00304076	** Std part


GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

71759C	SU00304395	HOOK, FRONT SEAT BACK, NO.1
71759D	SU00304396	HOOK, FRONT SEAT BACK, NO.2
71910A	SU00301689	HEADREST ASSY, FRONT SEAT
71931	SU00304349	SUPPORT, FRONT SEAT HEADREST
72210	SU00304358	CABLE ASSY, SEAT TRACK CONTROL
72241	SU00304346	BRACKET, SEAT TRACK CABLE
72441A	SU00304404	LINK, FRONT SEAT TRAVEL, NO.1
72442A	SU00304405	LINK, FRONT SEAT TRAVEL, NO.2
73910A	SU00303406	AIR BAG ASSY, FRONT SEAT, RH
73920A	SU00303407	AIR BAG ASSY, FRONT SEAT, LH
78970	SU00304343	BAND ASSY, SEAT LOCK
SU00304344	SU00304344	** Std part
SU00304353	SU00304353	** Std part
SU00304389	SU00304389	** Std part
SU00304390	SU00304390	** Std part
SU00304412	SU00304412	** Std part
SU00304413	SU00304413	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.17.2 Body - FRONT SEAT & SEAT TRACK(7101) - 2

※1 W/O(SEAT HEATER)




717809A

PNC	Original P/N	Description
7104		Ref to 7104
71537F	SU00304409	PROTECTOR, FRONT SEAT CUSHION, NO.2
71537G	SU00304371	PROTECTOR, FRONT SEAT CUSHION EDGE, RH(FOR RH SEAT)
71538A	SU00304375	PROTECTOR, FRONT SEAT CUSHION EDGE, LH(FOR RH SEAT)
71811D	SU00304362	SHIELD, FRONT SEAT CUSHION, RH
71848A	SU00304351	CAP, SEAT ADJUSTER COVER, RH
71861	SU00304367	SHIELD, FRONT SEAT CUSHION, INNER RH
72211	SU00304401	HANDLE, SEAT TRACK ADJUSTING
72525A	SU00304397	HANDLE, RECLINING ADJUSTER RELEASE, RH
SU00302815	SU00302815	** Std part
SU00304379	SU00304379	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.17.3 Body - FRONT SEAT & SEAT TRACK(7101) - 3

※1 W/O(SEAT HEATER)




717994

PNC	Original P/N	Description
7104		Ref to 7104
71537E	SU00304408	PROTECTOR, FRONT SEAT CUSHION, NO.1
71537F	SU00304409	PROTECTOR, FRONT SEAT CUSHION, NO.2
71537H	SU00304374	PROTECTOR, FRONT SEAT CUSHION EDGE, RH(FOR LH SEAT)
71538B	SU00304370	PROTECTOR, FRONT SEAT CUSHION EDGE, LH(FOR LH SEAT)
71812D	SU00304361	SHIELD, FRONT SEAT CUSHION, LH
71849	SU00304352	CAP, SEAT ADJUSTER COVER, LH
71862	SU00304366	SHIELD, FRONT SEAT CUSHION, INNER LH
71873	SU00304377	SHIELD, FRONT SEAT CUSHION, LOWER RH
71874	SU00304378	SHIELD, FRONT SEAT CUSHION, LOWER LH
72211	SU00304401	HANDLE, SEAT TRACK ADJUSTING
72495	SU00304400	HANDLE, VERTICAL ADJUSTING, LH
72526A	SU00304398	HANDLE, RECLINING ADJUSTER RELEASE, LH
SU00302815	SU00302815	** Std part
SU00304379	SU00304379	** Std part
SU00304403	SU00304403	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.18.2 Body - FUEL TANK & TUBE(7701) - 2




773235A

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

PNC	Original P/N	Description
23220A	SU00304154	PUMP ASSY, FUEL W/FILTER
23225A	SU00304162	SPACER, FUEL PUMP
23280J	SU00304155	REGULATOR ASSY, FUEL PRESSURE
23280K	SU00304157	RING, O(FOR FUEL PRESSURE REGULATOR)
77020A	SU00301018	TUBE ASSY, FUEL SUCTION W/PUMP & GAGE
77024A	SU00304166	PLATE SUB-ASSY, FUEL SUCTION
77131C	SU00304153	SUB-TANK, FUEL, NO.1
77203C	SU00304165	BRACKET, FUEL PUMP
77652C	SU00304164	SPRING, FUEL PUMP
77785	SU00304160	HARNESS, FUEL PUMP
8401		Ref to 8401
SU00304156	SU00304156	** Std part
SU00304159	SU00304159	** Std part
SU00304161	SU00304161	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.18.3 Body - FUEL TANK & TUBE(7701) - 3




773241

PNC	Original P/N	Description
77601A	SU00301017	BAND SUB-ASSY, FUEL TANK, NO.1
77641A	SU00301050	PROTECTOR, FUEL TANK, NO.1
77642A	SU00301051	PROTECTOR, FUEL TANK, NO.2
SU00300049	SU00300049	** Std part
SU00301055	SU00301055	** Std part
SU00302984	SU00302984	** Std part
SU00304131	SU00304131	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.18.4 Body - FUEL TANK & TUBE(7701) - 4



N04:この部品については補給していません
N04:This part is not available for service

773242


PNC	Original P/N	Description
77201E	SU00301076	PIPE SUB-ASSY, FUEL TANK FILLER
77202	SU00301079	TUBE SUB-ASSY, BREATHER
77202A	SU00301092	HOSE, FUEL, NO.1 (FOR BREATHER TUBE)
77202B	SU00301097	HOSE, FUEL, NO.2 (FOR BREATHER TUBE)
77202K	SU00301039	CLAMP (FOR BREATHER HOSE)
77216A	SU00301065	SUPPORT, FUEL TANK FILLER PIPE, NO.1
77216B	SU00301062	SUPPORT, FUEL TANK FILLER PIPE, NO.2
77216C	SU00301066	SUPPORT, FUEL TANK FILLER PIPE NO.3
77231A	SU00301044	CONNECTOR, FUEL TANK BREATHER TUBE
77248A	SU00301071	HOLDER, FUEL TANK FILLER PIPE COVER
77291A	SU00301053	SHIELD, FUEL TANK FILLER PIPE
77310A	SU00301020	CAP ASSY, FUEL TANK
77701A	SU00301104	HOSE, FUEL, NO.1 (FOR BREATHER VALVE)
77701B	SU00301094	HOSE, FUEL, NO.2 (FOR BREATHER VALVE)
77720H	SU00301107	VALVE ASSY, FUEL OUTLET
77740	SU00301026	CANISTER ASSY, CHARCOAL
77747	SU00301080	PIPE, CHARCOAL CANISTER, NO.1
77751	SU00301063	BRACKET, CHARCOAL CANISTER BASE
77753	SU00301060	BRACKET, CHARCOAL CANISTER, NO.3
SU00300008	SU00300008	** Std part
SU00300012	SU00300012	** Std part
SU00300051	SU00300051	** Std part
SU00300053	SU00300053	** Std part
SU00300068	SU00300068	** Std part
SU00301024	SU00301024	** Std part
SU00301032	SU00301032	** Std part
SU00301038	SU00301038	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

SU00301040	SU00301040	** Std part
SU00301041	SU00301041	** Std part
SU00302896	SU00302896	** Std part
SU00302993	SU00302993	** Std part
SU00303009	SU00303009	** Std part
SU00304078	SU00304078	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.18.5 Body - FUEL TANK & TUBE(7701) - 5




773243

PNC	Original P/N	Description
2211		Ref to 2211
4708		Ref to 4708
77200A	SU00301075	PIPE ASSY, CENTER
77241U	SU00301057	BRACKET, FUEL CLAMP
77251H	SU00300615	CUSHION, FUEL MAIN TUBE
77252	SU00301048	PROTECTOR, FUEL TUBE
77259D	SU00301096	HOSE, FUEL, NO.1
77279G	SU00301098	HOSE, FUEL, NO.2
77283	SU00301059	BRACKET, FUEL TUBE
77283A	SU00301058	BRACKET, FUEL TUBE CLAMP, NO.1
77285D	SU00301034	CLAMP, FUEL TUBE, NO.1
77286D	SU00301033	CLAMP, FUEL TUBE, NO.2
77286H	SU00301035	CLAMP, FUEL TUBE, NO.3
77286J	SU00301029	CLAMP, FUEL TUBE, NO.4
77419	SU00301095	HOSE, FUEL, NO.3
77740F	SU00301102	TUBE, FUEL, NO.1(FOR CHARCOAL CANISTER)
SU00300013	SU00300013	** Std part
SU00300068	SU00300068	** Std part
SU00301043	SU00301043	** Std part
SU00302128	SU00302128	** Std part
SU00302997	SU00302997	** Std part
SU00304080	SU00304080	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views


2.18.6 Body - FUEL TANK & TUBE(7701) - 6



773244

PNC	Original P/N	Description
77035	SU00301405	CABLE SUB-ASSY, FUEL LID LOCK CONTROL
77035A	SU00303002	CLAMP (FOR FUEL LID LOCK CONTROL CABLE)
77306	SU00301407	LEVER SUB-ASSY, FUEL LID LOCK OPEN
77306C	SU00301412	COVER, HANDLE
SU00302874	SU00302874	** Std part
SU00302935	SU00302935	** Std part
SU00303017	SU00303017	** Std part

2.18.7 Body - FUEL TANK & TUBE(7701) - 7



773240


GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

PNC	Original P/N	Description
77290	SU00301269	SHIELD ASSY, FUEL TANK FILLER PIPE
77350	SU00301473	LID ASSY, FUEL FILLER OPENING
77366	SU00301474	SPRING, FUEL FILLER OPENING LID HINGE
77391A	SU00301272	RING, FUEL INLET BOX
SU00302941	SU00302941	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.19 HOLE PLUG(5701)

2.19.1 Body - HOLE PLUG(5701) - 1




570553

PNC	Original P/N	Description
SU00300400	SU00300400	** Std part
SU00302862	SU00302862	** Std part
SU00303019	SU00303019	** Std part
SU00303026	SU00303026	** Std part
SU00303028	SU00303028	** Std part
SU00303030	SU00303030	** Std part
SU00303032	SU00303032	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views

2.19.2 Body - HOLE PLUG(5701) - 2



570556A

PNC	Original P/N	Description
-----	--------------	-------------

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.19.3 Body - HOLE PLUG(5701) - 3

 SU003-01987	 SU003-02909	 SU003-03039	 SU003-03017	 SU003-03018	 SU003-03038	 SU003-03025	 SU003-03031	 SU003-03040	 SU003-02906
 SU003-02907	 SU003-03036	 SU003-03037	 SU003-03016	 SU003-03030	 SU003-03033	 SU003-03027	 SU003-03035	 SU003-02911	
 REFER TO FIG 46-01	 REFER TO FIG 47-08	 REFER TO FIG 47-08	 REFER TO FIG 61-01	 REFER TO FIG 77-01	 REFER TO FIG 58-01	 REFER TO FIG 82-02			
 REFER TO FIG 76-01									

UNIT: mm

570557A


PNC	Original P/N	Description
4601		Ref to 4601
4708		Ref to 4708
5801		Ref to 5801
6101		Ref to 6101
7601		Ref to 7601
7701		Ref to 7701
8202		Ref to 8202
SU00301987	SU00301987	** Std part
SU00302906	SU00302906	** Std part
SU00302907	SU00302907	** Std part
SU00302909	SU00302909	** Std part
SU00302911	SU00302911	** Std part
SU00303016	SU00303016	** Std part
SU00303017	SU00303017	** Std part
SU00303018	SU00303018	** Std part
SU00303025	SU00303025	** Std part
SU00303027	SU00303027	** Std part
SU00303030	SU00303030	** Std part
SU00303031	SU00303031	** Std part
SU00303033	SU00303033	** Std part
SU00303035	SU00303035	** Std part
SU00303036	SU00303036	** Std part
SU00303037	SU00303037	** Std part
SU00303038	SU00303038	** Std part
SU00303039	SU00303039	** Std part
SU00303040	SU00303040	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.20 HOOD & FRONT FENDER(5302)

2.20.1 Body - HOOD & FRONT FENDER(5302) - 1




533730

PNC	Original P/N	Description
5303		Ref to 5303
5304		Ref to 5304
53301	SU00301394	HOOD SUB-ASSY
53301C	SU00301397	PROTECTOR, HOOD CUSHION
53381B	SU00301396	SEAL, HOOD TO RADIATOR SUPPORT, RH
53382G	SU00301396	SEAL, HOOD TO RADIATOR SUPPORT, LH
7403		Ref to 7403

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.20.2 Body - HOOD & FRONT FENDER(5302) - 2




533700

PNC	Original P/N	Description
53341B	SU00302960	INSULATOR, HOOD
53341C	SU00303011	CLIP(FOR HOOD INSULATOR)

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views

2.20.3 Body - HOOD & FRONT FENDER(5302) - 3




533728

PNC	Original P/N	Description
53383	SU00303139	SEAL, HOOD TO COWL TOP
53383A	SU00302964	CLIP(FOR HOOD TO COWL TOP SEAL)
5503		Ref to 5503
8503		Ref to 8503

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.2.0.4 Body - HOOD & FRONT FENDER(5302) - 4




533697A

PNC	Original P/N	Description
5304		Ref to 5304
53801	SU00301388	FENDER SUB-ASSY, FRONT RH
53802	SU00301389	FENDER SUB-ASSY, FRONT LH
53838A	SU00301392	EXTENSHION, FRONT FENDER, RH
53839A	SU00301393	EXTENSHION, FRONT FENDER, LH
53899	SU00302951	SILENCER
SU00302858	SU00302858	** Std part
SU00302859	SU00302859	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.20.5 Body - HOOD & FRONT FENDER(5302) - 5




533699

PNC	Original P/N	Description
53851D	SU00301554	PAD, FRONT WHEEL OPENING EXTENSION, RH
53852B	SU00301555	PAD, FRONT WHEEL OPENING EXTENSION, LH
53875A	SU00301547	LINER, FRONT FENDER, RH
53876A	SU00301548	LINER, FRONT FENDER, LH
SU00300057	SU00300057	** Std part
SU00301220	SU00301220	** Std part
SU00301536	SU00301536	** Std part
SU00302829	SU00302829	** Std part
SU00302899	SU00302899	** Std part
SU00302989	SU00302989	** Std part
SU00304134	SU00304134	** Std part

2.21 HOOD LOCK & HINGE(5303)

2.21.1 Body - HOOD LOCK & HINGE(5303) - 1

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views



533701

PNC	Original P/N	Description
-----	--------------	-------------


GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5302		Ref to 5302
5304		Ref to 5304
53410	SU00301399	HINGE ASSY, HOOD, RH
53420	SU00301400	HINGE ASSY, HOOD, LH
53451	SU00301395	ROD, HOOD SUPPORT
53451A	SU00303012	GROMMET(FOR HOOD SUPPORT ROD)
53452	SU00303010	HOLDER, HOOD STAY
53510	SU00301402	LOCK ASSY, HOOD
53601	SU00301410	LEVER SUB-ASSY, HOOD LOCK CONTROL
53614	SU00301413	CLAMP, HOOD LOCK CONTROL CABLE
53614A	SU00303006	CLAMP, HOOD LOCK CONTROL CABLE, NO.1
53630	SU00301403	CABLE ASSY, HOOD LOCK CONTROL
53630B	SU00302691	CLAMP(FOR HOOD LOCK CONTROL CABLE)
7403		Ref to 7403
8503		Ref to 8503
SU00300068	SU00300068	** Std part
SU00302797	SU00302797	** Std part
SU00302845	SU00302845	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.22 INSIDE TRIM BOARD & DOOR OPENING TRIM MOULDING(6401)

2.22.1 Body - INSIDE TRIM BOARD & DOOR OPENING TRIM MOULDING(6401) - 1




643053

PNC	Original P/N	Description
4504		Ref to 4504
5501		Ref to 5501
62170A	SU00303424	AIR BAG ASSY, CURTAIN SHIELD, RH
62170B	SU00300070	BOLT, W/WASHER
62180A	SU00303425	AIR BAG ASSY, CURTAIN SHIELD, LH
7101		Ref to 7101
7403		Ref to 7403

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.22.2 Body - INSIDE TRIM BOARD & DOOR OPENING TRIM MOULDING(6401) - 2




643050

PNC	Original P/N	Description
62311B	SU00301637	WEATHERSTRIP, FRONT DOOR OPENING TRIM, RH
62312B	SU00301638	WEATHERSTRIP, FRONT DOOR OPENING TRIM, LH

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.22.3 Body - INSIDE TRIM BOARD & DOOR OPENING TRIM MOULDING(6401) - 3




643051C

PNC	Original P/N	Description
62211	SU00303225	GARNISH, FRONT PILLAR, RH
62211T	SU00302975	CLIP(FOR FRONT PILLAR GARNISH)
62212	SU00303226	GARNISH, FRONT PILLAR, LH
62217G	SU00304477	CLIP, FRONT PILLAR GARNISH
62401A	SU00302977	CLIP (FOR CENTER PILLAR GARNISH PANEL, UPPER)
62411	SU00303227	GARNISH, CENTER PILLAR, RH
62412	SU00303228	GARNISH, CENTER PILLAR, LH
62461A	SU00303231	GARNISH, REAR WINDOW SIDE, RH
62462A	SU00303232	GARNISH, REAR WINDOW SIDE, LH
62471M	SU00304135	CLIP
62597D	SU00302969	CLIP
62605Q	SU00303237	LID SUB-ASSY, QUARTER TRIM, RH
62606A	SU00303238	LID SUB-ASSY, QUARTER TRIM, LH
62630Q	SU00302969	CLIP (FOR QUARTER TRIM)
62638	SU00303229	GARNISH, REAR QUARTER TRIM FRONT, RH
62639	SU00303230	GARNISH, REAR QUARTER TRIM FRONT, LH
SU00301535	SU00301535	** Std part
SU00302984	SU00302984	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.22.4 Body - INSIDE TRIM BOARD & DOOR OPENING TRIM MOULDING(6401) - 4




643069

PNC	Original P/N	Description
62111C	SU00303253	BOARD, COWL SIDE TRIM, RH
62112	SU00303255	BOARD, COWL SIDE TRIM, LH
62117B	SU00302968	CLIP, NO.1(FOR COWL SIDE TRIM)
62117C	SU00302986	CLIP, NO.2(FOR COWL SIDE TRIM)
67911B	SU00303252	PLATE, FRONT DOOR SCUFF, OUTSIDE, RH
67912A	SU00303260	PLATE, FRONT DOOR SCUFF, OUTSIDE LH
67913	SU00303247	PLATE, FRONT DOOR SCUFF, RH
67913A	SU00302983	CLIP(FOR SCUFF PLATE)
67914	SU00303249	PLATE, FRONT DOOR SCUFF, LH

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.23 INSTRUMENT PANEL & GLOVE COMPARTMENT(5501)

2.23.1 Body - INSTRUMENT PANEL & GLOVE COMPARTMENT(5501) - 1




552922

PNC	Original P/N	Description
55312A	SU00302967	CLIP, INSTRUMENT PANEL
55317A	SU00301924	PANEL, INSTRUMENT SIDE, RH
55318C	SU00301925	PANEL, INSTRUMENT SIDE, LH
55408F	SU00301951	PANEL SUB-ASSY, INSTRUMENT PANEL SPEAKER, NO.1
55409F	SU00301952	PANEL SUB-ASSY, INSTRUMENT PANEL SPEAKER, NO.2
55434E	SU00302961	CAP
55435A	SU00301970	PANEL, INSTRUMENT PANEL FINISH, END RH
55436A	SU00301971	PANEL, INSTRUMENT PANEL FINISH, END LH
55606	SU00301983	COVER SUB-ASSY, INSTRUMENT PANEL UNDER, NO.1
55607	SU00301922	COVER SUB-ASSY, INSTRUMENT PANEL UNDER, NO.2
8602		Ref to 8602
SU00300064	SU00300064	** Std part
SU00302931	SU00302931	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.23.2 Body - INSTRUMENT PANEL & GLOVE COMPARTMENT(5501) - 2




552332

PNC	Original P/N	Description
55061	SU00301942	REGISTER SUB-ASSY, INSTRUMENT PANEL, NO.1
55062	SU00301943	REGISTER SUB-ASSY, INSTRUMENT PANEL, NO.2
55312A	SU00302967	CLIP, INSTRUMENT PANEL
55349A	SU00301968	CUSHION, INSTRUMENT PANEL
55403	SU00301959	HOOD SUB-ASSY, METER
55405B	SU00301912	PANEL SUB-ASSY, INSTRUMENT CLUSTER FINISH, CENTER
55422	SU00301958	ORNAMENT, INSTRUMENT PANEL METER, UPPER
55461A	SU00301934	ORNAMENT, INSTRUMENT PANEL
55650B	SU00301916	BEZEL, INSTRUMENT PANEL REGISTER
55670A	SU00301945	REGISTER ASSY, INSTRUMENT PANEL, CENTER
55981	SU00301948	GARNISH, DEFROSTER NOZZLE, NO.1
55982	SU00301949	GARNISH, DEFROSTER NOZZLE, NO.2
55983	SU00301950	GARNISH, DEFROSTER NOZZLE, NO.3
8301		Ref to 8301
8401		Ref to 8401
8601		Ref to 8601
SU00302915	SU00302915	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.23.3 Body - INSTRUMENT PANEL & GLOVE COMPARTMENT(5501) - 3




552929A

PNC	Original P/N	Description
55044B	SU00301919	PANEL SUB-ASSY, INSTRUMENT PANEL FINISH, UPPER
55045C	SU00301920	PANEL SUB-ASSY, INSTRUMENT PANEL FINISH, UPPER
55302C	SU00301906	PANEL SUB-ASSY, INSTRUMENT
55303B	SU00301908	PANEL SUB-ASSY, INSTRUMENT, LOWER
55309C	SU00301967	REINFORCEMENT SUB-ASSY, INSTRUMENT PANEL, CENTER
55312A	SU00302967	CLIP, INSTRUMENT PANEL
55406B	SU00301914	PANEL SUB-ASSY, INSTRUMENT CLUSTER FINISH, LOWER CENTER
55474C	SU00301929	GARNISH, INSTRUMENT CLUSTER FINISH PANEL, NO.1
55475A	SU00301930	GARNISH, INSTRUMENT CLUSTER FINISH PANEL, NO.2
55503B	SU00301956	CUSHION(FOR GLOVE COMPARTMENT)
55510A	SU00304310	CUSHION(FOR GLOVE COMPARTMENT DOOR)
55550	SU00301955	DOOR ASSY, GLOVE COMPARTMENT
55557C	SU00301972	DAMPER, GLOVE COMPARTMENT DOOR
55558	SU00301965	REINFORCEMENT, GLOVE COMPARTMENT DOOR
8401		Ref to 8401
8715		Ref to 8715
SU00301974	SU00301974	** Std part
SU00302866	SU00302866	** Std part
SU00302915	SU00302915	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.23.4 Body - INSTRUMENT PANEL & GLOVE COMPARTMENT(5501) - 4




552926

PNC	Original P/N	Description
55315A	SU00302991	SPACER, INSTRUMENT PANEL, NO.1
55330B	SU00301977	REINFORCEMENT ASSY, INSTRUMENT PANEL
55394B	SU00302856	BOLT, INSTRUMENT PANEL
55394C	SU00302855	BOLT, INSTRUMENT PANEL
SU00300980	SU00300980	** Std part
SU00302915	SU00302915	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.23.6 Body - INSTRUMENT PANEL & GLOVE COMPARTMENT(5501) - 6




552950

PNC	Original P/N	Description
4504		Ref to 4504
6401		Ref to 6401
7101		Ref to 7101
73900	SU00303433	AIR BAG ASSY, INSTRUMENT PANEL, LOWER NO.1
73960A	SU00303427	AIR BAG ASSY, INSTRUMENT PANEL PASSENGER W/O DOOR
7403		Ref to 7403
SU00300008	SU00300008	** Std part
SU00300051	SU00300051	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views

2.23.7 Body - INSTRUMENT PANEL & GLOVE COMPARTMENT(5501) - 7




552954

PNC	Original P/N	Description
55522B	SU00302639	COVER, RADIO TUNER OPENING
8401		Ref to 8401
8601		Ref to 8601
SU00300062	SU00300062	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.24 LOCK CYLINDER SET(6712)

2.24.1 Body - LOCK CYLINDER SET(6712) - 1



※1 ATM


N05: This part is not supplied because it can be substituted with goods on the market

677375A

PNC	Original P/N	Description
4501		Ref to 4501
69051	N/A	CYLINDER & KEY SET, DOOR LOCK, RH
69052	SU00301443	CYLINDER & KEY SET, DOOR LOCK, LH
69055A	SU00301429	CYLINDER & KEY SET, LUGGAGE COMPARTMENT LOCK
69057A	N/A	CYLINDER & KEY SET, IGNITION SWITCH LOCK
69503	SU00301421	CYLINDER SET, LOCK
8401		Ref to 8401
8424		Ref to 8424
88027	N/A	LABEL, KEY LESS
89070E	N/A	TRANSMITTER ASSY, DOOR CONTROL
89071B	N/A	MODULE SET, TRANSMITTER SUB-ASSY, DOOR CONTROL
8907A	N/A	SWITCH SET, TRANSMITTER
89751A	N/A	COVER, TRANSMITTER HOUSING
89752A	N/A	CASE, TRANSMITTER HOUSING
89785B	N/A	TRANSMITTER, TRANSPONDER KEY MASTER

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.24.2 Body - LOCK CYLINDER SET(6712) - 2



N05: This part is not supplied because it can be substituted with goods on the market


677377A

PNC	Original P/N	Description
4501		Ref to 4501
69051	N/A	CYLINDER & KEY SET, DOOR LOCK, RH
69052	SU00301443	CYLINDER & KEY SET, DOOR LOCK, LH
69055A	SU00301429	CYLINDER & KEY SET, LUGGAGE COMPARTMENT LOCK
69503	SU00301421	CYLINDER SET, LOCK
69503A	SU00301451	KEY, BLANK
69503B	SU00301424	KEY, CUT
8401		Ref to 8401
8420		Ref to 8420
89904B	SU00302769	TRANSMITTER SUB-ASSY, ELECTRICAL KEY

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.25 LUGGAGE COMPARTMENT DOOR & LOCK(6105)

2.25.1 Body - LUGGAGE COMPARTMENT DOOR & LOCK(6105) - 1




614220A

PNC	Original P/N	Description
64401	SU00301454	PANEL SUB-ASSY, LUGGAGE COMPARTMENT DOOR
64459	SU00301472	CUSHION, LUGGAGE COMPARTMENT DOOR
64461	SU00301469	WEATHERSTRIP, LUGGAGE COMPARTMENT DOOR
64469	SU00301470	CUSHION, LUGGAGE COMPARTMENT DOOR, NO.2
64510	SU00301460	HINGE ASSY, LUGGAGE COMPARTMENT DOOR, RH
64520	SU00301461	HINGE ASSY, LUGGAGE COMPARTMENT DOOR, LH
64530A	SU00301462	SUPPORT ASSY, LUGGAGE COMPARTMENT DOOR
64554	SU00301471	STOPPER, LUGGAGE DOOR BALANCER
64620E	SU00301467	STRIKER ASSY, LUGGAGE COMPARTMENT DOOR
64650	SU00301465	CLOSER ASSY, LUGGAGE DOOR
64660	SU00301406	CABLE ASSY, LUGGAGE CLOSER
6712		Ref to 6712
SU00300025	SU00300025	** Std part
SU00301413	SU00301413	** Std part
SU00302789	SU00302789	** Std part
SU00302806	SU00302806	** Std part
SU00302898	SU00302898	** Std part
SU00302980	SU00302980	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.25.2 Body - LUGGAGE COMPARTMENT DOOR & LOCK(6105) - 2




614180

PNC	Original P/N	Description
5801		Ref to 5801
SU00303034	SU00303034	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.26 MAT & CARPET(5804)

2.26.1 Body - MAT & CARPET(5804) - 1




584451A

PNC	Original P/N	Description
58190B	N/A	REST ASSY, FRONT FLOOR FOOT
SU00302840	SU00302840	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.26.2 Body - MAT & CARPET(5804) - 2




584453

PNC	Original P/N	Description
58192A	SU00303336	FOOTREST, FRONT FLOOR, LH
58510D	SU00303333	CARPET ASSY, FLOOR, FRONT
58510E	SU00303328	RETAINER, FLOOR CARPET
58520C	SU00302972	CLIP(FOR FRONT FLOOR CARPET)
58530B	SU00303344	CLIP(FOR FRONT FLOOR CARPET)
58560B	SU00303344	CLIP(FOR FLOOR CARPET, REAR)
58621J	SU00304321	SILENCER, CENTER CONSOLE, NO.1
58694A	SU00303342	PLATE, MAT SET, UPPER
58698C	SU00303343	PLATE, MAT SET, LOWER
SU00302971	SU00302971	** Std part
SU00302973	SU00302973	** Std part
SU00302976	SU00302976	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.26.3 Body - MAT & CARPET(5804) - 3




584530

PNC	Original P/N	Description
58511H	SU00304277	MAT, FLOOR, FRONT RH
58512B	SU00304278	MAT, FLOOR, FRONT LH
58514C	SU00304279	MAT, FLOOR, REAR

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.26.4 Body - MAT & CARPET(5804) - 4




584452

PNC	Original P/N	Description
58556C	SU00302949	SILENCER, REAR FLOOR
58571F	SU00302944	PAD, FRONT FLOOR, FRONT
58621G	SU00302947	PAD, FRONT FLOOR SILENCER, RH
58622C	SU00302947	PAD, FRONT FLOOR SILENCER, LH
58624C	SU00302945	PAD, CENTER FLOOR SILENCER, RH
58625C	SU00302946	PAD, CENTER FLOOR SILENCER, LH
58673C	SU00302948	PAD, REAR FLOOR SILENCER, NO.1
58674B	SU00302948	PAD, REAR FLOOR SILENCER, NO.2
58676H	SU00304317	PAD, REAR FLOOR SILENCER

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views

2.26.5 Body - MAT & CARPET(5804) - 5




584454

PNC	Original P/N	Description
5304		Ref to 5304
5801		Ref to 5801
58293C	SU00302956	PAD, FRONT FLOOR
SU00303328	SU00303328	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.27 MUDGUARD & SPOILER(7601)

2.27.1 Body - MUDGUARD & SPOILER(7601) - 1




760831

PNC	Original P/N	Description
5201		Ref to 5201
71196A	SU00302984	CLIP
76851A	SU00304184	COVER, FRONT SPOILER, RH
76852A	SU00304192	COVER, FRONT SPOILER, LH
76853B	SU00304176	COVER, FRONT SPOILER, CENTER
76857	SU00304200	RETAINER, FRONT SPOILER SIDE, RH
76858	SU00304201	RETAINER, FRONT SPOILER SIDE, LH
76917D	SU00302964	CLIP
76917E	SU00302989	CLIP
SU00301514	SU00301514	** Std part
SU00303352	SU00303352	** Std part
SU00304226	SU00304226	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.27.2 Body - MUDGUARD & SPOILER(7601) - 2




760832A

PNC	Original P/N	Description
5202		Ref to 5202
76793C	SU00303949	BRACKET, REAR SPOILER, NO.2 RH
76794C	SU00303950	BRACKET, REAR SPOILER, NO.2 LH
76867	SU00303971	RETAINER, REAR SPOILER SIDE, RH
76868	SU00303972	RETAINER, REAR SPOILER SIDE, LH
76871B	SU00303954	COVER, REAR SPOILER
76879B	SU00304055	CLIP, REAR SPOILER, NO.2
76889	SU00302963	CLIP, REAR SPOILER, NO.2
76889D	SU00302988	CLIP, REAR SPOILER, NO.2
76897A	SU00303955	SPOILER, REAR SIDE RH
76898A	SU00303963	SPOILER, REAR SIDE LH
76973D	SU00303952	COVER, REAR UNDER SIDE, RH
76974D	SU00303953	COVER, REAR UNDER SIDE, LH
SU00303352	SU00303352	** Std part
SU00304223	SU00304223	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views

2.27.3 Body - MUDGUARD & SPOILER(7601) - 3




760833A

PNC	Original P/N	Description
71196	SU00302982	CLIP(FOR REAR SPOILER)
76085A	SU00301986	CAP(FOR REAR SPOILER)
76871	SU00303368	SPOILER, REAR
76879	SU00302970	CLIP, REAR SPOILER, NO.1
SU00304269	SU00304269	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.27.4 Body - MUDGUARD & SPOILER(7601) - 4




760834

PNC	Original P/N	Description
76085A	SU00301986	CAP(FOR REAR SPOILER)
76791	SU00303382	BRACKET, REAR SPOILER, NO.1 RH
76792B	SU00303383	BRACKET, REAR SPOILER, NO.1 LH
76871	SU00303368	SPOILER, REAR
76893A	SU00303384	COVER, REAR SPOILER, RH
76894	SU00303391	COVER, REAR SPOILER, LH
SU00302795	SU00302795	** Std part
SU00302853	SU00302853	** Std part
SU00304269	SU00304269	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.28 PACKAGE TRAY PANEL & LUGGAGE COMPARTMENT MAT(6403)

2.28.1 Body - PACKAGE TRAY PANEL & LUGGAGE COMPARTMENT MAT(6403) - 1




643066A

PNC	Original P/N	Description
64330	SU00301901	PANEL ASSY, PACKAGE TRAY TRIM
64330A	SU00302986	CLIP(FOR PACKAGE TRAY TRIM PANEL)
64330J	SU00302969	CLIP(FOR PACKAGE TRAY TRIM PANEL)
7104		Ref to 7104
71295	SU00304318	PLATE, REAR SEAT BACK, UPPER RH
71296A	SU00304319	PLATE, REAR SEAT BACK, UPPER LH
SU00302969	SU00302969	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views

2.28.2 Body - PACKAGE TRAY PANEL & LUGGAGE COMPARTMENT MAT(6403) - 2




643086

PNC	Original P/N	Description
64332	SU00302525	COVER, PACKAGE TRAY TRIM
8117		Ref to 8117

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.28.3 Body - PACKAGE TRAY PANEL & LUGGAGE COMPARTMENT MAT(6403) - 3




643067

PNC	Original P/N	Description
58387	SU00303322	PLATE, REAR FLOOR FINISH
64376A	SU00303345	SPACER, PACKAGE TRAY TRIM, NO.2
64385B	SU00302986	CLIP
64429F	SU00303129	BOX, LUGGAGE COMPARTMENT TRIM
64429H	SU00303347	TRAY, LUGGAGE COMPARTMENT SIDE
64429J	SU00303348	TRAY, LUGGAGE COMPARTMENT SIDE
64711	SU00303321	MAT, LUGGAGE COMPARTMENT FLOOR
64714D	SU00303235	COVER, LUGGAGE COMPARTMENT TRIM, SIDE, RH
64714J	SU00303239	COVER, DECK SIDE TRIM, RH
64715D	SU00303236	COVER, LUGGAGE COMPARTMENT TRIM, SIDE, LH
64715F	SU00303240	COVER, DECK SIDE TRIM, LH
64719A	SU00303325	COVER, LUGGAGE COMPARTMENT DOOR
64721	SU00303323	COVER, LUGGAGE COMPARTMENT TRIM, INNER RH
64721C	SU00302969	CLIP(LUGGAGE COMPARTMENT)
64721H	SU00303338	CLIP(LUGGAGE COMPARTMENT)
64722	SU00303324	COVER, LUGGAGE COMPARTMENT TRIM, INNER LH
64726A	SU00303261	CLIP, LUGGAGE TRIM, REAR
SU00303341	SU00303341	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.29 QUARTER WINDOW(6103)

2.29.1 Body - QUARTER WINDOW(6103) - 1




614172

PNC	Original P/N	Description
62710A	SU003G0012	WINDOW ASSY, QUARTER, RH
62720A	SU003G0013	WINDOW ASSY, QUARTER, LH
62741B	SU00304121	SEAL, QUARTER WINDOW GLASS, RH
62742B	SU00304121	SEAL, QUARTER WINDOW GLASS, LH

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.30 REAR BUMPER & BUMPER STAY(5202)

2.30.1 Body - REAR BUMPER & BUMPER STAY(5202) - 1




522623A

PNC	Original P/N	Description
0901		Ref to 0901
52152C	SU00302963	CLIP, REAR BUMPER SIDE
52159	SU00301494	COVER, REAR BUMPER
52162D	SU00302984	PIECE, REAR BUMPER
52162E	SU00302989	PIECE, REAR BUMPER
52163A	SU00301530	PLATE, REAR BUMPER, RH
52164A	SU00301531	PLATE, REAR BUMPER, LH
52167	SU00301509	REINFORCEMENT, REAR BUMPER
52169B	SU00301507	BRACKET, REAR BUMPER, CENTER
52171A	SU00301512	REINFORCEMENT, REAR BUMPER, NO.1
52172B	SU00301513	REINFORCEMENT, REAR BUMPER, NO.2
52185A	SU00301501	BRACKET, REAR BUMPER SIDE, RH
52186A	SU00301502	BRACKET, REAR BUMPER SIDE, LH
52461F	SU00304202	PAD, REAR BUMPER
52561A	SU00302988	CLIP(FOR REAR BUMPER RETAINER)
52575	SU00301503	RETAINER, REAR BUMPER SIDE, RH
52576	SU00301504	RETAINER, REAR BUMPER SIDE, LH
52591	SU00301527	SEAL, REAR BUMPER SIDE, RH
52592	SU00301528	SEAL, REAR BUMPER SIDE, LH
6101		Ref to 6101
SU00302801	SU00302801	** Std part
SU00302880	SU00302880	** Std part
SU00302918	SU00302918	** Std part
SU00303352	SU00303352	** Std part
SU00303367	SU00303367	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views

2.30.2 Body - REAR BUMPER & BUMPER STAY(5202) - 2




522657

PNC	Original P/N	Description
52159	SU00301494	COVER, REAR BUMPER
7601		Ref to 7601

2.31 REAR MOULDING(7504)

2.31.1 Body - REAR MOULDING(7504) - 1

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views



752678A


GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

PNC	Original P/N	Description
7501		Ref to 7501
75819	SU00304272	CLIP, LUGGAGE COMPARTMENT DOOR MOULDING
75827E	SU00304274	PROTECTOR, LUGGAGE DOOR MOULDING
76801A	SU00304056	GARNISH SUB-ASSY, LUGGAGE COMPARTMENT DOOR, OUTSIDE
76821A	SU00304273	PROTECTOR, LUGGAGE COMPARTMENT DOOR OUTSIDE GARNISH
8401		Ref to 8401
SU00302881	SU00302881	** Std part
SU00304270	SU00304270	** Std part
SU00304271	SU00304271	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.32 REAR SEAT & SEAT TRACK(7102)

2.32.1 Body - REAR SEAT & SEAT TRACK(7102) - 1




71779

PNC	Original P/N	Description
71301D	SU00301862	HINGE SUB-ASSY, REAR SEAT, RH
71302D	SU00301863	HINGE SUB-ASSY, REAR SEAT, LH
71329	SU00302810	BOLT, REAR SEAT HINGE
72601A	SU00301864	STRIKER SUB-ASSY, REAR SEAT BACK LOCK, RH
72602A	SU00301865	STRIKER SUB-ASSY, REAR SEAT BACK LOCK, LH
SU00302813	SU00302813	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.32.2 Body - REAR SEAT & SEAT TRACK(7102) - 2




N04:この部品については補給していません
N04:This part is not available for service

717780

PNC	Original P/N	Description
71017A	SU00301818	FRAME SUB-ASSY, REAR SEAT BACK
71075E	SU00304228	CLIP(FOR REAR SEAT)
71075S	SU00301825	COVER, REAR SEAT CUSHION, RH (FOR SEPARATE TYPE)
71076S	SU00301832	COVER, REAR SEAT CUSHION, LH (FOR SEPARATE TYPE)
71077B	SU00301846	COVER, REAR SEAT BACK (FOR BENCH TYPE)
71297A	SU00304120	WIRE, REAR SEAT BACK
71377	SU00301698	GUIDE, CONTROL LEVER
71602	SU00301869	LOCK SUB-ASSY, REAR SEAT BACK, RH
71603	SU00301868	LOCK SUB-ASSY, REAR SEAT BACK, LH
71611A	SU00301820	PAD, REAR SEAT CUSHION, RH
71612A	SU00301819	PAD, REAR SEAT CUSHION, LH
71639A	SU00304205	KNOB, REAR SEAT LOCK
71651B	SU00301821	PAD, REAR SEAT BACK(FOR BENCH TYPE)
72651D	SU00301861	ROD, REAR SEAT BACK LOCK, RH
72651E	SU00301860	ROD, REAR SEAT BACK LOCK, LH
72665B	SU00304203	COVER, REAR SEAT BACK LOCK
79915	SU00301817	BRACKET, SEAT LEG
SU00300061	SU00300061	** Std part
SU00302848	SU00302848	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.32.3 Body - REAR SEAT & SEAT TRACK(7102) - 3




717800

PNC	Original P/N	Description
7104		Ref to 7104
73705	SU00303398	BRACKET SUB-ASSY, CHILD RESTRAINT SEAT ANCHOR, RH
73706	SU00303398	BRACKET SUB-ASSY, CHILD RESTRAINT SEAT ANCHOR, LH
SU00302842	SU00302842	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.33 ROOF HEADLINING & SILENCER PAD(6402)

2.33.1 Body - ROOF HEADLINING & SILENCER PAD(6402) - 1




643062

PNC	Original P/N	Description
63305F	SU00302969	CLIP(FOR ROOF HEADLINING TRIM)
63310	SU00303317	HEADLINING ASSY, ROOF
63310D	SU00303320	CLIP, ROOF HEADLINING
8202		Ref to 8202
8604		Ref to 8604

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.34 ROOF PANEL & BACK WINDOW GLASS(6104)

2.34.1 Body - ROOF PANEL & BACK WINDOW GLASS(6104) - 1




614170

PNC	Original P/N	Description
63102A	SU00301374	PANEL SUB-ASSY, WINDSHIELD HEADER
63111	SU00301376	PANEL, ROOF
63123C	SU00301378	REINFORCEMENT, ROOF PANEL
63141H	SU00301377	REINFORCEMENT, ROOF PANEL, CENTER
63143A	SU00301375	REINFORCEMENT, ROOF PANEL

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.34.2 Body - ROOF PANEL & BACK WINDOW GLASS(6104) - 2




614182

PNC	Original P/N	Description
6101		Ref to 6101
64101	SU00301373	PANEL SUB-ASSY, UPPER BACK

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views

2.34.3 Body - ROOF PANEL & BACK WINDOW GLASS(6104) - 3




614181

PNC	Original P/N	Description
56115B	SU00301896	STOPPER, BACK WINDOW GLASS, NO.1
56116D	SU00301897	STOPPER, BACK WINDOW GLASS, NO.2
64811	SU003G0008	GLASS, BACK WINDOW
64813D	SU00301898	DAM, BACK WINDOW GLASS ADHESIVE
64814C	SU00301899	DAM, BACK WINDOW GLASS ADHESIVE, LOWER
75571G	SU00301900	MOULDING, BACK WINDOW, OUTSIDE UPPER, NO.1

2.35 ROOF SIDE VENTILATOR(6102)

2.35.1 Body - ROOF SIDE VENTILATOR(6102) - 1




614165

PNC	Original P/N	Description
62931B	SU00302111	DUCT, QUARTER VENT

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.36 SEAT BELT & CHILD RESTRAINT SEAT(7104)

2.36.1 Body - SEAT BELT & CHILD RESTRAINT SEAT(7104) - 1




71775A

PNC	Original P/N	Description
73210	SU00301874	BELT ASSY, FRONT SEAT OUTER, RH
73220	SU00301875	BELT ASSY, FRONT SEAT OUTER, LH
73230	SU00301881	BELT ASSY, FRONT SEAT INNER, RH
73240	SU00301880	BELT ASSY, FRONT SEAT INNER, LH
SU00300068	SU00300068	** Std part
SU00302809	SU00302809	** Std part
SU00304388	SU00304388	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views

2.36.2 Body - SEAT BELT & CHILD RESTRAINT SEAT(7104) - 2




71776

PNC	Original P/N	Description
73360	SU00301885	BELT ASSY, REAR SEAT 3 POINT TYPE, OUTER RH
73370	SU00301886	BELT ASSY, REAR SEAT 3 POINT TYPE, OUTER LH
73380	SU00301887	BELT ASSY, REAR SEAT 3 POINT TYPE, INNER, RH
73390	SU00301887	BELT ASSY, REAR SEAT 3 POINT TYPE, INNER, LH
SU00302809	SU00302809	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views

2.36.3 Body - SEAT BELT & CHILD RESTRAINT SEAT(7104) - 3




11111

PNC	Original P/N	Description
7102		Ref to 7102
73719	SU00303399	BRACKET, CHILD RESTRAINT SEAT TETHER ANCHOR
SU00302832	SU00302832	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views

2.36.4 Body - SEAT BELT & CHILD RESTRAINT SEAT(7104) - 4




717778

PNC	Original P/N	Description
6403		Ref to 6403
73731B	SU00301902	COVER, CHILD RESTRAINT SEAT, NO.1
73731C	SU00301903	COVER, CHILD RESTRAINT SEAT, NO.2

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.37 SIDE MEMBER(6101)

2.37.1 Body - SIDE MEMBER(6101) - 1




614106A

PNC	Original P/N	Description
55713C	SU00301255	PANEL, COWL TOP SIDE, RH
55714C	SU00301256	PANEL, COWL TOP SIDE, LH
61037A	SU00301257	REINFORCEMENT SUB-ASSY, CENTER BODY PILLAR, RH
61038A	SU00301258	REINFORCEMENT SUB-ASSY, CENTER BODY PILLAR, LH
61108A	SU00301259	REINFORCE SUB-ASSY, FRONT BODY PILLAR, LOWER RH
61109A	SU00301260	REINFORCE SUB-ASSY, FRONT BODY PILLAR, LOWER LH
61131	SU00301245	PILLAR, FRONT BODY, UPPER OUTER RH
61132	SU00301246	PILLAR, FRONT BODY, UPPER OUTER LH
61201	SU00301261	RAIL SUB-ASSY, ROOF SIDE, RH
61202	SU00301262	RAIL SUB-ASSY, ROOF SIDE, LH
61403C	SU00301270	REINFORCE SUB-ASSY, ROCKER, OUTER RH
61404E	SU00301271	REINFORCE SUB-ASSY, ROCKER, OUTER LH
61431	SU00301251	PANEL, ROCKER, OUTER REAR RH
61432	SU00301252	PANEL, ROCKER, OUTER REAR LH
61611	SU00301247	PANEL, QUARTER, RH
61612	SU00301248	PANEL, QUARTER, LH
61613E	SU00301263	PANEL, QUARTER, INNER RH
61614E	SU00301264	PANEL, QUARTER, INNER LH
61617A	SU00301265	PANEL, QUARTER INNER, REAR RH
61618A	SU00301266	PANEL, QUARTER, INNER REAR LH
61627E	SU00301267	EXTENSION, QUARTER PANEL, REAR LOWER RH
61628D	SU00301268	EXTENSION, QUARTER PANEL, REAR LOWER LH
SU00301987	SU00301987	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.37.2 Body - SIDE MEMBER(6101) - 2




614167

PNC	Original P/N	Description
61023B	SU00301275	PILLAR SUB-ASSY, FRONT BODY, INNER RH
61024B	SU00301276	PILLAR SUB-ASSY, FRONT BODY, INNER LH
61032A	SU00301281	PILLAR SUB-ASSY, NO.1 INNER, RH
6104		Ref to 6104
61042A	SU00301282	PILLAR SUB-ASSY, NO.1 INNER, LH
61057A	SU00301285	EXTENSION SUB-ASSY, QUARTER LOCK PILLAR
61058A	SU00301286	EXTENSION SUB-ASSY, QUARTER LOCK PILLAR, LH
61135	SU00301230	REINFORCEMENT, FRONT BODY PILLAR, UPPER RH
61136	SU00301231	REINFORCEMENT, FRONT BODY PILLAR, UPPER LH
61158A	SU00301277	EXTENSION, FRONT PILLER, LOWER RH
61159K	SU00301278	EXTENSION, FRONT PILLER, LOWER LH
61203	SU00301279	RAIL SUB-ASSY, ROOF SIDE, INNER RH
61204	SU00301280	RAIL SUB-ASSY, ROOF SIDE, INNER LH
61452	SU00301287	PANEL, ROCKER INNER, FRONT RH
61453A	SU00301289	PANEL, ROCKER INNER, REAR RH
61462	SU00301288	PANEL, ROCKER, INNER FRONT LH
61463A	SU00301290	PANEL, ROCKER, INNER REAR LH
61601B	SU00301273	PANEL SUB-ASSY, QUARTER, RH
61602C	SU00301274	PANEL SUB-ASSY, QUARTER, LH
61631A	SU00301283	PANEL, QUARTER WHEEL HOUSE, OUTER RH
61632A	SU00301284	PANEL, QUARTER WHEEL HOUSE, OUTER LH
SU00302828	SU00302828	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.37.3 Body - SIDE MEMBER(6101) - 3




614191

PNC	Original P/N	Description
5305		Ref to 5305
5801		Ref to 5801
61165	SU00301241	PILLAR, FRONT BODY LOWER INNER, RH
61166	SU00301242	PILLAR, FRONT BODY LOWER INNER, LH

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.37.4 Body - SIDE MEMBER(6101) - 4




614168

PNC	Original P/N	Description
65631C	SU00301556	PLATE, REAR WHEEL HOUSE, FRONT RH
65632B	SU00301557	PLATE, REAR WHEEL HOUSE, FRONT LH
65637	SU00301551	LINER, REAR WHEEL HOUSE, RH
65638	SU00301552	LINER, REAR WHEEL HOUSE, LH
SU00302984	SU00302984	** Std part
SU00302989	SU00302989	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.37.5 Body - SIDE MEMBER(6101) - 5




614169

PNC	Original P/N	Description
62155B	SU00302952	PAD, QUARTER PANEL

2.38 SIDE MOULDING(7503)

2.38.1 Body - SIDE MOULDING(7503) - 1

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views




752659

PNC	Original P/N	Description
-----	--------------	-------------

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

7501		Ref to 7501
75601A	SU00303109	MOULDING SUB-ASSY, FRONT FENDER, RH
75602A	SU00303117	MOULDING SUB-ASSY, FRONT FENDER, LH
75871A	SU00303092	CLIP (FOR FRONT FENDER MOULDING NO.1)
75895A	SU00303132	TAPE, MOULDING, NO.1

2.38.2 Body - SIDE MOULDING(7503) - 2




GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

PNC	Original P/N	Description
75853	SU00303130	PROTECTOR, REAR FENDER, RH
75854	SU00303131	PROTECTOR, REAR FENDER, LH

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views


2.38.3 Body - SIDE MOULDING(7503) - 3



752701

PNC	Original P/N	Description
6701		Ref to 6701
67863F	SU00301633	WEATHERSTRIP, FRONT DOOR, NO.2 RH
67864F	SU00301634	WEATHERSTRIP, FRONT DOOR, NO.2 LH
67869M	SU00304053	CLIP, DOOR WEATHERSTRIP
75551	SU00301635	MOULDING, ROOF DRIP SIDE FINISH, RH
75552	SU00301636	MOULDING, ROOF DRIP SIDE FINISH, LH
SU00301629	SU00301629	** Std part
SU00302920	SU00302920	** Std part

2.38.4 Body - SIDE MOULDING(7503) - 4




752662

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

PNC	Original P/N	Description
75555D	SU00303068	MOULDING, ROOF DRIP SIDE FINISH, CENTER RH
75556C	SU00303069	MOULDING, ROOF DRIP SIDE FINISH, CENTER LH
75561	SU00302992	CLIP, ROOF DRIP SIDE FINISH MOULDING, NO.1

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.38.5 Body - SIDE MOULDING(7503) - 5




752663

PNC	Original P/N	Description
75850A	SU00303353	MOULDING ASSY, BODY ROCKER PANEL, RH
75860A	SU00303360	MOULDING ASSY, BODY ROCKER PANEL, LH
75867A	SU00302964	CLIP, ROCKER PANEL MOULDING
75867C	SU00302978	CLIP, ROCKER PANEL MOULDING
75868B	SU00302989	CLIP, ROCKER PANEL MOULDING, NO.2
76923B	SU00302990	RETAINER, SIDE MUDGUARD

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.39 SPARE WHEEL CARRIER(5104)

2.39.1 Body - SPARE WHEEL CARRIER(5104) - 1




512491

PNC	Original P/N	Description
0901		Ref to 0901
51929	SU00304451	HOLDER, SPARE WHEEL CARRIER
51933C	SU00303404	STOPPER, SPARE WHEEL
6403		Ref to 6403

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.40 SUSPENSION CROSSMEMBER & UNDER COVER(5102)

2.40.1 Body - SUSPENSION CROSSMEMBER & UNDER COVER(5102) - 1




512443

PNC	Original P/N	Description
4802		Ref to 4802
4803		Ref to 4803
5102		Ref to 5102
57104E	SU00300348	MEMBER SUB-ASSY, FRONT CROSS
SU00302792	SU00302792	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.4.0.2 Body - SUSPENSION CROSSMEMBER & UNDER COVER(5102) - 2




*1 REFER TO
FIG 48-04

512444

PNC	Original P/N	Description
4101		Ref to 4101
4804		Ref to 4804
51206A	SU00300349	MEMBER SUB-ASSY, REAR SUSPENSION
52273A	SU00300350	STOPPER, REAR SUSPENSION MEMBER, LOWER RH
52274A	SU00300351	STOPPER, REAR SUSPENSION MEMBER, LOWER LH
52277B	SU00300353	STOPPER, REAR SUSPENSION MEMBER, REAR UPPER
52278C	SU00300352	STOPPER, REAR SUSPENSION MEMBER, REAR LOWER
52285	SU00302807	BOLT, DIFFERENTIAL SUPPORT MEMBER MOUNTING, NO.1
SU00302824	SU00302824	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.40.3 Body - SUSPENSION CROSSMEMBER & UNDER COVER(5102) - 3




512436

PNC	Original P/N	Description
51441	SU00301383	COVER, ENGINE UNDER, NO.1
51441C	SU00301384	COVER, ENGINE UNDER, RH
51442C	SU00301385	COVER, ENGINE UNDER, LH
51442E	SU00301379	COVER, ENGINE UNDER, NO.2
51443C	SU00301386	COVER, ENGINE UNDER, REAR RH
51444A	SU00301387	COVER, ENGINE UNDER, REAR LH
58219C	SU00301382	PLATE, CENTER FLOOR REAR END
SU00300003	SU00300003	** Std part
SU00301536	SU00301536	** Std part
SU00302800	SU00302800	** Std part
SU00302927	SU00302927	** Std part
SU00302984	SU00302984	** Std part
SU00302989	SU00302989	** Std part
SU00303024	SU00303024	** Std part
SU00304132	SU00304132	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

2.40.4 Body - SUSPENSION CROSSMEMBER & UNDER COVER(5102) - 4




512437

PNC	Original P/N	Description
51443A	SU00301380	COVER, ENGINE UNDER, REAR
51444B	SU00301381	COVER, ENGINE UNDER, REAR LH
SU00302800	SU00302800	** Std part
SU00302989	SU00302989	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views

2.40.5 Body - SUSPENSION CROSSMEMBER & UNDER COVER(5102) - 5



512438


PNC	Original P/N	Description
52205H	SU00301224	CUSHION SUB-ASSY, BODY MOUNTING, REAR RH
52206C	SU00301225	CUSHION SUB-ASSY, BODY MOUNTING, REAR LH
SU00302801	SU00302801	** Std part
SU00302816	SU00302816	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3 Electrical

3.1 ABS & VSC(8414)

3.1.1 Electrical - ABS & VSC(8414) - 1




84D150

PNC	Original P/N	Description
88266B	SU00302979	CLAMP, SKID CONTROL SENSOR, NO.1
89542	SU00300662	SENSOR, SPEED, FRONT RH
89543	SU00300663	SENSOR, SPEED, FRONT LH
89545	SU00300664	SENSOR, SPEED, REAR RH
89546	SU00300665	SENSOR, SPEED, REAR LH
SU00300009	SU00300009	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.1.2 Electrical - ABS & VSC(8414) - 2



※1 ECU does include ①,②,③,④ parts

N03 この部品は、分解・組付け後の性能・品質確保が困難なため、単品では補給していません
N03 This part is not supplied as an individual part, because it is difficult to keep the function / quality of parts assembled / disassembled


84D340

PNC	Original P/N	Description
4708		Ref to 4708
8202		Ref to 8202
89541	SU00304292	COMPUTER, SKID CONTROL

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.2 AIR BAG(8421)

3.2.1 Electrical - AIR BAG(8421) - 1




84D152

PNC	Original P/N	Description
89170A	SU00303415	COMPUTER ASSY, AIR BAG
89173A	SU00303419	SENSOR, AIR BAG, FRONT RH
89174A	SU00303419	SENSOR, AIR BAG, FRONT LH
89833	SU00303420	SENSOR, AIR BAG, REAR RH
89834	SU00303420	SENSOR, AIR BAG, REAR LH
89860	SU00303421	SENSOR ASSY, SIDE AIR BAG, RH
89860A	SU00303421	SENSOR ASSY, SIDE AIR BAG, LH
89860B	SU00303422	SENSOR ASSY, SIDE AIR BAG, RH, NO.2
89860C	SU00303422	SENSOR ASSY, SIDE AIR BAG, LH, NO.2
89970	SU00303423	SENSOR ASSY, AIR BAG, NO.2
SU00300008	SU00300008	** Std part
SU00300011	SU00300011	** Std part
SU00300053	SU00300053	** Std part
SU00302827	SU00302827	** Std part
SU00302878	SU00302878	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.3 ANTENNA(8604)

3.3.1 Electrical - ANTENNA(8604) - 1




864959

PNC	Original P/N	Description
86101	SU00302659	CORD SUB-ASSY, ANTENNA
86101D	SU00302661	CORD SUB-ASSY, ANTENNA, NO.3
86101J	SU00302658	CORD SUB-ASSY, ANTENNA, NO.2
86300B	SU00302655	ANTENNA ASSY, AMPLIFIER
86309E	SU00302657	POLE SUB-ASSY, ROOF ANTENNA
86396	SU00302662	NUT, ANTENNA

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.4 BACK UP LAMP(8112)

3.4.1 Electrical - BACK UP LAMP(8112) - 1




816154

PNC	Original P/N	Description
81210E	SU00302567	BULB, REAR FOG LAMP
81670B	SU00302130	BULB(FOR BACK-UP LAMP)
81671A	SU00302528	LENS & BODY, BACK-UP LAMP
81675	SU00302575	SOCKET & WIRE, BACK-UP LAMP
SU00302800	SU00302800	** Std part
SU00302984	SU00302984	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.5 BATTERY & BATTERY CABLE(8201)

3.5.1 Electrical - BATTERY & BATTERY CABLE(8201) - 1




N04:この部品については補給していません
N04:This part is not available for service

828181

PNC	Original P/N	Description
28800	SU00304415	BATTERY
28800A	SU00302356	TERMINAL, BATTERY POSITIVE
28800D	SU00302359	COVER, CONNECTOR(FOR BATTERY TERMINAL)
28899	SU00302413	INSULATOR, BATTERY
7402		Ref to 7402
8202		Ref to 8202
SU00302358	SU00302358	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.5.2 Electrical - BATTERY & BATTERY CABLE(8201) - 2




828182

PNC	Original P/N	Description
28800J	SU00300510	TERMINAL, BATTERY NEGATIVE
8202		Ref to 8202

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views

3.6 CENTER STOP LAMP(8117)

3.6.1 Electrical - CENTER STOP LAMP(8117) - 1




816132

PNC	Original P/N	Description
6403		Ref to 6403
81570	SU00302523	LAMP ASSY, CENTER STOP

3.7 CRUISE CONTROL (AUTO DRIVE)(8408)

3.7.1 Electrical - CRUISE CONTROL (AUTO DRIVE)(8408) - 1

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views



84D149

PNC	Original P/N	Description
-----	--------------	-------------


GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

4504		Ref to 4504
84630	SU00302480	SWITCH ASSY, CRUISE CONTROL MAIN
SU00300856	SU00300856	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.8 DAYTIME RUNNING LAMP OR ILLUMINATION LAMP(8119)

3.8.1 Electrical - DAYTIME RUNNING LAMP OR ILLUMINATION LAMP(8119) - 1




816155

PNC	Original P/N	Description
8102		Ref to 8102
81430C	N/A	LAMP ASSY, DAYTIME RUNNING, RH
81431A	N/A	OUTER LENS, DAYTIME RUNNING LAMP, RH
81431B	N/A	BULB, DAYTIME RUNNING LAMP
81432	N/A	OUTER LENS, DAYTIME RUNNING LAMP, LH
81440B	N/A	LAMP ASSY, DAYTIME RUNNING, LH
SU00302893	SU00302893	** Std part
SU00302921	SU00302921	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.9 ELECTRONIC FUEL INJECTION SYSTEM(8404)

3.9.1 Electrical - ELECTRONIC FUEL INJECTION SYSTEM(8404) - 1




84D176

PNC	Original P/N	Description
89570A	SU00300426	COMPUTER ASSY, FUEL PUMP CONTROL
89661	SU00300442	COMPUTER, ENGINE CONTROL
89667	SU00300423	BRACKET, ENGINE CONTROL COMPUTER
SU00300522	SU00300522	** Std part
SU00302435	SU00302435	** Std part
SU00302438	SU00302438	** Std part
SU00302879	SU00302879	** Std part
SU00302886	SU00302886	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views


3.9.2 Electrical - ELECTRONIC FUEL INJECTION SYSTEM(8404) - 2



PNC	Original P/N	Description
1603		Ref to 1603
2211		Ref to 2211
3514		Ref to 3514
8716		Ref to 8716
89422	SU00300420	SENSOR, WATER TEMPERATURE (FOR E.F.I.)
SU00302157	SU00302157	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.9.3 Electrical - ELECTRONIC FUEL INJECTION SYSTEM(8404) - 3




84D285

PNC	Original P/N	Description
1104		Ref to 1104
1701		Ref to 1701
1708		Ref to 1708
8202		Ref to 8202
8401		Ref to 8401
89871	SU00300421	DRIVER, INJECTOR
89879	SU00300424	BRACKET, INJECTOR DRIVER
SU00300011	SU00300011	** Std part
SU00300023	SU00300023	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.9.4 Electrical - ELECTRONIC FUEL INJECTION SYSTEM(8404) - 4




84D286

PNC	Original P/N	Description
1701		Ref to 1701
2211		Ref to 2211
7701		Ref to 7701
89458	SU00300329	SENSOR, FUEL PRESSURE

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.10 ELECTRONIC HEIGHT CONTROL(8418)

3.10.1 Electrical - ELECTRONIC HEIGHT CONTROL(8418) - 1




84D151

PNC	Original P/N	Description
89408C	SU00302513	SENSOR SUB-ASSY, HEIGHT CONTROL, REAR LH
SU00300051	SU00300051	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.11 FOG LAMP(8102)

3.11.1 Electrical - FOG LAMP(8102) - 1




816123

PNC	Original P/N	Description
8119		Ref to 8119
81210A	SU00302518	LAMP ASSY, FOG, RH
81210B	SU00302565	BULB, FOG LAMP
81211C	SU00302545	LAMP UNIT, FOG LAMP, RH
81220	SU00302518	LAMP ASSY, FOG, LH
81221C	SU00302545	LAMP UNIT, FOG LAMP, LH
81431C	N/A	BULB, DAYTIME RUNNING LAMP
SU00302893	SU00302893	** Std part
SU00302921	SU00302921	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.12 FRONT TURN SIGNAL LAMP(8103)

3.12.1 Electrical - FRONT TURN SIGNAL LAMP(8103) - 1




816120

PNC	Original P/N	Description
8106		Ref to 8106
81510	SU00302534	LAMP ASSY, FRONT TURN SIGNAL, RH
81510B	SU00302568	BULB (FOR FRONT TURN SIGNAL LAMP)
81515E	SU00302577	SOCKET PLUG ASSY
81520	SU00302535	LAMP ASSY, FRONT TURN SIGNAL, LH
SU00302895	SU00302895	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.13 HEADLAMP CLEANER(8505)

3.13.1 Electrical - HEADLAMP CLEANER(8505) - 1




852850

PNC	Original P/N	Description
8503		Ref to 8503
85044	SU00302703	NOZZLE SUB-ASSY, TYPE1 H/LAMP WASHER, RH
85045	SU00302710	NOZZLE SUB-ASSY, TYPE1 H/LAMP WASHER, LH
85207A	SU00302701	ACTUATOR SUB-ASSY, HEADLAMP WASHER, RH
85208A	SU00302702	ACTUATOR SUB-ASSY, HEADLAMP WASHER, LH
85280A	SU00302689	MOTOR AND PUMP ASSY, HEADLAMP CLEANER
85283	SU00302718	BRACKET, HEADLAMP CLEANER WASHER
85330B	SU00302131	BUSH, HEADLAMP CLEANER WASHER JAR
85370A	SU00302726	HOSE ASSY, HEADLAMP CLEANER WASHER, NO.1
SU00301535	SU00301535	** Std part
SU00302984	SU00302984	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.14 HEADLAMP(8101)

3.14.1 Electrical - HEADLAMP(8101) - 1




816127A

PNC	Original P/N	Description
81110	SU00302509	HEADLAMP ASSY, RH
81110B	N/A	BULB(FOR HEADLAMP, NO.1)
81110D	N/A	BULB(FOR HEADLAMP, NO.2)
81125	N/A	CORD, HEADLAMP
81135	SU00302554	UNIT, HEADLAMP, RH
81144	N/A	COVER, HEADLAMP, NO.1
81144D	SU00302590	CAP, HEADLAMP LOCKING
81145	N/A	COVER, HEADLAMP, NO.2
81150	SU00302510	HEADLAMP ASSY, LH
81175	SU00302555	UNIT, HEADLAMP, LH
81610F	N/A	BULB(FOR CLEARANCE LAMP)
SU00301535	SU00301535	** Std part
SU00304227	SU00304227	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.14.2 Electrical - HEADLAMP(8101) - 2




816126B

PNC	Original P/N	Description
74533D	SU00303142	LABEL, HEADLAMP VOLTAGE CAUTION
81107	SU00302592	COMPUTER SUB-ASSY, HEADLAMP LIGHT CONTROL, RH
81108	SU00302592	COMPUTER SUB-ASSY, HEADLAMP LIGHT CONTROL, LH
81110	SU00302509	HEADLAMP ASSY, RH
81110L	SU00302560	BULB, DISCHARGE HEADLAMP
81135	SU00302554	UNIT, HEADLAMP, RH
81144D	SU00302590	CAP, HEADLAMP LOCKING
81150	SU00302510	HEADLAMP ASSY, LH
81175	SU00302555	UNIT, HEADLAMP, LH
81189	SU00302589	COVER, HEADLAMP
SU00300072	SU00300072	** Std part
SU00301535	SU00301535	** Std part
SU00304227	SU00304227	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views

3.15 HEATING & AIR CONDITIONING

3.15.1 Electrical - HEATING & AIR CONDITIONING - COMPRESSOR(8719) - 1




87C835A

PNC	Original P/N	Description
1601		Ref to 1601
88310E	SU00302114	COMPRESSOR, W/MAGNET CLUTCH
SU00304257	SU00304257	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.15.2 Electrical - HEATING & AIR CONDITIONING - CONTROL & AIR DUCT(8715) - 1




87C861A

PNC	Original P/N	Description
5501		Ref to 5501
55900	SU00302092	CONTROL ASSY, AIR CONDITIONER
55901D	SU00302096	CONTROL SUB-ASSY, HEATER, NO.1
55905A	SU00302097	KNOB, HEATER CONTROL
55905B	SU00302104	KNOB, HEATER CONTROL, NO.2
SU00302105	SU00302105	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views

3.15.3 Electrical - HEATING & AIR CONDITIONING - CONTROL & AIR DUCT(8715) - 2




87C862

PNC	Original P/N	Description
5501		Ref to 5501
55901	N/A	BASE SUB-ASSY, HEATER CONTROL
55902B	N/A	CONTROL SUB-ASSY, HEATER
55903A	N/A	CONTROL SUB-ASSY, HEATER, NO.3
55906	N/A	CABLE SUB-ASSY, HEATER CONTROL
55908A	N/A	CABLE SUB-ASSY, AIR INLET DAMPER CONTROL
55910B	N/A	BULB, HEATER CONTROL

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views

3.15.4 Electrical - HEATING & AIR CONDITIONING - CONTROL & AIR DUCT(8715) - 3




87C864

PNC	Original P/N	Description
5501		Ref to 5501
55843A	SU00301935	DUCT, HEATER TO REGISTER, NO.1
55844	SU00301936	DUCT, HEATER TO REGISTER, NO.2
55950G	SU00301939	NOZZLE ASSY, DEFROSTER
55971C	SU00301937	DUCT, SIDE DEFROSTER NOZZLE, NO.1
55972C	SU00301938	DUCT, SIDE DEFROSTER NOZZLE, NO.2
SU00302915	SU00302915	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.15.5 Electrical - HEATING & AIR CONDITIONING - CONTROL & AIR DUCT(8715) - 4

①	REFER TO FIG 87-14
②	REFER TO FIG 87-14




87C898

PNC	Original P/N	Description
8714		Ref to 8714
87201	SU00302038	DUCT SUB-ASSY, AIR, NO.1
87201B	SU00302037	DUCT SUB-ASSY, AIR, NO.2

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.15.6 Electrical - HEATING & AIR CONDITIONING - CONTROL & AIR DUCT(8715) - 5




87C899

PNC	Original P/N	Description
1603		Ref to 1603
5304		Ref to 5304
7403		Ref to 7403
8718		Ref to 8718
88625Q	SU003A0023	THERMISTOR, COOLER (ROOM TEMP. SENSOR)
88790B	SU003A0022	THERMISTOR ASSY
88897A	SU00302027	PIPE, ASPIRATOR
88897P	SU00302095	ASPIRATOR

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.15.7 Electrical - HEATING & AIR CONDITIONING - COOLER PIPING(8718) - 1




87C855

PNC	Original P/N	Description
1603		Ref to 1603
5304		Ref to 5304
7403		Ref to 7403
8715		Ref to 8715
88460	SU00302116	CONDENSER ASSY, COOLER
88463A	SU00302118	BRACKET, COOLER CONDENSER, NO.2
88463B	SU00302117	BRACKET, COOLER CONDENSER, NO.3
SU00300037	SU00300037	** Std part
SU00303033	SU00303033	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.15.8 Electrical - HEATING & AIR CONDITIONING - COOLER PIPING(8718) - 2




87C856

PNC	Original P/N	Description
8719		Ref to 8719
88704	SU003A0005	HOSE SUB-ASSY, SUCTION
88710	SU003A0009	TUBE ASSY, AIRCONDITIONER
88711	SU003A0002	HOSE, COOLER REFRIGERANT DISCHARGE, NO.1
SU00300010	SU00300010	** Std part
SU00300023	SU00300023	** Std part
SU00300038	SU00300038	** Std part
SU00302127	SU00302127	** Std part
SU00302874	SU00302874	** Std part
SU00303004	SU00303004	** Std part
SU00303005	SU00303005	** Std part
SU003A0001	SU003A0001	** Std part
SU003A0013	SU003A0013	** Std part
SU003A0024	SU003A0024	** Std part
SU003A0025	SU003A0025	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views

3.15.9 Electrical - HEATING & AIR CONDITIONING - COOLER UNIT(8714) - 1



87C870

PNC	Original P/N	Description
87010	SU00302001	UNIT ASSY, AIR CONDITIONER
8716		Ref to 8716
88899K	SU00302085	PLATE, COVER
SU00302879	SU00302879	** Std part
SU00302933	SU00302933	** Std part
SU00303014	SU00303014	** Std part


GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.15.11 Electrical - HEATING & AIR CONDITIONING - COOLER UNIT(8714) - 3

①	SU003-02113(X)
②	SU003-A0024
③	SU003-A0025

REFER TO
ILLUST NO.
2 OF 4




87C872A

PNC	Original P/N	Description
87107A	SU00302040	UNIT SUB-ASSY, HEATER RADIATOR
87114B	SU00302033	COVER, HEATER
87154A	SU00302058	SHAFT, DAMPER, NO.1
87154B	SU00302060	SHAFT, DAMPER, NO.2
87205C	SU00302062	GUIDE SUB-ASSY, AIR DUCT
87287A	SU00302063	DAMPER, HEATER AIR
88326A	SU00302032	PLATE, COVER
88501	SU00302121	EVAPORATOR SUB-ASSY, COOLER, NO.1
88515	SU003A0014	VALVE, COOLER EXPANSION
88521C	SU00302011	CASE, COOLING UNIT
88578V	SU00304124	PACKING, COOLING UNIT, NO.3
88625	SU003A0017	THERMISTOR, COOLER, NO.1
88666	SU00302061	SPACER (FOR COOLER UNIT)
88790E	SU003A0020	TUBE & ACCESSORY ASSY, AIRCONDITIONER
88899N	N/A	PLATE, COVER
SU00302031	SU00302031	** Std part
SU00302053	SU00302053	** Std part
SU00302064	SU00302064	** Std part
SU00302065	SU00302065	** Std part
SU00302113	SU00302113	** Std part
SU00302852	SU00302852	** Std part
SU00304476	SU00304476	** Std part
SU003A0024	SU003A0024	** Std part
SU003A0025	SU003A0025	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.15.12 Electrical - HEATING & AIR CONDITIONING - COOLER UNIT(8714) - 4




87C873

PNC	Original P/N	Description
87103B	SU00302079	MOTOR SUB-ASSY, BLOWER W/FAN
87130K	SU00304470	DAMPER SERVO SUB-ASSY, BLOWER, NO.1
87139C	SU00302112	FILTER, CLEAN AIR
88502A	SU00302070	CASE SUB-ASSY, COOLING UNIT
88502R	SU00302071	CASE SUB-ASSY, COOLING UNIT
88544	SU00302069	CASE, COOLER BLOWER
88548B	SU00302084	CASE, AIR FILTER
88578W	SU00302077	PACKING, COOLING UNIT, NO.4
88891	SU00302076	PACKING (FOR COOLER)
88899P	SU00302080	PLATE, COVER
SU00301990	SU00301990	** Std part
SU00301992	SU00301992	** Std part
SU00302074	SU00302074	** Std part
SU00302075	SU00302075	** Std part
SU00302083	SU00302083	** Std part
SU00302113	SU00302113	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.15.13 Electrical - HEATING & AIR CONDITIONING - WATER PIPING(8716) - 1




87C858

PNC	Original P/N	Description
1603		Ref to 1603
8714		Ref to 8714
87245A	SU00302106	HOSE, HEATER WATER, INLET A
87246A	SU00302107	HOSE, HEATER WATER, OUTLET A
87246B	SU00302108	HOSE, HEATER WATER, OUTLET B
87251D	SU00302110	JOINT, WATER, NO.1
SU00300078	SU00300078	** Std part
SU00301991	SU00301991	** Std part
SU00302109	SU00302109	** Std part
SU00302995	SU00302995	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.16 HORN(8611)

3.16.1 Electrical - HORN(8611) - 1




864939

PNC	Original P/N	Description
8401		Ref to 8401
8503		Ref to 8503
86508	SU00302629	BRACKET SUB-ASSY, HORN
86510	SU00302625	HORN ASSY, HIGH PITCHED
86520	SU00302626	HORN ASSY, LOW PITCHED
SU00302788	SU00302788	** Std part
SU00302888	SU00302888	** Std part
SU00302928	SU00302928	** Std part
SU00302929	SU00302929	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.17 INTERIOR LAMP(8121)

3.17.1 Electrical - INTERIOR LAMP(8121) - 1




816139

PNC	Original P/N	Description
81260A	SU00302522	LAMP ASSY, MAP
81260C	SU00302569	BULB(FOR MAP LAMP)
81265C	SU00302526	LENS, MAP LAMP, NO.1
81330	SU00302521	LAMP ASSY, LUGGAGE COMPARTMENT, NO.1
81330B	SU00301984	BULB, LUGGAGE COMPARTMENT LAMP
81331	SU00302527	LENS, LUGGAGE COMPARTMENT LAMP

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.17.2 Electrical - INTERIOR LAMP(8121) - 2




816141

PNC	Original P/N	Description
7401		Ref to 7401
81340B	SU00302566	BULB (FOR VANITY LAMP)
81341	SU00303185	LENS, VANITY LAMP

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.17.3 Electrical - INTERIOR LAMP(8121) - 3




816161

PNC	Original P/N	Description
6701		Ref to 6701
6703		Ref to 6703
7401		Ref to 7401
8115		Ref to 8115
81230	SU00303290	LAMP ASSY, COURTESY
81230B	SU00303297	BULB(FOR COURTESY LAMP)
8401		Ref to 8401

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.18 METER(8301)

3.18.1 Electrical - METER(8301) - 1




831644

PNC	Original P/N	Description
83100	SU00302604	METER ASSY, COMBINATION
83136A	SU00302618	COVER, COMBINATION METER
83138G	SU00302619	GLASS, COMBINATION METER
SU00302915	SU00302915	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.19 MIRROR(8701)

3.19.1 Electrical - MIRROR(8701) - 1




※1 SU003-03182が構成に含まれます
 ※1 SU003-03182 is included as a component

87C832

PNC	Original P/N	Description
87810	SU00303183	MIRROR ASSY, INNER REAR VIEW
87853	SU00303181	BASE, INNER REAR VIEW MIRROR
SU00303182	SU00303182	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.19.2 Electrical - MIRROR(8701) - 2




87C833

PNC	Original P/N	Description
87901B	SU00303050	MIRROR SUB-ASSY, OUTER REAR VIEW, RH
87906B	SU00303051	MIRROR SUB-ASSY, OUTER REAR VIEW, LH
87915	SU00303070	COVER, OUTER MIRROR, RH
87915A	SU00303090	COVER, OUTER MIRROR, RH
87931	SU00303056	OUTER MIRROR, RH
87945	SU00303078	COVER, OUTER MIRROR, LH
87945B	SU00303091	COVER, OUTER MIRROR, LH
87961	SU00303057	MIRROR OUTER, LH
SU00300071	SU00300071	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.20 RADIO RECEIVER & AMPLIFIER & CONDENSER(8601)

3.20.1 Electrical - RADIO RECEIVER & AMPLIFIER & CONDENSER(8601) - 1




864985

PNC	Original P/N	Description
5501		Ref to 5501
8301		Ref to 8301
8401		Ref to 8401
86211	SU00301960	BRACKET, RADIO, NO.1
86212	SU00301961	BRACKET, RADIO, NO.2
SU00300008	SU00300008	** Std part
SU00301536	SU00301536	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.20.2 Electrical - RADIO RECEIVER & AMPLIFIER & CONDENSER(8601) - 2




864950

PNC	Original P/N	Description
5501		Ref to 5501
8401		Ref to 8401
86190C	SU00302640	ADAPTER ASSY, STEREO JACK, NO.1
86203D	SU00302641	WIRE, STEREO COMPONENT, NO.1
86453A	SU00302660	WIRE, MULTI-MEDIA MODULE
SU00302914	SU00302914	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.20.3 Electrical - RADIO RECEIVER & AMPLIFIER & CONDENSER(8601) - 3




864952

PNC	Original P/N	Description
86120	SU00302635	RECEIVER ASSY, RADIO

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.20.4 Electrical - RADIO RECEIVER & AMPLIFIER & CONDENSER(8601) - 4




864953

PNC	Original P/N	Description
86011C	SU00302632	FILTER, NOISE

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.21 REAR COMBINATION LAMP(8111)

3.21.1 Electrical - REAR COMBINATION LAMP(8111) - 1




816130

PNC	Original P/N	Description
81550L	SU00302568	BULB, REAR TURN SIGNAL LAMP
81551D	SU00302530	LENS & BODY, REAR COMBINATION LAMP, RH
81552A	SU00302586	GASKET, REAR COMBINATION LAMP, RH
81555	SU00302573	SOCKET & WIRE SUB-ASSY, REAR COMBINATION LAMP, RH
81561D	SU00302531	LENS & BODY, REAR COMBINATION LAMP, LH
81562A	SU00304315	GASKET, REAR COMBINATION LAMP, LH
81565	SU00302573	SOCKET & WIRE SUB-ASSY, REAR COMBINATION LAMP, LH
SU00302875	SU00302875	** Std part
SU00303013	SU00303013	** Std part

3.22 REAR LICENSE PLATE LAMP(8113)

3.22.1 Electrical - REAR LICENSE PLATE LAMP(8113) - 1




816124

PNC	Original P/N	Description
81270B	SU00302129	BULB (FOR LICENSE PLATE LAMP)
81271	SU00302542	LENS, LICENSE PLATE LAMP
81275	SU00302585	SOCKET AND WIRE, LICENSE PLATE LAMP

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.23 REFLEX REFLECTOR(8115)

3.23.1 Electrical - REFLEX REFLECTOR(8115) - 1




816159

PNC	Original P/N	Description
6701		Ref to 6701
6703		Ref to 6703
7401		Ref to 7401
8121		Ref to 8121
81730D	N/A	REFLECTOR, REFLEX, FRONT SIDE
8401		Ref to 8401

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.24 SIDE TURN SIGNAL LAMP & OUTER MIRROR LAMP(8106)

3.24.1 Electrical - SIDE TURN SIGNAL LAMP & OUTER MIRROR LAMP(8106) - 1




816157

PNC	Original P/N	Description
8103		Ref to 8103
81730	SU00302538	LAMP ASSY, SIDE TURN SIGNAL, RH
81730B	SU00302562	BULB (FOR SIDE TURN SIGNAL LAMP)
81735	SU00302580	SOCKET AND WIRE, SIDE TURN SIGNAL LAMP
81740	SU00302539	LAMP ASSY, SIDE TURN SIGNAL, LH

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.25 SPEAKER(8602)

3.25.1 Electrical - SPEAKER(8602) - 1




864979

PNC	Original P/N	Description
6701		Ref to 6701
86160	SU00302642	SPEAKER ASSY, FRONT NO.1
86160B	SU00302643	SPEAKER ASSY, REAR
86160P	SU00302645	SPEAKER ASSY, FRONT NO.2
SU00300066	SU00300066	** Std part
SU00300067	SU00300067	** Std part
SU00303022	SU00303022	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.26 SWITCH & RELAY(8401)

3.26.1 Electrical - SWITCH & RELAY(8401) - 1




84D305

PNC	Original P/N	Description
1701		Ref to 1701
83530	SU00300523	SWITCH ASSY, OIL PRESSURE (FOR ENGINE)
89420M	SU00300419	SENSOR ASSY, AIR PRESSURE
89429F	SU00300420	SENSOR, TEMPERATURE
89465	SU00300428	SENSOR, OXYGEN
89467A	SU00300425	SENSOR, WIDE RANGE AIR FUEL RATIO
89615	SU00300415	SENSOR, KNOCK CONTROL
SU00300297	SU00300297	** Std part
SU00300298	SU00300298	** Std part
SU00302157	SU00302157	** Std part
SU00302200	SU00302200	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views

3.26.2 Electrical - SWITCH & RELAY(8401) - 10




84D201A

PNC	Original P/N	Description
4504		Ref to 4504
84140	SU00302470	SWITCH ASSY, HEADLAMP DIMMER
84306	SU00304267	CABLE SUB-ASSY, SPIRAL
84650	SU00302462	SWITCH ASSY, WINDSHIELD WIPER
89245B	SU00300670	SENSOR, STEERING
SU00302474	SU00302474	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.2.6.3 Electrical - SWITCH & RELAY(8401) - 11





84D203A

PNC	Original P/N	Description
5806		Ref to 5806
7401		Ref to 7401
84233	SU00302494	SWITCH ASSY, COURTESY LAMP (FOR FRONT DOOR)
84720J	SU00302484	SWITCH ASSY, PATTERN SELECT
84751	SU00304127	SWITCH, SEAT HEATER
84751F	SU00304128	SWITCH, SEAT HEATER
84810	SU00302456	SWITCH ASSY, POWER WINDOW REGULATOR
84820	SU00302454	MASTER SWITCH ASSY, POWER WINDOW REGULATOR
84870A	SU00302451	SWITCH ASSY, OUTER MIRROR
85530D	SU00302728	SOCKET ASSY, POWER OUTLET, NO.2
85535E	SU00302731	COVER, POWER OUTLET SOCKET, NO.2
SU00302808	SU00302808	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.26.4 Electrical - SWITCH & RELAY(8401) - 12



84D328


PNC	Original P/N	Description
7701		Ref to 7701
83320	SU00301106	GAGE ASSY, FUEL SENDER
83320B	SU00301105	GAGE ASSY, FUEL SENDER, NO.2
84840G	SU00302777	SWITCH ASSY, BACK DOOR OPENER

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

PNC	Original P/N	Description
3302		Ref to 3302
3312		Ref to 3312
3503		Ref to 3503
3513		Ref to 3513
8410		Ref to 8410
84210	SU00300821	SWITCH ASSY, BACK-UP LAMP
84540	SU00300822	SWITCH ASSY, NEUTRAL START
SU00302158	SU00302158	** Std part
SU00303476	SU00303476	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.26.6 Electrical - SWITCH & RELAY(8401) - 3




84D196

PNC	Original P/N	Description
8202		Ref to 8202
82210P	SU00302428	ENGINE ROOM FUSIBLE LINK
82600E	SU00302423	ENGINE ROOM FUSE
82616	SU00304209	PULLER, FUSE
82662A	SU00302433	COVER, RELAY BLOCK, UPPER, NO.1
SU00302434	SU00302434	** Std part
SU00302436	SU00302436	** Std part
SU00302438	SU00302438	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.26.7 Electrical - SWITCH & RELAY(8401) - 4




84D197

PNC	Original P/N	Description
8714		Ref to 8714
SU00302434	SU00302434	** Std part
SU00302435	SU00302435	** Std part
SU00302437	SU00302437	** Std part
SU00302439	SU00302439	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.26.8 Electrical - SWITCH & RELAY(8401) - 5




84D205A

PNC	Original P/N	Description
8503		Ref to 8503
85942	SU00302732	RELAY, HEADLAMP CLEANER CONTROL
89530C	N/A	COMPUTER ASSY, TRANSMISSION CONTROL
89539E	N/A	BRACKET, COMPUTER
89650	SU00300873	COMPUTER ASSY, POWER STEERING
89658	SU00300875	BRACKET, POWER STEERING COMPUTER
SU00300009	SU00300009	** Std part
SU00300051	SU00300051	** Std part
SU00304417	SU00304417	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.2.6.9 Electrical - SWITCH & RELAY(8401) - 6




84D207A

PNC	Original P/N	Description
4601		Ref to 4601
81980	SU00302630	FLASHER ASSY, TURN SIGNAL
82600D	SU00302422	INSTRUMENT PANEL FUSE
82730	SU00302421	BLOCK ASSY, INSTRUMENT PANEL JUNCTION
84550	SU00302493	SWITCH ASSY, PARKING BRAKE
85900	N/A	RELAY ASSY, CONTROL UNIT
89111	SU00304026	COMPUTER, NETWORK GATEWAY
89120A	SU00302516	SENSOR, AUTOMATIC LIGHT CONTROL
89960	SU00302514	COMPUTER ASSY, HEADLAMP LEVELING
SU00300009	SU00300009	** Std part
SU00300059	SU00300059	** Std part
SU00300070	SU00300070	** Std part
SU00302874	SU00302874	** Std part
SU00302879	SU00302879	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.26.10 Electrical - SWITCH & RELAY(8401) - 7




84D199

PNC	Original P/N	Description
5501		Ref to 5501
69065A	SU00302443	CYLINDER SUB-ASSY, AIR BAG CUT OFF SWITCH
82620C	SU00302730	CLIP
83910G	SU00302621	CLOCK ASSY
84119	SU00302445	RHEOSTAT, LIGHT CONTROL
84152	N/A	SWITCH, HEADLAMP LEVELING
84840D	SU00302446	SWITCH ASSY, LUGGAGE DOOR OPENING
84975	SU00302441	SWITCH, TRIP
85530	SU00302729	SOCKET ASSY, POWER OUTLET, NO.1
89611	SU00302448	SWITCH, PUSH START

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.26.11 Electrical - SWITCH & RELAY(8401) - 8




84D335

PNC	Original P/N	Description
4701		Ref to 4701
84340	SU00302490	SWITCH ASSY, STOP LAMP
84345	SU00302491	ADJUSTER, STOP LAMP SWITCH MOUNTING
84520	SU00302489	SWITCH ASSY, CLUTCH START
88280A	SU00302488	SWITCH ASSY, CLUTCH
SU00300045	SU00300045	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.27 WINDSHIELD WASHER(8503)

3.27.1 Electrical - WINDSHIELD WASHER(8503) - 1



852852

PNC	Original P/N	Description
8401		Ref to 8401
85035	SU00302700	NOZZLE SUB-ASSY, WASHER
8505		Ref to 8505
85301	SU00302693	INLET SUB-ASSY, WASHER
85310	SU00302688	MOTOR AND PUMP ASSY, WINDSHIELD WASHER
85330	SU00302698	JAR ASSY, WINDSHIELD WASHER
85330A	SU00302695	BUSH, WINDSHIELD WASHER JAR
85332	SU00302690	CAP, WINDSHIELD WASHER JAR
85336D	SU00302696	PACKING, WINDSHIELD WASHER JAR
85336G	SU00302692	GAGE, WATER LEVEL
85348	SU00302717	JOINT, WINDSHIELD WASHER HOSE, NO.1
85355	SU00302699	VALVE, WINDSHIELD WASHER HOSE
85361	SU00302727	HOLDER, WINDSHIELD WASHER
85372	SU00302725	HOSE, WINDSHIELD WASHER (FROM JOINT TO JOINT), NO.1
85372B	SU00302722	HOSE, WINDSHIELD WASHER (FROM JOINT TO JOINT), NO.2
85372H	SU00302724	HOSE, WINDSHIELD WASHER (FROM JOINT TO JOINT), NO.3
85372J	SU00302723	HOSE, WINDSHIELD WASHER (FROM JOINT TO JOINT), NO.4
85387	SU00303006	CLAMP NO.1 (FOR WINDSEIELD WASHER)
85387A	SU00302691	CLAMP, WASHER, NO.2
SU00300004	SU00300004	** Std part
SU00300051	SU00300051	** Std part


GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

SU00301553	SU00301553	** Std part
SU00302831	SU00302831	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.28 WINDSHIELD WIPER(8501)

3.28.1 Electrical - WINDSHIELD WIPER(8501) - 1




852849

PNC	Original P/N	Description
85010	SU00302664	MOTOR & LINK ASSY, FR WIPER
85159	SU00302686	CUSHION, WINDSHIELD WIPER MOTOR
85178	SU00300045	NUT (FOR FRONT WIPER ARM SETTING)
85192	SU00302675	COVER, WINDSHIELD WIPER ARM
85211B	SU00302672	ARM, FR WIPER, RH
85212A	SU00302681	BLADE, FR WIPER, RH
85213A	SU00304214	RUBBER, WIPER BLADE, RH
85214A	SU00304216	RUBBER, WIPER, RH
85214B	SU00304215	RUBBER, WIPER, LH
85221B	SU00302668	ARM, FR WIPER, LH
85222A	SU00302677	BLADE, FR WIPER, LH
85223A	SU00304213	RUBBER, FRONT WIPER BLADE, LH
SU00302665	SU00302665	** Std part
SU00302666	SU00302666	** Std part
SU00302674	SU00302674	** Std part
SU00302684	SU00302684	** Std part
SU00302685	SU00302685	** Std part
SU00302860	SU00302860	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.29.2 Electrical - WIRELESS DOOR LOCK(8420) - 2




84D172

PNC	Original P/N	Description
8401		Ref to 8401
89741	SU00302765	RECEIVER, DOOR CONTROL
89990A	SU00302763	COMPUTER ASSY, SMART KEY
89992	SU00302775	OSCILLATOR, INDOOR ELECTRICAL KEY
89992C	SU00302776	OSCILLATOR, INDOOR ELECTRICAL KEY, NO.2
89992D	SU00302776	OSCILLATOR, INDOOR ELECTRICAL KEY, NO.3
89997	SU00302774	ANTENNA, ELECTRICAL KEY
SU00300070	SU00300070	** Std part
SU00302926	SU00302926	** Std part
SU00302928	SU00302928	** Std part
SU00303023	SU00303023	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.30 WIRING & CLAMP(8202)

3.30.1 Electrical - WIRING & CLAMP(8202) - 1




828220B

PNC	Original P/N	Description
1903		Ref to 1903
82111	SU00302296	WIRE, ENGINE ROOM MAIN
8401		Ref to 8401
SU00300005	SU00300005	** Std part
SU00300008	SU00300008	** Std part
SU00300039	SU00300039	** Std part
SU00300042	SU00300042	** Std part
SU00300068	SU00300068	** Std part
SU00302203	SU00302203	** Std part
SU00302204	SU00302204	** Std part
SU00302205	SU00302205	** Std part
SU00302837	SU00302837	** Std part
SU00302874	SU00302874	** Std part
SU00302905	SU00302905	** Std part
SU00302928	SU00302928	** Std part
SU00303017	SU00303017	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views

3.30.2 Electrical - WIRING & CLAMP(8202) - 10




828213

PNC	Original P/N	Description
82151	SU00302389	WIRE, FRONT DOOR, RH
82152	SU00302372	WIRE, FRONT DOOR, LH

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.30.3 Electrical - WIRING & CLAMP(8202) - 11




828214

PNC	Original P/N	Description
82171	SU00302363	WIRE, ROOF, NO.1

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.30.4 Electrical - WIRING & CLAMP(8202) - 12




828224

PNC	Original P/N	Description
82161	SU00302337	WIRE, FLOOR
82162	SU00302346	WIRE, FLOOR, NO.2
SU00302407	SU00302407	** Std part
SU00302928	SU00302928	** Std part
SU00303018	SU00303018	** Std part
SU00303029	SU00303029	** Std part
SU00303038	SU00303038	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.30.5 Electrical - WIRING & CLAMP(8202) - 13




828216

PNC	Original P/N	Description
82181	SU00302366	WIRE, LUGGAGE ROOM, NO.1

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views

3.30.6 Electrical - WIRING & CLAMP(8202) - 14




828225

PNC	Original P/N	Description
8401		Ref to 8401

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views

3.30.7 Electrical - WIRING & CLAMP(8202) - 15




828218

PNC	Original P/N	Description
5305		Ref to 5305
82001	SU00302405	CABLE, BOND, NO.1
82001C	SU00302404	CABLE, BOND, NO.2
SU00302794	SU00302794	** Std part
SU00302928	SU00302928	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views

3.30.8 Electrical - WIRING & CLAMP(8202) - 2




828222

PNC	Original P/N	Description
SU00302928	SU00302928	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views

3.30.9 Electrical - WIRING & CLAMP(8202) - 3




828207

PNC	Original P/N	Description
8401		Ref to 8401

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views

3.30.10 Electrical - WIRING & CLAMP(8202) - 4




828208

PNC	Original P/N	Description
82121	SU00300516	WIRE, ENGINE
SU00300025	SU00300025	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.30.11 Electrical - WIRING & CLAMP(8202) - 5




828240

PNC	Original P/N	Description
1104		Ref to 1104
1701		Ref to 1701
1708		Ref to 1708
82219A	SU00300518	WIRE, SENSOR
8401		Ref to 8401
8404		Ref to 8404

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.30.12 Electrical - WIRING & CLAMP(8202) - 6




828241

PNC	Original P/N	Description
1104		Ref to 1104
1105		Ref to 1105
1901		Ref to 1901
8401		Ref to 8401
SU00300020	SU00300020	** Std part
SU00300030	SU00300030	** Std part
SU00300081	SU00300081	** Std part
SU00300429	SU00300429	** Std part
SU00300430	SU00300430	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.30.13 Electrical - WIRING & CLAMP(8202) - 7




N04:この部品については補給していません
N04:This part is not available for service

828229

PNC	Original P/N	Description
7402		Ref to 7402
8201		Ref to 8201
82122	SU00302351	WIRE, ENGINE, NO.2
SU00302835	SU00302835	** Std part
SU00302836	SU00302836	** Std part
SU00302863	SU00302863	** Std part
SU00302905	SU00302905	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

3.30.14 Electrical - WIRING & CLAMP(8202) - 8




828242

PNC	Original P/N	Description
3312		Ref to 3312
3514		Ref to 3514
82125	N/A	WIRE, TRANSMISSION

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views

3.30.15 Electrical - WIRING & CLAMP(8202) - 9



828223


PNC	Original P/N	Description
82141	SU00302226	WIRE, INSTRUMENT PANEL
SU00300068	SU00300068	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

4 Power train, Chassis

4.1 BRAKE BOOSTER & VACUUM TUBE(4703)

4.1.1 Power train, Chassis - BRAKE BOOSTER & VACUUM TUBE(4703) - 1




478261A

PNC	Original P/N	Description
1701		Ref to 1701
1905		Ref to 1905
44610	SU00300590	BOOSTER ASSY, BRAKE
44763	SU00300562	TUBE, BOOSTER VACUUM
44771	SU00300567	HOSE, VACUUM TUBE CONNECTOR
44773	SU00300569	HOSE, VACUUM, NO.2
4702		Ref to 4702
47288C	SU00300563	LABEL, FLUID MARK
SU00300025	SU00300025	** Std part
SU00300080	SU00300080	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

4.1.2 Power train, Chassis - BRAKE BOOSTER & VACUUM TUBE(4703) - 2




PNC	Original P/N	Description
3102		Ref to 3102
4701		Ref to 4701
8401		Ref to 8401
SU00300053	SU00300053	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

4.2 BRAKE MASTER CYLINDER(4702)

4.2.1 Power train,Chassis - BRAKE MASTER CYLINDER(4702) - 1




478323A

PNC	Original P/N	Description
1701		Ref to 1701
1905		Ref to 1905
4703		Ref to 4703
47201	SU00304242	CYLINDER SUB-ASSY, BRAKE MASTER
47201B	SU00300593	RING, O(FOR BRAKE MASTER CYLINDER)
47215	SU00304246	INDICATOR, BRAKE FLUID
47220D	SU00304288	RESERVOIR ASSY, BRAKE MASTER CYLINDER
47230	SU00304244	CAP ASSY, BRAKE MASTER CYLINDER RESERVOIR FILLER
47255	SU00304245	GROMMET, MASTER CYLINDER RESERVOIR
47287	SU00300565	LABEL, BRAKE FLUID INFORMATION
47299	SU00304243	STRAINER, BRAKE MASTER CYLINDER RESERVOIR
SU00300591	SU00300591	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

4.3 BRAKE PEDAL & BRACKET(4701)

4.3.1 Power train,Chassis - BRAKE PEDAL & BRACKET(4701) - 1




PNC	Original P/N	Description
3102		Ref to 3102
4703		Ref to 4703
47101A	SU00300978	SPRING(FOR BRAKE PEDAL RETURN)
47101B	SU00300967	BUSH(FOR BRAKE PEDAL)
47110	SU00300945	SUPPORT ASSY, BRAKE PEDAL
47121	SU00300971	PAD, BRAKE PEDAL
47131	SU00300984	CUSHION(FOR STOP LAMP SWITCH)
47264A	SU00302938	PIN(FOR PUSH ROD)
8401		Ref to 8401
SU00300005	SU00300005	** Std part
SU00300075	SU00300075	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

4.4 BRAKE TUBE & CLAMP(4708)

4.4.1 Power train,Chassis - BRAKE TUBE & CLAMP(4708) - 1




478348

PNC	Original P/N	Description
4702		Ref to 4702
47310	SU00300595	TUBE ASSY, BRAKE, NO.1
47311	SU00300596	TUBE, FRONT BRAKE, NO.1
47311B	SU00300598	WAY, NO.1(FOR FRONT BRAKE TUBE)
47312	SU00300597	TUBE, FRONT BRAKE, NO.2
47313A	SU00300616	HOSE, FLEXIBLE, NO.1(FOR FRONT)
47313B	SU00300600	BOLT, UNION(FOR FRONT FLEXIBLE HOSE)
47313J	SU00300617	HOSE, FLEXIBLE, NO.2(FOR FRONT)
47313P	SU00300127	GASKET(FOR FRONT FLEXIBLE HOSE)
47351	SU00304289	BRACKET, FLEXIBLE HOSE(FOR FRONT RH)
47352	SU00304290	BRACKET, FLEXIBLE HOSE(FOR FRONT LH)
47371	SU00300601	BRACKET, CONNECTOR
47371A	SU00300605	CLAMP, BRAKE TUBE, NO.1
47371C	SU00300599	CLAMP, BRAKE TUBE, NO.7
47371E	SU00300608	CLAMP, BRAKE TUBE, NO.9
47371F	SU00300607	CLAMP, BRAKE TUBE, NO.10
47372	SU00300611	CLAMP, BRAKE TUBE, NO.2
47373B	SU00300609	CLAMP, BRAKE TUBE, NO.3
SU00300013	SU00300013	** Std part
SU00300015	SU00300015	** Std part
SU00300016	SU00300016	** Std part
SU00300524	SU00300524	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

4.4.2 Power train, Chassis - BRAKE TUBE & CLAMP(4708) - 2




478349

PNC	Original P/N	Description
2211		Ref to 2211
47371H	SU00300608	CLAMP, BRAKE TUBE, NO.12
47371M	SU00300607	CLAMP, BRAKE TUBE, NO.13
7701		Ref to 7701

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views

4.4.3 Power train, Chassis - BRAKE TUBE & CLAMP(4708) - 3




478345

PNC	Original P/N	Description
47318D	SU00300600	BOLT, UNION(FOR REAR FLEXIBLE HOSE)
47318E	SU00300127	GASKET(FOR REAR FLEXIBLE HOSE)
47318F	SU00300618	HOSE, FLEXIBLE(FOR REAR RH)
47319F	SU00300619	HOSE, FLEXIBLE(FOR REAR LH)
SU00300015	SU00300015	** Std part
SU00301628	SU00301628	** Std part
SU00303033	SU00303033	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

4.4.4 Power train, Chassis - BRAKE TUBE & CLAMP(4708) - 4



※1 ECU does include ①,②,③,④ parts

N03 この部品は、分解・組付け後の性能・品質確保が困難なため、単品では補給していません
N03 This part is not supplied as an individual part, because it is difficult to keep the function / quality of parts assembled / disassembled


478346

PNC	Original P/N	Description
44510	SU00304297	ACTUATOR ASSY, BRAKE
44590	SU00300661	BRACKET ASSY, BRAKE ACTUATOR
44599A	SU00300659	DAMPER, BRAKE ACTUATOR
8202		Ref to 8202
8414		Ref to 8414
SU00300015	SU00300015	** Std part
SU00300666	SU00300666	** Std part
SU00300667	SU00300667	** Std part
SU00300668	SU00300668	** Std part
SU00300669	SU00300669	** Std part
SU00300671	SU00300671	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

4.5 CLUTCH & RELEASE FORK(3101)

4.5.1 Power train,Chassis - CLUTCH & RELEASE FORK(3101) - 1




312602

PNC	Original P/N	Description
1301		Ref to 1301
31210	SU00300800	COVER ASSY, CLUTCH
31250	SU00300799	DISC ASSY, CLUTCH
SU00302137	SU00302137	** Std part

4.6 CLUTCH HOUSING & TRANSMISSION CASE (MTM)(3302)

4.6.1 Power train,Chassis - CLUTCH HOUSING & TRANSMISSION CASE (MTM)(3302) - 1

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views




334508

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

PNC	Original P/N	Description
31111	SU00303854	HOUSING, CLUTCH
31111E	SU00302144	BOLT(FOR TRANSAXLE & ENGINE SETTING)
31121	SU00300818	COVER, CLUTCH HOUSING, NO.1
33124C	SU00303860	PIPE, OIL RECEIVER, NO.1(MTM)
33131	SU00303853	RETAINER, BEARING, FRONT(MTM)
33131A	SU00303631	SEAL, OIL(FOR TRANSMISSION FRONT BEARING RETAINER)
SU00303483	SU00303483	** Std part
SU00303635	SU00303635	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

4.6.2 Power train, Chassis - CLUTCH HOUSING & TRANSMISSION CASE (MTM)(3302) - 2




334535

PNC	Original P/N	Description
1105		Ref to 1105
1701		Ref to 1701
1904		Ref to 1904
3503		Ref to 3503
SU00302153	SU00302153	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views


4.6.3 Power train, Chassis - CLUTCH HOUSING & TRANSMISSION CASE (MTM)(3302) - 3



PNC	Original P/N	Description
1105		Ref to 1105
1501		Ref to 1501
3503		Ref to 3503
SU00302151	SU00302151	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

4.6.4 Power train, Chassis - CLUTCH HOUSING & TRANSMISSION CASE (MTM)(3302) - 4




334509

PNC	Original P/N	Description
3307		Ref to 3307
33101A	SU00303617	PLUG(FOR MANUAL TRANSMISSION FILLER)
33101C	SU00303626	GASKET(FOR MANUAL TRANSMISSION FILLER PLUG)
33104	SU00303618	PLUG SUB-ASSY, DRAIN(MTM)
33104A	SU00303626	GASKET, DRAIN PLUG(MTM)
33111	SU00303851	CASE, MANUAL TRANSMISSION
33111J	SU00303635	PIN, STRAIGHT(FOR MANUAL TRANSMISSION CASE)
33151	SU00303852	RETAINER, OUTPUT SHAFT REAR BEARING(MTM)
SU00303484	SU00303484	** Std part
SU00303528	SU00303528	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

4.6.5 Power train, Chassis - CLUTCH HOUSING & TRANSMISSION CASE (MTM)(3302) - 5




334507

PNC	Original P/N	Description
8401		Ref to 8401
SU00303489	SU00303489	** Std part
SU00303921	SU00303921	** Std part
SU00303922	SU00303922	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

4.7 CLUTCH MASTER CYLINDER(3103)

4.7.1 Power train,Chassis - CLUTCH MASTER CYLINDER(3103) - 1




312605

PNC	Original P/N	Description
3102		Ref to 3102
31410	SU00300991	CYLINDER ASSY, CLUTCH MASTER
31415	SU00300994	GASKET, CLUTCH MASTER CYLINDER
31415B	SU00300992	PISTON ASSY
31415C	SU00300126	STOP RING
31417	SU00300592	GROMMET, CLUTCH RESERVOIR
31440P	SU00300993	CAP ASSY, CLUTCH MASTER CYLINDER RESERVOIR FILLER

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

4.8 CLUTCH PEDAL & FLEXIBLE HOSE(3102)


4.8.1 Power train,Chassis - CLUTCH PEDAL & FLEXIBLE HOSE(3102) - 1



PNC	Original P/N	Description
31301A	SU00300979	SPRING(FOR CLUTCH PEDAL)
31301B	SU00300975	CUSHION, NO.1(FOR CLUTCH PEDAL)
31301Q	SU00300968	BUSH(FOR CLUTCH PEDAL SPRING)
31301S	SU00301639	CUSHION, NO.2(FOR CLUTCH PEDAL)
31303	SU00300973	ROD SUB-ASSY, PEDAL RETURN SPRING
31309A	SU00302937	PIN, W/HOLE(FOR PEDAL RETURN SPRING CLEVIS)
31321	SU00300971	PAD, CLUTCH PEDAL
31354A	SU00300966	BUSH(FOR CLUTCH PEDAL SPRING SEAT UPPER)
31453B	SU00300969	BUSH(FOR CLUTCH MASTER CYLINDER PUSH ROD CLEVIS)
4701		Ref to 4701
4703		Ref to 4703
8401		Ref to 8401
SU00300005	SU00300005	** Std part
SU00300053	SU00300053	** Std part
SU00300058	SU00300058	** Std part
SU00300972	SU00300972	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

4.8.2 Power train, Chassis - CLUTCH PEDAL & FLEXIBLE HOSE(3102) - 2




312615

PNC	Original P/N	Description
3103		Ref to 3103
31453A	SU00302938	PIN, W/HOLE(FOR CLUTCH MASTER CYLINDER PUSH ROD CLEVIS)
31481	SU00300996	TUBE, CLUTCH MASTER CYLINDER TO FLEXIBLE HOSE
31484A	SU00301000	BRACKET, FLEXIBLE HOSE, NO.1(FOR CLUTCH)
31486B	SU00300998	HOSE, MASTER CYLINDER TO RELEASE CYLINDER
SU00300075	SU00300075	** Std part
SU00300124	SU00300124	** Std part
SU00300127	SU00300127	** Std part
SU00301628	SU00301628	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

4.9 CLUTCH RELEASE CYLINDER(3105)

4.9.1 Power train,Chassis - CLUTCH RELEASE CYLINDER(3105) - 1




312613

PNC	Original P/N	Description
3101		Ref to 3101
31470	SU00300808	CYLINDER ASSY, CLUTCH RELEASE
31470A	SU00300034	BOLT(FOR CLUTCH RELEASE CYLINDER SETTING)
3302		Ref to 3302

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

4.10 DISC WHEEL & WHEEL CAP(4103)

4.10.1 Power train,Chassis - DISC WHEEL & WHEEL CAP(4103) - 1




413722A

PNC	Original P/N	Description
42601	SU00300757	WHEEL, DISC
42601C	SU00300765	NUT, HUB (FOR AXLE)
42601D	SU00300684	WEIGHT, BALANCE (FOR DISC WHEEL)
42611G	SU00300447	VALVE (FOR TUBELESS TIRE)

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views

4.10.2 Power train, Chassis - DISC WHEEL & WHEEL CAP(4103) - 2




413723

PNC	Original P/N	Description
42601A	SU00300757	WHEEL, DISC (FOR SPARE)
42601C	SU00300765	NUT, HUB (FOR AXLE)
42601D	SU00300684	WEIGHT, BALANCE (FOR DISC WHEEL)
42611J	SU00300447	VALVE (FOR TUBELESS TIRE SPARE)

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

4.10.3 Power train,Chassis - DISC WHEEL & WHEEL CAP(4103) - 3




413726

PNC	Original P/N	Description
42603	SU00300797	ORNAMENT SUB-ASSY, WHEEL HUB

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

4.10.4 Power train,Chassis - DISC WHEEL & WHEEL CAP(4103) - 4




413725

PNC	Original P/N	Description
42652	SU00300759	TIRE
42652A	SU00300759	TIRE (FOR SPARE)

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

4.11 EXTENSION HOUSING (MTM)(3303)

4.11.1 Power train,Chassis - EXTENSION HOUSING (MTM)(3303) - 1




334510

PNC	Original P/N	Description
3307		Ref to 3307
33103	SU00303855	HOUSING SUB-ASSY, EXTENSION(MTM)
33103Q	SU00303637	PIN, RING(FOR EXTENSION HOUSING)
33103R	SU00303632	SEAL, OIL(FOR MANUAL TRANSMISSION EXTENSION HOUSING)
33124F	SU00303856	PIPE, OIL RECEIVER, NO.1(FOR EXTENSION HOUSING)
33124G	SU00303859	PIPE, OIL RECEIVER, NO.2(FOR EXTENSION HOUSING)
33141C	SU00303633	SEAL, OIL(FOR EXTENSION HOUSING REAR)
33146	SU00303857	DEFLECTOR, EXTENSION HOUSING DUST(MTM)
SU00303482	SU00303482	** Std part
SU00303484	SU00303484	** Std part
SU00303486	SU00303486	** Std part
SU00303858	SU00303858	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

4.12 FRONT AXLE ARM & STEERING KNUCKLE(4802)

4.12.1 Power train,Chassis - FRONT AXLE ARM & STEERING KNUCKLE(4802) - 1



483629A


PNC	Original P/N	Description
43211	SU00300779	KNUCKLE, STEERING, RH
43211K	SU00302805	BOLT (FOR STEERING KNUCKLE RH)
43211L	SU00302889	NUT (FOR STEERING KNUCKLE RH)
43212	SU00300780	KNUCKLE, STEERING, LH
43212D	SU00302805	BOLT (FOR STEERING KNUCKLE LH)
43212E	SU00302889	NUT (FOR STEERING KNUCKLE LH)
43330K	SU00300358	JOINT ASSY, LOWER BALL, FRONT RH
43340A	SU00300358	JOINT ASSY, LOWER BALL, FRONT LH
4803		Ref to 4803
48068A	SU00302850	BOLT(FOR FRONT SUSPENSION LOWER ARM)
48068C	SU00302871	NUT(FOR FRONT SUSPENSION LOWER ARM)
48194E	SU00300399	CAM, FRONT SUSPENSION CAMBER ADJUST, NO.3 RH
48198E	SU00300399	CAM, FRONT SUSPENSION CAMBER ADJUST, NO.3 LH
48620	SU00300354	ARM ASSY, FRONT SUSPENSION, LOWER RH
48640	SU00300355	ARM ASSY, FRONT SUSPENSION LOWER, LH
48651	SU00300359	PLATE, LOWER ARM SUPPORT
48654E	SU00300357	BUSH, FRONT LOWER ARM, NO.1 RH
48654F	SU00300357	BUSH, FRONT LOWER ARM, NO.1 LH
48655D	SU00300356	BUSH, FRONT LOWER ARM, NO.2 RH
48655E	SU00300356	BUSH, FRONT LOWER ARM, NO.2 LH
5102		Ref to 5102
SU00300056	SU00300056	** Std part
SU00300076	SU00300076	** Std part
SU00302820	SU00302820	** Std part
SU00302870	SU00302870	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

4.13 FRONT AXLE HUB(4303)

4.13.1 Power train,Chassis - FRONT AXLE HUB(4303) - 1

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views



432662


PNC	Original P/N	Description
-----	--------------	-------------

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

43501C	SU00300782	HUB SUB-ASSY, FRONT AXLE, RH
43501D	SU00300781	BOLT, HUB (FOR FRONT AXLE RH)
43502C	SU00300782	HUB SUB-ASSY, FRONT AXLE, LH
43502D	SU00300781	BOLT, HUB (FOR FRONT AXLE LH)
4705		Ref to 4705
4802		Ref to 4802
SU00302823	SU00302823	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views

4.13.2 Power train, Chassis - FRONT AXLE HUB(4303) - 2




432663

PNC	Original P/N	Description
43512	SU00300586	DISC, FRONT
4705		Ref to 4705
4802		Ref to 4802

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

4.14 FRONT DISC BRAKE CALIPER & DUST COVER(4705)

4.14.1 Power train,Chassis - FRONT DISC BRAKE CALIPER & DUST COVER(4705) - 1




478317

PNC	Original P/N	Description
04465	SU00304089	PAD KIT, DISC BRAKE, FRONT
04479	SU00304098	CYLINDER KIT, DISC BRAKE, FRONT
31478B	SU00301627	CAP, BLEEDER PLUG(FOR FRONT DISC BRAKE)
4303		Ref to 4303
47547B	SU00300582	PLUG, BLEEDER(FOR FRONT DISC BRAKE)
47710A	SU00302841	BOLT, HEXAGON(FOR FRONT DISC BRAKE CALIPER)
47715A	SU00300626	PIN, FRONT DISC BRAKE CYLINDER SLIDE
47715D	SU00300574	PIN, FRONT DISC BRAKE CYLINDER SLIDE, NO.2
47716	SU00300577	PLATE, PAD SUPPORT, NO.1(FOR FRONT DISC BRAKE)
47717	SU00300578	PLATE, PAD SUPPORT, NO.2(FOR FRONT DISC BRAKE)
47721	SU00300572	MOUNTING, FRONT DISC BRAKE CYLINDER, RH
47721A	SU00300575	BOLT(FOR FRONT DISC BRAKE CYLINDER MOUNTING)
47722	SU00300573	MOUNTING, FRONT DISC BRAKE CYLINDER, LH
47730	SU00304085	CYLINDER ASSY, FRONT DISC BRAKE, RH
47731	SU00300634	PISTON, FRONT DISC BRAKE
47750	SU00304086	CYLINDER ASSY, DISC BRAKE, LH
47769	SU00300576	BUSH, CYLINDER SLIDE, NO.1(FOR FRONT DISC BRAKE)
47781	SU00300583	COVER, DISC BRAKE DUST, FRONT RH
47781A	SU00302783	BOLT(FOR DUST COVER TO STEERING KNUCKLE ARM SETTING)
47782	SU00300584	COVER, DISC BRAKE DUST, FRONT LH
4802		Ref to 4802

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

4.14.2 Power train, Chassis - FRONT DISC BRAKE CALIPER & DUST COVER(4705) - 2




478263

PNC	Original P/N	Description
04465	SU00304089	PAD KIT, DISC BRAKE, FRONT
04479	SU00304098	CYLINDER KIT, DISC BRAKE, FRONT
31478B	SU00301627	CAP, BLEEDER PLUG(FOR FRONT DISC BRAKE)
4303		Ref to 4303
47547B	SU00300582	PLUG, BLEEDER(FOR FRONT DISC BRAKE)
47710A	SU00302841	BOLT, HEXAGON(FOR FRONT DISC BRAKE CALIPER)
47715A	SU00300626	PIN, FRONT DISC BRAKE CYLINDER SLIDE
47715D	SU00300574	PIN, FRONT DISC BRAKE CYLINDER SLIDE, NO.2
47716	SU00300577	PLATE, PAD SUPPORT, NO.1(FOR FRONT DISC BRAKE)
47717	SU00300578	PLATE, PAD SUPPORT, NO.2(FOR FRONT DISC BRAKE)
47721	SU00300572	MOUNTING, FRONT DISC BRAKE CYLINDER, RH
47721A	SU00300575	BOLT(FOR FRONT DISC BRAKE CYLINDER MOUNTING)
47722	SU00300573	MOUNTING, FRONT DISC BRAKE CYLINDER, LH
47730	SU00304085	CYLINDER ASSY, FRONT DISC BRAKE, RH
47731	SU00300634	PISTON, FRONT DISC BRAKE
47744	SU00300580	SHIM, ANTI-SQUEAL, NO.1(FOR FRONT DISC BRAKE)
47745	SU00300579	SHIM, ANTI-SQUEAL, NO.2(FOR FRONT DISC BRAKE)
47750	SU00304086	CYLINDER ASSY, DISC BRAKE, LH
47769	SU00300576	BUSH, CYLINDER SLIDE, NO.1(FOR FRONT DISC BRAKE)
47781	SU00300583	COVER, DISC BRAKE DUST, FRONT RH
47781A	SU00302783	BOLT(FOR DUST COVER TO STEERING KNUCKLE ARM SETTING)
47782	SU00300584	COVER, DISC BRAKE DUST, FRONT LH
4802		Ref to 4802

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

4.15.2 Power train, Chassis - FRONT SPRING & SHOCK ABSORBER(4803) - 2



483630


483645

PNC	Original P/N	Description
4802		Ref to 4802
48131	SU00304144	SPRING, FRONT COIL, RH
48132	SU00304144	SPRING, FRONT COIL, LH
48152	SU00300376	SEAT, FRONT SPRING
48157B	SU00300375	INSULATOR, FRONT COIL SPRING, UPPER RH
48157C	SU00300375	INSULATOR, FRONT COIL SPRING, UPPER LH
48331B	SU00300374	BUMPER, FRONT SPRING, RH
48331C	SU00300374	BUMPER, FRONT SPRING, LH
48510	SU00300371	ABSORBER ASSY, SHOCK, FRONT RH
48520	SU00300372	ABSORBER ASSY, SHOCK, FRONT LH
48603	SU00300373	SUPPORT SUB-ASSY, FRONT SUSPENSION, RH
48603D	SU00302868	NUT(FOR FRONT SUPPORT TO FRONT SHOCK ABSORBER RH)
48609	SU00300373	SUPPORT SUB-ASSY, FRONT SUSPENSION, LH
48609E	SU00302868	NUT(FOR FRONT SUPPORT TO FRONT SHOCK ABSORBER LH)
48684A	SU00300378	COVER, FRONT SUSPENSION SUPPORT DUST, RH
48684B	SU00300378	COVER, FRONT SUSPENSION SUPPORT DUST, LH
SU00303642	SU00303642	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

4.16 FRONT STEERING GEAR & LINK(4505)

4.16.1 Power train,Chassis - FRONT STEERING GEAR & LINK(4505) - 1




N04 この部品については補給していません
N04 This part is not available for service

456137

PNC	Original P/N	Description
4501		Ref to 4501
45046A	SU00300047	NUT, CASTLE(FOR TIE ROD END)
SU00300073	SU00300073	** Std part
SU00302838	SU00302838	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

4.16.2 Power train, Chassis - FRONT STEERING GEAR & LINK(4505) - 2




456138

PNC	Original P/N	Description
45046	SU00300833	END SUB-ASSY, TIE ROD, RH
45046B	SU00300835	RING, SET(FOR TIE ROD END DUST SEAL)
45046C	SU00300836	SEAL, DUST(FOR TIE ROD END)
45047	SU00300834	END SUB-ASSY, TIE ROD, LH
45222	SU00300830	COVER, STEERING GEAR DUST
45503	SU00300832	END SUB-ASSY, STEERING RACK
45504A	SU00300828	GUIDE SUB-ASSY, RACK
45510	SU00300841	GEAR ASSY, STEERING
45516A	SU00300824	BUSH, STEERING RACK HOUSING, NO.1
45523A	SU00300827	SPRING(FOR STEERING GEAR RACK GUIDE)
45524	SU00300829	CAP, STEERING RACK GUIDE SPRING
45524A	SU00300839	NUT(FOR STEERING RACK GUIDE SPRING CAP)
45535	SU00300831	BOOT, STEERING RACK, NO.1
45535B	SU00300825	CLIP(FOR STEERING RACK BOOT)
45535D	SU00300826	CLAMP(FOR STEERING RACK BOOT NO.1)
SU00300044	SU00300044	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

4.17 GEAR SHIFT FORK & LEVER SHAFT (MTM)(3307)

4.17.1 Power train,Chassis - GEAR SHIFT FORK & LEVER SHAFT (MTM)(3307) - 1




334513

PNC	Original P/N	Description
33212C	SU00303863	FORK, GEAR SHIFT, NO.1
33213G	SU00303864	FORK, GEAR SHIFT, NO.2
33214G	SU00303865	FORK, GEAR SHIFT, NO.3
33221	SU00303867	ARM, REVERSE SHIFT
33225	SU00303868	SHOE, SHIFT ARM
33225B	SU00303885	RING, E(FOR SHIFT ARM SHOE)
33232F	SU00303869	HEAD, GEAR SHIFT, NO.1
33233A	SU00303870	HEAD, GEAR SHIFT, NO.2
33234A	SU00303871	HEAD, GEAR SHIFT, NO.3
33242H	SU00303872	SHAFT, GEAR SHIFT FORK, NO.1
33243A	SU00303873	SHAFT, GEAR SHIFT FORK, NO.2
33244B	SU00303549	RING, SHAFT SNAP (FOR SHIFT FORK SHAFT)
33244D	SU00303875	SHAFT, GEAR SHIFT FORK, NO.3
SU00303485	SU00303485	** Std part
SU00303640	SU00303640	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

4.17.2 Power train, Chassis - GEAR SHIFT FORK & LEVER SHAFT (MTM)(3307) - 2




334514

PNC	Original P/N	Description
33215B	SU00303866	FORK, GEAR SHIFT, NO.4
33234F	SU00303862	HEAD, REVERSE & 5TH SHIFT
33242	SU00303878	SHAFT, GEAR SHIFT FORK, NO.1
33244B	SU00303549	RING, SHAFT SNAP (FOR SHIFT FORK SHAFT)
33245G	SU00303876	SHAFT, GEAR SHIFT FORK, NO.4
33246C	SU00303874	SHAFT, GEAR SHIFT FORK, NO.5
33251	SU00303879	LEVER, SHIFT & SELECT
33251C	SU00303487	BOLT, SET (FOR SHIFT & SELECT LEVER)
33265	SU00303877	PIN, SHIFT INTER LOCK, NO.2
33275B	SU00303884	BALL, SHAFT DETENT
33275E	SU00303881	SPRING, COMPRESSION (FOR SHIFT DETENT BALL)
SU00303498	SU00303498	** Std part
SU00303640	SU00303640	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views

4.17.3 Power train, Chassis - GEAR SHIFT FORK & LEVER SHAFT (MTM)(3307) - 3




334531

PNC	Original P/N	Description
3312		Ref to 3312
33263D	SU00300901	PIN (FOR SHIFT LEVER SHAFT)
33511G	SU00300895	SHAFT, CONTROL
33511H	SU00300897	COLLAR (FOR CONTROL SHAFT)
33544C	SU00300882	DAMPER, SHIFT LEVER
5806		Ref to 5806

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views

4.17.4 Power train, Chassis - GEAR SHIFT FORK & LEVER SHAFT (MTM)(3307) - 4




334529

PNC	Original P/N	Description
3302		Ref to 3302
33212B	SU00303619	PLUG, W/HEAD STRAIGHT SCREW, NO.1
33275B	SU00303884	BALL, SHAFT DETENT
33276A	SU00303880	SPRING, COMPRESSION, NO.2 (FOR SHIFT DETENT BALL)

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views

4.17.5 Power train, Chassis - GEAR SHIFT FORK & LEVER SHAFT (MTM)(3307) - 5




PNC	Original P/N	Description
3303		Ref to 3303
33213H	SU00303620	PLUG, W/HEAD STRAIGHT SCREW, NO.2
33251P	SU00303882	SPRING (FOR SHIFT & SELECT LEVER)
33292A	SU00303638	PIN, LOCK BALL

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

4.18 PARKING BRAKE & CABLE(4601)

4.18.1 Power train,Chassis - PARKING BRAKE & CABLE(4601) - 1




461276

PNC	Original P/N	Description
46210	SU00300530	LEVER ASSY, PARKING BRAKE
46401	SU00300543	BRACKET SUB-ASSY, CABLE SUPPORT
46410C	SU00300546	CLAMP(FOR PARKING BRAKE FRONT CABLE)
46420	SU00300548	CABLE ASSY, PARKING BRAKE, NO.2
46420A	SU00300547	CLAMP, NO.1(FOR PARKING BRAKE CABLE)
46430	SU00300549	CABLE ASSY, PARKING BRAKE, NO.3
46441	SU00302866	NUT, WIRE ADJUSTING, NO.1
46451B	SU00300544	BRACKET, PARKING BRAKE CABLE SUPPORT
46451C	SU00300545	BRACKET, PARKING BRAKE CABLE SUPPORT, NO.1
46524	SU00300553	COVER, PARKING BRAKE DUST
8401		Ref to 8401
SU00300013	SU00300013	** Std part
SU00300053	SU00300053	** Std part
SU00302826	SU00302826	** Std part
SU00303018	SU00303018	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

4.18.2 Power train, Chassis - PARKING BRAKE & CABLE(4601) - 2




461275

PNC	Original P/N	Description
04495A	SU00300637	SHOE KIT, PARKING BRAKE
4102		Ref to 4102
46503	SU00300640	PLATE SUB-ASSY, PARKING BRAKE, RH
46504	SU00300641	PLATE SUB-ASSY, PARKING BRAKE, LH
46550B	SU00300645	PIN(FOR PARKING BRAKE SHOE)
46550C	SU00300636	WASHER, TYPE C(FOR PARKING BRAKE SHOE)
46550D	SU00300650	WASHER, WAVE(FOR PARKING BRAKE SHOE)
46550E	SU00300646	SPRING, TENSION, NO.2(FOR PARKING BRAKE SHOE RETURN)
46550G	SU00300648	SPRING, TENSION, NO.3(FOR PARKING BRAKE SHOE RETURN)
47405A	SU00300642	SCREW SET, SHOE ADJUSTING, RH(FOR PARKING BRAKE)
47406A	SU00300642	SCREW SET, SHOE ADJUSTING, LH(FOR PARKING BRAKE)
47447C	SU00300651	PIN, SHOE HOLD DOWN SPRING(FOR PARKING BRAKE)
47447D	SU00300649	SPRING, COMPRESSION(FOR PARKING BRAKE SHOE HOLD DOWN)
47611	SU00300643	LEVER, PARKING BRAKE SHOE, RH
47612	SU00300644	LEVER, PARKING BRAKE SHOE, LH
47613D	SU00300647	SPRING, COMPRESSION(FOR PARKING BRAKE SHOE STRUT)
47613E	SU00300652	STRUT, PARKING BRAKE SHOE, RH
47614	SU00300653	STRUT, PARKING BRAKE SHOE, LH

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

4.19 PROPELLER SHAFT & UNIVERSAL JOINT(3701)

4.19.1 Power train,Chassis - PROPELLER SHAFT & UNIVERSAL JOINT(3701) - 1




370803

PNC	Original P/N	Description
37100	SU00300657	SHAFT ASSY, PROPELLER W/CENTER BEARING
37100A	SU00302814	BOLT, NO.1 (FOR PROPELLER SHAFT & DIFFERENTIAL SETTING)
37100B	SU00302884	NUT, NO.1 (FOR PROPELLER SHAFT & DIFFERENTIAL SETTING)
37100C	SU00302903	WASHER, NO.1 (FOR PROPELLER SHAFT & DIFFERENTIAL SETTING)
37230F	SU00302843	BOLT, NO.1 (FOR CENTER SUPPORT BEARING)
4101		Ref to 4101

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

4.20 REAR AXLE HOUSING & DIFFERENTIAL(4101)

4.20.1 Power train,Chassis - REAR AXLE HOUSING & DIFFERENTIAL(4101) - 1



N01:この部品は、構造上分解・組付けが困難なため、単品では補給していません
N01:This part is not supplied as an individual part, because it is hard to assemble/disassemble due to the structure

413602A


PNC	Original P/N	Description
41110	4111018020	CARRIER ASSY, DIFFERENTIAL, REAR
41110D	9034118035	PLUG (FOR REAR DIFFERENTIAL DRAIN)
41110E	1215710010	GASKET (FOR REAR DIFFERENTIAL DRAIN PLUG)
41110H	SU00300304	PLUG (FOR REAR DIFFERENTIAL FILLER)
41110J	SU00300122	GASKET (FOR REAR DIFFERENTIAL FILLER PLUG)
41110K	9093003077	PLUG, BREATHER (FOR REAR DIFFERENTIAL)
41111A	9025008120	PIN, STRAIGHT (FOR REAR DIFFERENTIAL CARRIER)
41114	9010512164	BOLT, REAR DIFFERENTIAL BEARING CAP
41181H	4110853020	COVER, REAR DIFFERENTIAL CARRIER
41181P	9010510417	BOLT (FOR REAR DIFFERENTIAL CARRIER COVER SETTING)
41183	4118353020	DEFLECTOR, REAR DIFFERENTIAL BREATHER PLUG OIL
41183A	91611B0614	BOLT (FOR REAR DIFFERENTIAL BREATHER PLUG OIL DEFLECTOR)
41201	4120119605	FINAL GEAR KIT, DIFFERENTIAL, REAR
41201A	9036635133	BEARING, TAPERED ROLLER (FOR REAR DRIVE PINION REAR)
41201B	9036630093	BEARING, TAPERED ROLLER (FOR REAR DRIVE PINION FRONT)
41201C	9031138070	SEAL, OIL (FOR REAR DIFFERENTIAL CARRIER)
41201D	9020135497	WASHER, PLATE (FOR REAR DIFFERENTIAL DRIVE PINION)
41204	4120435041	FLANGE SUB-ASSY, REAR DRIVE PINION COMPANION, REAR
41204B	9017920018	NUT (FOR REAR DRIVE PINION)
41214	4121426010	SLINGER, REAR DIFFERENTIAL DRIVE PINION OIL
41222	4122222010	PLATE, REAR DIFFERENTIAL RING GEAR SET BOLT LOCK
41222A	9010111353	BOLT (FOR REAR DIFFERENTIAL RING GEAR SET)

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

41231	4123124010	SPACER, REAR DIFFERENTIAL DRIVE PINION BEARING
41252	4125235020	DEFLECTOR, DUST (FOR REAR DIFFERENTIAL)
41301	4130153020	CASE SUB-ASSY, REAR DIFFERENTIAL
41301A	9036650001	BEARING(FOR REAR DIFFERENTIAL CASE)
41334B	9031143009	SEAL, OIL (FOR REAR DIFFERENTIAL SIDE GEAR SHAFT)
41334C	9020152001	WASHER, PLATE (FOR REAR DIFFERENTIAL SIDE GEAR SHAFT)

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

4.20.2 Power train, Chassis - REAR AXLE HOUSING & DIFFERENTIAL(4101) - 2




413693

PNC	Original P/N	Description
41110A	SU00301012	BOLT, NO.1 (FOR REAR DIFFERENTIAL CARRIER SET)
41110S	SU00302812	BOLT, NO.2 (FOR REAR DIFFERENTIAL CARRIER SET)
41110T	SU00302812	BOLT, NO.3 (FOR REAR DIFFERENTIAL CARRIER SET)
41651	SU00301008	CUSHION, REAR DIFFERENTIAL MOUNT, NO.1
41651A	SU00301009	CUSHION, REAR DIFFERENTIAL MOUNT, NO.2
41653	SU00301010	STOPPER, REAR DIFFERENTIAL MOUNT, UPPER
41654	SU00301011	STOPPER, REAR DIFFERENTIAL MOUNT, LOWER
5102		Ref to 5102

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

4.21 REAR AXLE SHAFT & HUB(4102)

4.21.1 Power train,Chassis - REAR AXLE SHAFT & HUB(4102) - 1




413721A

PNC	Original P/N	Description
42311N	SU00302864	NUT (FOR REAR AXLE SHAFT RH)
42311U	SU00300781	BOLT, HUB (FOR REAR AXLE RH)
42312B	SU00302864	NUT (FOR REAR AXLE SHAFT LH)
42312E	SU00300781	BOLT, HUB (FOR REAR AXLE LH)
42450A	SU00300791	HUB & BEARING ASSY, REAR AXLE, RH
42450B	SU00300791	HUB & BEARING ASSY, REAR AXLE, LH
4804		Ref to 4804

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views

4.21.2 Power train, Chassis - REAR AXLE SHAFT & HUB(4102) - 2




461275

413719

PNC	Original P/N	Description
42431	SU00300638	DISC, REAR
42491	SU00300635	PLUG, SHOE ADJUSTING HOLE (FOR PARKING BRAKE)
4601		Ref to 4601

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

4.21.3 Power train, Chassis - REAR AXLE SHAFT & HUB(4102) - 3



※1 PNC 42350D(RH), 42350E(LH) does include ①, ②, ③ parts
 ※2 BOOT KIT - REFER TO ILLUSTR. NO. 4 OF 4

413720


PNC	Original P/N	Description
42330	SU00300785	SHAFT ASSY, REAR DRIVE, RH
42340B	SU00300785	SHAFT ASSY, REAR DRIVE, LH
42341A	SU00300788	RING, SNAP (FOR REAR DRIVE SHAFT)
42341B	SU00300682	RING, SNAP (FOR REAR DRIVE SHAFT RH)
42341C	SU00300682	RING, SNAP (FOR REAR DRIVE SHAFT LH)
42342	SU00300786	BOOT, REAR DRIVE SHAFT JOINT
42346A	SU00300448	CLAMP (FOR REAR DRIVE SHAFT OUTBOARD JOINT BOOT)
42347	SU00300448	CLAMP (FOR REAR DRIVE SHAFT INBOARD JOINT BOOT)
42347A	SU00300449	CLAMP (FOR REAR DRIVE SHAFT INBOARD JOINT BOOT)
42347B	SU00300449	CLAMP, NO.2 (FOR REAR DRIVE SHAFT INBOARD JOINT BOOT)
42350A	SU00301626	RING, HOLE SNAP
42350D	SU00300792	JOINT ASSY, REAR DRIVE SHAFT OUTBOARD, RH
42350E	SU00300792	JOINT ASSY, REAR DRIVE SHAFT OUTBOARD, LH
42360C	SU00300793	JOINT ASSY, REAR DRIVE SHAFT INBOARD, RH
42360D	SU00300793	JOINT ASSY, REAR DRIVE SHAFT INBOARD, LH
42360L	SU00300683	RING, SHAFT SNAP (FOR REAR DRIVE SHAFT INBOARD JOINT RH)
42360M	SU00300683	RING, SHAFT SNAP (FOR REAR DRIVE SHAFT INBOARD JOINT LH)
42451A	SU00300790	DEFLECTOR, REAR WHEEL BEARING DUST, NO.1 RH
42451B	SU00300790	DEFLECTOR, REAR WHEEL BEARING DUST, NO.1 LH
43458A	SU00300789	COVER, REAR DRIVE SHAFT DUST

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

SU00303646	SU00303646	** Std part
SU00303647	SU00303647	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views

4.21.4 Power train, Chassis - REAR AXLE SHAFT & HUB(4102) - 4




413703

PNC	Original P/N	Description
42340K	SU00300795	BOOT KIT, REAR DRIVE SHAFT JOINT

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

4.22 REAR DISC BRAKE CALIPER & DUST COVER(4707)

4.22.1 Power train,Chassis - REAR DISC BRAKE CALIPER & DUST COVER(4707) - 1




478326

PNC	Original P/N	Description
04466	SU00304097	PAD KIT, DISC BRAKE, REAR
04479A	SU00304098	CYLINDER KIT, DISC BRAKE, REAR
31478C	SU00301627	CAP, BLEEDER PLUG(FOR REAR DISC BRAKE)
47547C	SU00300582	PLUG, BLEEDER(FOR REAR DISC BRAKE)
47721C	SU00300622	MOUNTING, REAR DISC BRAKE CYLINDER, RH
47721D	SU00300575	BOLT(FOR REAR DISC BRAKE CYLINDER MOUTING)
47722A	SU00300622	MOUNTING, REAR DISC BRAKE CYLINDER, LH
47730B	SU00304092	CYLINDER ASSY, REAR DISC BRAKE, RH
47731B	SU00300634	PISTON, REAR DISC BRAKE
47744B	SU00300633	SHIM, ANTI-SQUEAL(FOR REAR DISC BRAKE)
47744C	SU00300632	SHIM, ANTI-SQUEAL, NO.1(FOR REAR DISC BRAKE)
47745B	N/A	SHIM, ANTI-SQUEAL, NO.2(FOR REAR DISC BRAKE)
47750A	SU00304093	CYLINDER ASSY, DISC BRAKE, REAR LH
47769A	SU00300576	BUSH, CYLINDER SLIDE, NO.1(FOR REAR DISC BRAKE)
47810A	SU00302796	BOLT, HEXAGON(FOR REAR CALIPER)
47814	SU00300624	PIN, CYLINDER SLIDE, NO.1(FOR REAR DISC BRAKE)
47815	SU00300625	PIN, REAR CYLINDER SLIDE, NO.2(FOR REAR DISC BRAKE)
47816	SU00300628	PLATE, PAD SUPPORT, NO.1(FOR REAR DISC BRAKE)
4804		Ref to 4804

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

4.23 REAR SPRING & SHOCK ABSORBER(4804)

4.23.1 Power train,Chassis - REAR SPRING & SHOCK ABSORBER(4804) - 1



483631


PNC	Original P/N	Description
4101		Ref to 4101
48705	SU00300362	LINK SUB-ASSY, TOE CONTROL, RH
48706B	SU00300362	LINK SUB-ASSY, TOE CONTROL, LH
48706C	SU00300367	BUSH SUB-ASSY, LATERAL CONTROL ROD
48710A	SU00300360	ARM ASSY, REAR SUSPENSION, NO.1 RH
48720A	SU00300360	ARM ASSY, REAR SUSPENSION, NO.1 LH
48725B	SU00300366	BUSH, REAR SUSPENSION ARM, NO.1
48725C	SU00300365	BUSH, REAR SUSPENSION ARM, NO.2
48730F	SU00300361	ARM ASSY, REAR SUSPENSION, NO.2 RH
48740F	SU00300361	ARM ASSY, REAR SUSPENSION, NO.2 LH
48770A	SU00300363	ARM ASSY, UPPER CONTROL, REAR RH
48790	SU00300364	ARM ASSY, UPPER CONTROL, REAR LH
48802	SU00300398	LINK SUB-ASSY, STABILIZER
48805A	SU00300396	BUSH(FOR REAR STABILIZER BAR)
48812	SU00300395	BAR, STABILIZER, REAR
48824R	SU00300397	BRACKET, STABILIZER(FOR REAR)
5102		Ref to 5102
SU00300015	SU00300015	** Std part
SU00300056	SU00300056	** Std part
SU00300076	SU00300076	** Std part
SU00300399	SU00300399	** Std part
SU00302781	SU00302781	** Std part
SU00302782	SU00302782	** Std part
SU00302785	SU00302785	** Std part
SU00302804	SU00302804	** Std part
SU00302819	SU00302819	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

SU00302854	SU00302854	** Std part
SU00302865	SU00302865	** Std part
SU00302870	SU00302870	** Std part
SU00302883	SU00302883	** Std part
SU00302904	SU00302904	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

4.23.2 Power train, Chassis - REAR SPRING & SHOCK ABSORBER(4804) - 2




483650

PNC	Original P/N	Description
4102		Ref to 4102
42304	SU00300783	CARRIER SUB-ASSY, REAR AXLE, RH
42305	SU00300784	CARRIER SUB-ASSY, REAR AXLE, LH
48725F	SU00300366	BUSH, REAR AXLE CARRIER, RH
48725G	SU00300366	BUSH, REAR AXLE CARRIER, LH
48751	SU00300370	BUSH, REAR AXLE MOUNTING
SU00302790	SU00302790	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

4.23.3 Power train, Chassis - REAR SPRING & SHOCK ABSORBER(4804) - 3




483652

PNC	Original P/N	Description
48231A	SU00304147	SPRING, COIL, REAR RH
48231B	SU00304147	SPRING, COIL, REAR LH
48341A	SU00300384	BUMPER, REAR SPRING, NO.1 RH
48341B	SU00300384	BUMPER, REAR SPRING, NO.1 LH
48481	SU00300387	SEAT, REAR SPRING, UPPER
48482	SU00300387	SEAT, REAR SPRING, UPPER LH
48530	SU00300382	ABSORBER ASSY, SHOCK, REAR RH
48540	SU00300382	ABSORBER ASSY, SHOCK, REAR LH
48559C	SU00300385	COVER, REAR SHOCK ABSORBER DUST, RH NO.1
48559D	SU00300385	COVER, REAR SHOCK ABSORBER DUST, LH NO.1
48750H	SU00300383	SUPPORT ASSY, REAR SUSPENSION, RH
48750J	SU00302869	NUT(FOR REAR SUPPORT TO REAR SHOCK ABSORBER RH)
48760B	SU00300383	SUPPORT ASSY REAR SUSPENSION, LH
48760C	SU00302869	NUT(FOR REAR SUPPORT TO REAR SHOCK ABSORBER LH)
SU00302803	SU00302803	** Std part
SU00302869	SU00302869	** Std part
SU00302870	SU00302870	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

4.24 SHIFT LEVER & RETAINER(3312)

4.24.1 Power train,Chassis - SHIFT LEVER & RETAINER(3312) - 1



334515A


PNC	Original P/N	Description
3307		Ref to 3307
33503A	SU00300886	COLLAR(FOR SHIFT LEVER)
33504F	SU00300884	KNOB SUB-ASSY, SHIFT LEVER
33506F	SU00300890	RETAINER SUB-ASSY, CONTROL SHIFT LEVER (FOR FLOOR SHIFT)
33511	SU00300893	SHAFT, CONTROL (FOR FLOOR SHIFT)
33511C	SU00300886	COLLAR (FOR CONTROL SHAFT)
33523B	SU00300899	PIN, SHIFT LEVER (FOR FLOOR SHIFT)
33530F	SU00300876	LEVER ASSY, SHIFT (FOR FLOOR SHIFT)
33532	SU00300891	PLATE, DUST BOOT
33554	SU00300877	CAP, SHIFT LEVER
33555	SU00300879	BOOT, SHIFT LEVER
33555B	SU00300881	BOOT, SHIFT & SELECT LEVER
33575	SU00300887	RETAINER, CONTROL SHIFT LEVER (FOR FLOOR SHIFT)
33575A	SU00300888	BUSH, NO.1 (FOR CONTROL SHIFT LEVER RETAINER)
33575B	SU00300889	BUSH, NO.2 (FOR CONTROL SHIFT LEVER RETAINER)
33597B	SU00300880	SEAT, SHIFT LEVER, NO.1 (FOR FLOOR SHIFT)
5806		Ref to 5806
SU00300005	SU00300005	** Std part
SU00300006	SU00300006	** Std part
SU00300878	SU00300878	** Std part
SU00300892	SU00300892	** Std part
SU00300896	SU00300896	** Std part
SU00300898	SU00300898	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

SU00304101	SU00304101	** Std part
------------	------------	-------------

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

4.25.2 Power train, Chassis - STEERING COLUMN & SHAFT(4501) - 2




N04 この部品については補給していません
N04 This part is not available for service

456137

PNC	Original P/N	Description
4505		Ref to 4505
45222G	SU00304152	CLIP, DUST COVER
45260	SU00300838	SHAFT ASSY, STEERING INTERMEDIATE, NO.2
SU00302849	SU00302849	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

4.25.3 Power train, Chassis - STEERING COLUMN & SHAFT(4501) - 3



N05: This part is not supplied because it can be substituted with goods on the market


456154

PNC	Original P/N	Description
45020A	SU00302475	ACTUATOR ASSY, STEERING LOCK
45897	SU00302479	BOLT, STEERING LOCK SET
6712		Ref to 6712
8401		Ref to 8401
8420		Ref to 8420

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

4.26 STEERING WHEEL(4504)

4.26.1 Power train,Chassis - STEERING WHEEL(4504) - 1




456131A

PNC	Original P/N	Description
45111	SU00300844	WHEEL, STEERING
45116	SU00304252	ORNAMENT, STEERING WHEEL, NO.1
45184	SU00304249	COVER, STEERING WHEEL BOSS, LOWER
45201P	SU00300056	NUT, STEERING WHEEL SET
45713A	SU00300857	DAMPER, STEERING SHAKE
8401		Ref to 8401
8408		Ref to 8408
SU00300856	SU00300856	** Std part
SU00304251	SU00304251	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views

4.26.2 Power train, Chassis - STEERING WHEEL(4504) - 2




456157

PNC	Original P/N	Description
4504		Ref to 4504
45107	N/A	WIRE SUB-ASSY, HORN BUTTON

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views

4.26.3 Power train, Chassis - STEERING WHEEL(4504) - 3




456161

PNC	Original P/N	Description
45130	SU00303411	BUTTON ASSY, HORN
5501		Ref to 5501
6401		Ref to 6401
7101		Ref to 7101
7403		Ref to 7403

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views

4.27 TRANSAXLE OR TRANSMISSION ASSY & GASKET KIT (MTM)(3301)

4.27.1 Power train,Chassis - TRANSAXLE OR TRANSMISSION ASSY & GASKET KIT (MTM)(3301) -
 1




334542A

PNC	Original P/N	Description
33110	SU00304329	TRANSMISSION ASSY, MANUAL

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

4.28 TRANSMISSION GEAR (MTM)(3305)

4.28.1 Power train,Chassis - TRANSMISSION GEAR (MTM)(3305) - 1



334511


PNC	Original P/N	Description
33037B	SU00303886	RING SET, SYNCHRONIZER, NO.1
33311	SU00303911	SHAFT, INPUT
33311A	SU00303527	BEARING (FOR INPUT SHAFT FRONT)
33311B	SU00303575	RING, SHAFT SNAP (FOR FRONT BEARING)
33311D	SU00303522	BEARING, INPUT SHAFT
33311G	SU00303588	RING, SHAFT SNAP (FOR FRONT BEARING)
33321	SU00303912	SHAFT, OUTPUT
33321A	SU00303526	BEARING (FOR OUTPUT SHAFT REAR)
33321B	SU00303588	RING, SHAFT SNAP (FOR OUTPUT SHAFT BEARING)
33331	SU00303913	GEAR, REVERSE
33331A	SU00303523	BEARING (FOR REVERSE GEAR)
33332	SU00303914	GEAR, 2ND
33332B	SU00303520	BEARING, NEEDLE ROLLER (FOR 2ND GEAR)
33335	SU00303915	GEAR, 1ST
33335A	SU00303908	BALL, 1ST SHIFT RESTRICT
33335C	SU00303519	BEARING, NEEDLE ROLLER(FOR 1ST GEAR)
33337	SU00303916	GEAR SUB-ASSY, 6TH
33337C	SU00303564	RING, SHAFT SNAP(FOR 6TH GEAR)
33355	SU00303891	RACE, 1ST GEAR BEARING INNER
33361	SU00303893	HUB, TRANSMISSION CLUTCH, NO.1
33363	SU00303895	SLEEVE, TRANSMISSION HUB, NO.1
33365	SU00303897	KEY, SYNCHROMESH SHIFTING, NO.1
33365C	SU00303907	BALL(FOR SYNCHROMESH SHIFTING KEY)
33368	SU00303901	RING, SYNCHRONIZER, NO.2
33369	SU00303899	RING, SYNCHRONIZER, NO.3

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

33371	SU00303902	SPRING, SYNCHROMESH SHIFTING KEY, NO.1
33393	SU00303904	HUB, TRANSMISSION CLUTCH, NO.3
33393A	SU00303581	RING, SHAFT SNAP (FOR TRANSMISSION CLUTCH HUB NO.3)
33395	SU00303905	SLEEVE, TRANSMISSION HUB, NO.3

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

4.28.2 Power train, Chassis - TRANSMISSION GEAR (MTM)(3305) - 2



334512

PNC	Original P/N	Description
33327	SU00303888	SLEEVE, TRANSMISSION HUB, NO.4
33327A	SU00303551	RING, SNAP(FOR CLUTCH HUB NO.4)
33329	SU00303890	RING, 4TH WASHER RETAINING
33329A	SU00303550	RING, SNAP(FOR 4TH WASHER RETAINING RING)
33333	SU00303909	GEAR, 3RD
33333A	SU00303521	BEARING, NEEDLE ROLLER (FOR 3RD GEAR)
33337A	SU00303524	BEARING, NEEDLE ROLLER (FOR 6TH GEAR)
33342A	SU00303641	PIN, STRAIGHT (FOR GEAR THRUST WASHER)
33347D	SU00303499	WASHER, 6TH GEAR THRUST
33349A	SU00303500	WASHER, 4TH GEAR
33352B	SU00303889	HUB, TRANSMISSION CLUTCH, NO.4
33352C	SU00303552	RING, SHAFT SNAP
33358	SU00303892	RACE, 4TH GEAR BEARING INNER
33362	SU00303894	HUB, TRANSMISSION CLUTCH, NO.2
33364	SU00303896	SLEEVE, TRANSMISSION HUB, NO.2
33365	SU00303897	KEY, SYNCHROMESH SHIFTING, NO.1
33365C	SU00303907	BALL(FOR SYNCHROMESH SHIFTING KEY)
33367	SU00303887	RING, SYNCHRONIZER, NO.1
33369B	SU00303900	RING, SYNCHRONIZER, NO.4
33371	SU00303902	SPRING, SYNCHROMESH SHIFTING KEY, NO.1
33393A	SU00303581	RING, SHAFT SNAP (FOR TRANSMISSION CLUTCH HUB NO.3)
33402	SU00303917	GEAR SUB-ASSY, REVERSE IDLER
33411	SU00303918	COUNTERSHAFT
33411A	SU00303525	BEARING OR ROLLER(FOR COUNTER GEAR FRONT)
33411D	SU00303587	RING, COUNTER GEAR FRONT BEARING SNAP, NO.1

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views


33411Q	SU00303558	RING, COUNTER GEAR FRONT BEARING SNAP, NO.2
33411W	SU00303919	GEAR, COUNTER, 6TH
33421	SU00303920	GEAR, COUNTER
33422	SU00303910	GEAR, COUNTER SHAFT 4TH SPEED
33451	SU00303906	SHAFT, REVERSE IDLER GEAR
33451H	SU00303488	BOLT (FOR REVERSE IDLER GEAR SHAFT)
33451J	SU00303627	GASKET (FOR REVERSE IDLER GEAR SHAFT)

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5 Tool,Engine,Fuel

5.1 AIR CLEANER(1703)

5.1.1 Tool,Engine,Fuel - AIR CLEANER(1703) - 1




177609A

PNC	Original P/N	Description
1201		Ref to 1201
17701	SU00301214	CASE SUB-ASSY, AIR CLEANER
17705	SU00301215	CAP SUB-ASSY, AIR CLEANER
17801	SU00300319	ELEMENT SUB-ASSY, AIR CLEANER FILTER
17881	SU00304333	HOSE, AIR CLEANER, NO.1
17881A	SU00301217	CLAMP(FOR AIR CLEANER HOSE, NO.1)
2211		Ref to 2211
22204	SU00300427	METER SUB-ASSY, INTAKE AIR FLOW
SU00301207	SU00301207	** Std part
SU00301222	SU00301222	** Std part
SU00302922	SU00302922	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.1.2 Tool,Engine,Fuel - AIR CLEANER(1703) - 2




177610A

PNC	Original P/N	Description
17341F	SU00301209	HOSE, AIR, NO.1
17342D	SU00301210	HOSE, AIR, NO.2
17659A	SU00301202	CONNECTOR, AIR
17710B	SU00304103	GROMMET
17750A	SU00301199	INLET ASSY, AIR CLEANER
17764	SU00301200	DUCT, AIR CLEANER
17764C	SU00302174	CLAMP, HOSE(FOR AIR CLEANER DUCT)
17764D	SU00301212	CHAMBER ASSY
17771A	SU00301211	BRACKET, AIR CLEANER
17882A	SU00302175	CLAMP(FOR AIR CLEANER HOSE, NO.2)
2211		Ref to 2211
5304		Ref to 5304
SU00300015	SU00300015	** Std part
SU00300519	SU00300519	** Std part
SU00301024	SU00301024	** Std part
SU00301207	SU00301207	** Std part
SU00301208	SU00301208	** Std part
SU00301222	SU00301222	** Std part
SU00301223	SU00301223	** Std part
SU00302833	SU00302833	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.2 ALTERNATOR(1903)

5.2.1 Tool,Engine,Fuel - ALTERNATOR(1903) - 1




193882

PNC	Original P/N	Description
27020	SU00300484	ALTERNATOR ASSY
27039	SU00300490	COVER, ALTERNATOR REAR END
27310	SU00300487	FRAME ASSY, DRIVE END, ALTERNATOR
27310B	SU00300489	BEARING(FOR ALTERNATOR DRIVE END FRAME)
27330	SU00300485	ROTOR ASSY, ALTERNATOR
27330A	SU00300488	BEARING(FOR ALTERNATOR ROTOR)
27357	SU00300513	HOLDER, ALTERNATOR, W/RECTIFIER
27360	SU00300486	COIL ASSY, ALTERNATOR
27370	SU00300512	HOLDER ASSY, ALTERNATOR BRUSH
27387	SU00300511	INSULATOR, TERMINAL
27411	SU00300492	PULLEY, ALTERNATOR
SU00300491	SU00300491	** Std part
SU00300493	SU00300493	** Std part
SU00300494	SU00300494	** Std part
SU00300495	SU00300495	** Std part
SU00300496	SU00300496	** Std part
SU00300497	SU00300497	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.2.2 Tool,Engine,Fuel - ALTERNATOR(1903) - 2




193897

PNC	Original P/N	Description
1105		Ref to 1105
1106		Ref to 1106
1601		Ref to 1601
1605		Ref to 1605
27020E	SU00302142	BOLT(FOR ALTERNATOR)
27029	SU00300506	COVER, ALTERNATOR
SU00300022	SU00300022	** Std part
SU00300027	SU00300027	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.3 CAMSHAFT & VALVE(1302)

5.3.1 Tool,Engine,Fuel - CAMSHAFT & VALVE(1302) - 1




131867A

PNC	Original P/N	Description
13711	SU00300196	VALVE, INTAKE
13711B	SU00300204	SPRING, COMPRESSION(FOR INNER)
13711E	SU00300198	SEAL, INTAKE VALVE STEM OIL
13715	SU00300197	VALVE, EXHAUST
13715A	SU00300201	SEAL, EXHAUST VALVE STEM OIL
13734	SU00300276	SEAT, VALVE SPRING
13741	SU00300199	RETAINER, VALVE SPRING
13741A	SU00300200	LOCK, VALVE SPRING RETAINER
13753	SU00300205	SHIM, VALVE ADJUSTING
13801	SU00300278	ARM SUB-ASSY, VALVE ROCKER, NO.1
13801K	SU00300283	PIVOT, ROCKER ARM RH
13802A	SU00304240	PIVOT, ROCKER ARM LH

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.3.2 Tool,Engine,Fuel - CAMSHAFT & VALVE(1302) - 2




131868

PNC	Original P/N	Description
13050B	SU00300284	GEAR ASSY, CAMSHAFT TIMING INTAKE, RH
13060B	SU00300286	GEAR ASSY, CAMSHAFT TIMING INTAKE, LH
13070	SU00300285	GEAR ASSY, CAMSHAFT TIMING EXHAUST, RH
13080	SU00300287	GEAR ASSY, CAMSHAFT TIMING EXHAUST, LH
13511C	SU00300180	CAMSHAFT, INTAKE, RH
13512D	SU00300181	CAMSHAFT, EXHAUST, RH
13513	SU00300182	CAMSHAFT, INTAKE, LH
13514	SU00300183	CAMSHAFT, EXHAUST, LH
13523F	SU00300195	BOLT(FOR CAMSHAFT TIMING GEAR)
13540D	SU00302185	RING, O(FOR CHAIN TENSIONER)

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.3.3 Tool,Engine,Fuel - CAMSHAFT & VALVE(1302) - 3




131869

PNC	Original P/N	Description
1301		Ref to 1301
13506	SU00300193	CHAIN SUB-ASSY
13540	SU00300191	TENSIONER ASSY, CHAIN, NO.1
13550	SU00300192	TENSIONER ASSY, CHAIN, NO.2
13559	SU00300190	SLIPPER, CHAIN TENSIONER
13561	SU00300194	DAMPER, CHAIN VIBRATION, NO.1
SU00302138	SU00302138	** Std part
SU00302197	SU00302197	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.4 CAUTION PLATE & NAME PLATE (ENGINE)(1709)

5.4.1 Tool,Engine,Fuel - CAUTION PLATE & NAME PLATE (ENGINE)(1709) - 1




177628

PNC	Original P/N	Description
1603		Ref to 1603
16793A	SU00301197	LABEL, COOLING FAN CAUTION
5304		Ref to 5304
7403		Ref to 7403

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.5 CRANKSHAFT & PISTON(1301)

5.5.1 Tool,Engine,Fuel - CRANKSHAFT & PISTON(1301) - 1




131879

PNC	Original P/N	Description
1302		Ref to 1302
13471	SU00300173	PULLEY, CRANKSHAFT
13471C	SU00300178	BOLT(FOR CRANKSHAFT PULLEY SET)
13471G	SU00302190	RING, O(FOR CRANKSHAFT PULLEY)
13471P	SU00300177	SPACER(FOR CRANKSHAFT PULLEY)

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.5.2 Tool,Engine,Fuel - CRANKSHAFT & PISTON(1301) - 2




※1 PNC13011 & PNC13041 are the set-items for one vehicle respectively.
 N04 この部品については補給していません
 N04 This part is not available for service

131878

PNC	Original P/N	Description
11702	SU00300156	BEARING SET, CRANKSHAFT
11711	SU00300160	BEARING, CRANKSHAFT
13011	SU00300145	RING SET, PISTON
13041	SU00300149	BEARING, CONNECTING ROD
13101	SU00300137	PISTON SUB-ASSY, W/PIN
13101A	SU00302170	RING, HOLE SNAP(FOR PISTON PIN)
13201	SU00300148	ROD SUB-ASSY, CONNECTING
13201A	SU00300154	BUSH(FOR CONNECTING ROD SMALL END)
13265	SU00300153	BOLT, CONNECTING ROD
13301	SU00300141	PISTON SUB-ASSY, W/PIN, LH
13411	SU00300155	CRANKSHAFT
13521	SU00300179	GEAR OR SPROCKET, CRANKSHAFT TIMING
13521A	SU00302169	KEY(FOR CRANKSHAFT TIMING GEAR)
19315	SU00300172	PLATE, CRANK ANGLE SENSOR, NO.1

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views

5.5.3 Tool,Engine,Fuel - CRANKSHAFT & PISTON(1301) - 3




131866

PNC	Original P/N	Description
1105		Ref to 1105
13405	SU00304287	FLYWHEEL SUB-ASSY
13405B	SU00302143	BOLT, FLYWHEEL SET
13405G	SU00302179	BEARING, FLYEEL
3502		Ref to 3502

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.6 CYLINDER BLOCK(1105)

5.6.1 Tool,Engine,Fuel - CYLINDER BLOCK(1105) - 1




N04 この部品については補給していません
N04 This part is not available for service

117471

PNC	Original P/N	Description
11401	SU00300102	BLOCK SUB-ASSY, CYLINDER
11416	SU00300098	BOLT(FOR CRANKSHAFT BEARING CAP SET)
SU00302154	SU00302154	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views


5.6.2 Tool,Engine,Fuel - CYLINDER BLOCK(1105) - 2



PNC	Original P/N	Description
11271J	SU00300109	PLATE, CYLINDER BLOCK
11401L	SU00302181	SEAL, ENGINE REAR OIL
11401R	SU00300097	HOLDER ASSY, CRANKSHAFT SENSOR
11401S	SU00300135	CONNECTOR, PCV HOSE
11431A	SU00300107	PLUG, TIGHT, NO.1(FOR CYLINDER BLOCK)
1201		Ref to 1201
12270H	SU00300136	COVER, OIL SEPARATOR
1603		Ref to 1603
SU00300020	SU00300020	** Std part
SU00300021	SU00300021	** Std part
SU00300022	SU00300022	** Std part
SU00302147	SU00302147	** Std part
SU00302185	SU00302185	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.6.3 Tool,Engine,Fuel - CYLINDER BLOCK(1105) - 3




※1 mark parts are contained in PNC12101
 ※2 6F
 ※3 6FC

117508

PNC	Original P/N	Description
11401A	SU00300105	PLUG(FOR CYLINDER BLOCK BLIND)
12101	SU00300119	PAN SUB-ASSY, OIL
12101A	SU00302194	PLUG(FOR OIL PAN DRAIN)
12101B	SU00302159	GASKET(FOR OIL PAN DRAIN PLUG)
12101C	SU00302188	RING, O(FOR OIL PAN)
12101L	SU00300121	GASKET NO.1(FOR OIL PAN)
12102A	SU00300118	PAN SUB-ASSY, OIL, NO.2
12121	SU00300110	PLATE, OIL PAN BAFFLE, NO.1
1501		Ref to 1501
3302		Ref to 3302
3503		Ref to 3503
SU00300020	SU00300020	** Std part
SU00300032	SU00300032	** Std part
SU00302136	SU00302136	** Std part
SU00302148	SU00302148	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.6.4 Tool,Engine,Fuel - CYLINDER BLOCK(1105) - 4




117496

PNC	Original P/N	Description
1106		Ref to 1106
11452	SU00300307	GUIDE, OIL LEVEL GAGE
11452B	SU00300306	RING, O(FOR OIL LEVEL GAGE GUIDE)
1502		Ref to 1502
15301	SU00300123	GAGE SUB-ASSY, OIL LEVEL
15301A	SU00303978	RING, O(FOR OIL LEVEL GAGE)
8401		Ref to 8401
SU00302196	SU00302196	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.6.5 Tool,Engine,Fuel - CYLINDER BLOCK(1105) - 5




117498

PNC	Original P/N	Description
1104		Ref to 1104
11401G	SU00300412	SENSOR, CRANK POSITION
1901		Ref to 1901
8202		Ref to 8202
8401		Ref to 8401
SU00300021	SU00300021	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.6.6 Tool,Engine,Fuel - CYLINDER BLOCK(1105) - 6




117509

PNC	Original P/N	Description
11444	SU00300125	PLUG, HOLE
1701		Ref to 1701
1904		Ref to 1904
3302		Ref to 3302
3503		Ref to 3503

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views

5.6.7 Tool,Engine,Fuel - CYLINDER BLOCK(1105) - 7




117476

PNC	Original P/N	Description
11361J	SU00300801	COVER, FLYWHEEL HOUSING UNDER
SU00300128	SU00300128	** Std part
SU00300129	SU00300129	** Std part
SU00300130	SU00300130	** Std part
SU00302136	SU00302136	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.7 CYLINDER HEAD(1104)

5.7.1 Tool,Engine,Fuel - CYLINDER HEAD(1104) - 1




117473

PNC	Original P/N	Description
11101V	SU00300117	BOLT(FOR CYLINDER HEAD SET SUB)
11103C	SU00304236	HOUSING SUB-ASSY, CAMSHAFT, RH
11103D	SU00300029	BOLT(FOR CAMSHAFT HOUSING TO CYLINDER HEAD, RH)
11103G	SU00300816	SPACER, OIL, RH
11115	SU00300112	GASKET, CYLINDER HEAD
11151E	SU00300028	BOLT(FOR CAMSHAFT BEARING CAP TO HOUSING RH, NO.1)
11191A	SU00300100	GASKET(FOR SPARK PLUG TUBE)
15044	N/A	PIPE SUB-ASSY, CAMSHAFT OIL FEED
15678D	SU00300299	FILTER, OIL CONTROL VALVE, RH
SU00300020	SU00300020	** Std part
SU00300022	SU00300022	** Std part
SU00300309	SU00300309	** Std part
SU00302155	SU00302155	** Std part
SU00302184	SU00302184	** Std part
SU00302193	SU00302193	** Std part
SU00304084	SU00304084	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.7.2 Tool,Engine,Fuel - CYLINDER HEAD(1104) - 2




① 11153A

117474

PNC	Original P/N	Description
11101V	SU00300117	BOLT(FOR CYLINDER HEAD SET SUB)
11104A	SU00304237	HOUSING SUB-ASSY, CAMSHAFT, LH
11104B	SU00300029	BOLT(FOR CAMSHAFT HOUSING TO CYLINDER HEAD, LH)
11104E	SU00300330	CASE ASSY, PUMP DRIVE
11104F	SU00300816	SPACER, OIL, LH
11116	SU00300099	GASKET, CYLINDER HEAD, NO.2
11153A	SU00300028	BOLT(FOR CAMSHAFT BEARING CAP TO HOUSING LH, NO.1)
11193A	SU00300100	GASKET, SPARK PLUG TUBE, LH
13751A	SU00300277	LIFTER, VALVE
15678E	SU00300299	FILTER, OIL CONTROL VALVE, LH
SU00300022	SU00300022	** Std part
SU00302134	SU00302134	** Std part
SU00302184	SU00302184	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.7.3 Tool,Engine,Fuel - CYLINDER HEAD(1104) - 3




117475

PNC	Original P/N	Description
11101	SU00300111	HEAD SUB-ASSY, CYLINDER
11102	SU00300115	HEAD, CYLINDER, LH
11117A	SU00300303	PLUG, W/HEAD TAPER SCREW, NO.1
11117B	SU00300303	PLUG, W/HEAD TAPER SCREW, NO.2
11122	SU00300202	BUSH, INTAKE VALVE GUIDE
11122B	SU00300202	BUSH, INTAKE VALVE GUIDE, NO.2
11126	SU00300203	BUSH, EXHAUST VALVE GUIDE
11126B	SU00300203	BUSH, EXHAUST VALVE GUIDE, NO.2
SU00302150	SU00302150	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views

5.7.4 Tool,Engine,Fuel - CYLINDER HEAD(1104) - 4




117479

PNC	Original P/N	Description
11201	SU00300279	COVER SUB-ASSY, CYLINDER HEAD
11202	SU00300282	COVER SUB-ASSY, CYLINDER HEAD, LH
11213	SU00300280	GASKET, CYLINDER HEAD COVER
11214	SU00300281	GASKET, CYLINDER HEAD COVER, NO.2
SU00300022	SU00300022	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.7.5 Tool,Engine,Fuel - CYLINDER HEAD(1104) - 5




117488

PNC	Original P/N	Description
11101Y	SU00300103	HEAD & VALVE SET, CYLINDER, RH
11102B	SU00300104	HEAD & VALVE SET, CYLINDER, LH
1302		Ref to 1302

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.7.6 Tool,Engine,Fuel - CYLINDER HEAD(1104) - 6




117494

PNC	Original P/N	Description
11181	SU00300116	PLATE, CYLINDER HEAD, REAR
1905		Ref to 1905
4703		Ref to 4703
SU00300026	SU00300026	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.7.7 Tool,Engine,Fuel - CYLINDER HEAD(1104) - 7




117497

PNC	Original P/N	Description
1105		Ref to 1105
11102A	SU00300413	SENSOR, CAMSHAFT POSITION
1901		Ref to 1901
8202		Ref to 8202
8401		Ref to 8401
SU00300021	SU00300021	** Std part
SU00300184	SU00300184	** Std part
SU00300185	SU00300185	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.8 ENGINE OIL PUMP(1501)

5.8.1 Tool,Engine,Fuel - ENGINE OIL PUMP(1501) - 1



※1 6F
※2 6FC

151945

PNC	Original P/N	Description
1105		Ref to 1105
15104	SU00300305	STRAINER SUB-ASSY, OIL
15104A	SU00302192	RING, O(FOR OIL STRAINER)
3302		Ref to 3302
3503		Ref to 3503
SU00300021	SU00300021	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.9 ENGINE OVERHAUL GASKET KIT(1103)

5.9.1 Tool,Engine,Fuel - ENGINE OVERHAUL GASKET KIT(1103) - 1

NO	REFER TO FIG	PART NAME(PART NO.)	QTY	NO	REFER TO FIG	PART NAME(PART NO.)	QTY
1	REFER TO FIG 11-05 (PNC 11401L)	OILSEAL-92X109X8 (SU003-02181)	1	11	REFER TO FIG 11-06 (PNC 11301G)	O RING-12.1X2.5 (SU003-02183)	3
2	REFER TO FIG 11-05	O RING-16.1X2.3 (SU003-02185)	1	12	REFER TO FIG 11-06 (PNC 11302A)	OILSEAL-50X62X7 (SU003-02180)	1
	REFER TO FIG 13-02 (PNC 13540D)	O RING-16.1X2.3 (SU003-02185)	1				
3	REFER TO FIG 11-04 (PNC 11115)	GSKT-CYL HEAD (11044-AA810)	1	13	REFER TO FIG 11-05 (PNC 11452B)	SEAL-OIL LEVEL (15090-KA000)	1
4	REFER TO FIG 11-04 (PNC 11116)	GSKT-CYL HEAD.2 (10944-AA100)	1	14	REFER TO FIG 11-04 (PNC 11213)	GSKT-ROCKER COVERRH (13270-AA250)	1
5	REFER TO FIG 11-04 (PNC 11191A (RH)) (PNC 11193A (LH))	GSKT-SPARK PL PIP (10966-AA040)	4	15	REFER TO FIG 11-04 (PNC 11214)	GSKT-ROCKER COVERLH (13272-AA180)	1
6	REFER TO FIG 11-04	O RING-15.4X1.8 (SU003-02184)	4	16	REFER TO FIG 17-01 (PNC 17177)	GSKT-INT MANIF (14035-AA610)	2
7	REFER TO FIG 11-05 (PNC 12101B)	GSKT-16X21X2.3 (SU003-02159)	1	17	REFER TO FIG 22-11 (PNC 23801Y)	GSKT-FUEL PIPE (17555-AA040)	1
8	REFER TO FIG 11-05 (PNC 12101C)	O RING-32.6X2.7 (SU003-02188)	3	18	REFER TO FIG 22-11	O RING-31.5X2.0 (SU003-02187)	1
9	REFER TO FIG 13-01 (PNC 13471G)	O RING-39.0X2.0 (SU003-02190)	1	19	REFER TO FIG 16-03 (PNC 16322A)	O RING-33.7X3.5 (SU003-02189)	2
10	REFER TO FIG 11-06 (PNC 11301H)	O RING-23.8X2.8 (SU003-02186)	1	20	REFER TO FIG 17-01 (PNC 17173 (RH)) (PNC 17173A (LH))	GASKET F (44022-AA020)	2


117489

PNC	Original P/N	Description
04111	SU00300094	GASKET KIT, ENGINE OVERHAUL
1104		Ref to 1104
1105		Ref to 1105
1106		Ref to 1106
1301		Ref to 1301
1302		Ref to 1302
1603		Ref to 1603
1701		Ref to 1701
2211		Ref to 2211

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.10 EXHAUST PIPE(1702)

5.10.1 Tool,Engine,Fuel - EXHAUST PIPE(1702) - 1




177614

PNC	Original P/N	Description
1701		Ref to 1701
17401	SU00301137	PIPE SUB-ASSY, EXHAUST, FRONT
17410	SU00301132	PIPE ASSY, EXHAUST, FRONT
17410B	SU00301110	GASKET, EXHAUST PIPE
17551	SU00301165	INSULATOR, EXHAUST PIPE HEAT, NO.1
17552	SU00301167	INSULATOR, EXHAUST PIPE HEAT, NO.2
17553	SU00301169	INSULATOR, EXHAUST PIPE HEAT, NO.3
17554	SU00301171	INSULATOR, EXHAUST PIPE HEAT, FRONT
17555	SU00301142	INSULATOR, EXHAUST PIPE HEAT, NO.5
17556	SU00301144	INSULATOR, EXHAUST PIPE HEAT, NO.6
17557	SU00301146	INSULATOR, EXHAUST PIPE HEAT, NO.7
SU00300008	SU00300008	** Std part
SU00300009	SU00300009	** Std part
SU00300051	SU00300051	** Std part
SU00301117	SU00301117	** Std part
SU00301138	SU00301138	** Std part
SU00301139	SU00301139	** Std part
SU00301140	SU00301140	** Std part
SU00302877	SU00302877	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.10.2 Tool,Engine,Fuel - EXHAUST PIPE(1702) - 2




177631

PNC	Original P/N	Description
1701		Ref to 1701
17410B	SU00301110	GASKET, EXHAUST PIPE
17420	SU00301118	PIPE ASSY, EXHAUST, CENTER
17430	SU00301121	PIPE ASSY, EXHAUST, TAIL
17448	SU00301126	BAFFLE, TAIL PIPE
17451	SU00301112	GASKET, EXHAUST PIPE
17451A	SU00301113	GASKET, EXHAUST PIPE, NO.2
17455	SU00301129	BRACKET, EXHAUST PIPE
17561B	SU00301116	SUPPORT, EXHAUST PIPE, NO.1
8401		Ref to 8401
SU00300001	SU00300001	** Std part
SU00300015	SU00300015	** Std part
SU00300035	SU00300035	** Std part
SU00301114	SU00301114	** Std part
SU00301115	SU00301115	** Std part
SU00302152	SU00302152	** Std part
SU00302846	SU00302846	** Std part
SU00302867	SU00302867	** Std part
SU00302877	SU00302877	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.11 FUEL INJECTION SYSTEM(2211)

5.11.1 Tool,Engine,Fuel - FUEL INJECTION SYSTEM(2211) - 1




222795

PNC	Original P/N	Description
1701		Ref to 1701
23250	SU00300325	INJECTOR ASSY, FUEL
23250B	SU00300322	RING, O(FOR FUEL INJECTOR)
23250C	SU00300317	GROMMET(FOR FUEL INJECTOR)
23255A	SU00300323	SEAL, FUEL INJECTOR
23256	SU00300333	RING, FUEL INJECTOR BACK-UP, NO.1
23257	SU00300334	RING, FUEL INJECTOR BACK-UP, NO.2
23270	SU00300331	DAMPER ASSY, FUEL PRESSURE PULSATION
23270D	SU00300346	GASKET(FOR PULSATION DAMPER)
23295	SU00300320	HOLDER, INJECTOR, NO.1
23801P	SU00300338	PIPE SUB-ASSY, FUEL, NO.1
23802B	SU00300339	PIPE SUB-ASSY, FUEL, NO.2
23814E	SU00300336	PIPE, FUEL DELIVERY, RH
23815E	SU00300337	PIPE, FUEL DELIVERY, LH
7701		Ref to 7701
8404		Ref to 8404
SU00300025	SU00300025	** Std part
SU00300029	SU00300029	** Std part
SU00300321	SU00300321	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.11.2 Tool,Engine,Fuel - FUEL INJECTION SYSTEM(2211) - 2




222796

PNC	Original P/N	Description
1701		Ref to 1701
1708		Ref to 1708
23100X	SU00300328	PUMP ASSY, FUEL
23801V	SU00300310	BOLT, UNION
23801Y	SU00300347	GASKET
23807	SU00300343	PIPE SUB-ASSY, FUEL DELIVERY
23808	SU00300345	PIPE SUB-ASSY, FUEL DELIVERY, NO.2
23814B	SU00300341	PIPE, FUEL DELIVERY
23815	SU00300342	PIPE, FUEL DELIVERY, NO.2
7701		Ref to 7701
SU00300021	SU00300021	** Std part
SU00300820	SU00300820	** Std part
SU00302187	SU00302187	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views

5.11.3 Tool,Engine,Fuel - FUEL INJECTION SYSTEM(2211) - 3




222798

PNC	Original P/N	Description
1701		Ref to 1701
22030	SU00300313	BODY ASSY, THROTTLE W/MOTOR
SU00300024	SU00300024	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views

5.11.4 Tool,Engine,Fuel - FUEL INJECTION SYSTEM(2211) - 4

※1 6F
 ※2 6FC




222797

PNC	Original P/N	Description
1201		Ref to 1201
1701		Ref to 1701
22271	SU00300316	GASKET, THROTTLE BODY
4703		Ref to 4703

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.12 IGNITION COIL & SPARK PLUG(1901)

5.12.1 Tool,Engine,Fuel - IGNITION COIL & SPARK PLUG(1901) - 1



193883


PNC	Original P/N	Description
1104		Ref to 1104
1105		Ref to 1105
19100P	SU00300416	PLUG, SPARK
19500	SU00300417	COIL ASSY, IGNITION
8202		Ref to 8202
8401		Ref to 8401
SU00302140	SU00302140	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.13 MANIFOLD(1701)

5.13.1 Tool,Engine,Fuel - MANIFOLD(1701) - 1

※1 0F
※2 0FC




177649

PNC	Original P/N	Description
1201		Ref to 1201
17111	SU00300288	MANIFOLD, INTAKE
17177	SU00300290	GASKET, INTAKE MANIFOLD TO HEAD, NO.1
2211		Ref to 2211
4703		Ref to 4703

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.13.2 Tool,Engine,Fuel - MANIFOLD(1701) - 2




177612

PNC	Original P/N	Description
1104		Ref to 1104
1708		Ref to 1708
23261A	SU00300291	COVER, INJECTOR
8202		Ref to 8202
8401		Ref to 8401
8404		Ref to 8404
SU00300025	SU00300025	** Std part
SU00302201	SU00302201	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.13.3 Tool,Engine,Fuel - MANIFOLD(1701) - 3




177611

PNC	Original P/N	Description
1105		Ref to 1105
1904		Ref to 1904
23261A	SU00300291	COVER, INJECTOR
3302		Ref to 3302
3503		Ref to 3503
SU00300025	SU00300025	** Std part
SU00300315	SU00300315	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.13.4 Tool,Engine,Fuel - MANIFOLD(1701) - 4




177613

PNC	Original P/N	Description
12611B	SU00300289	COVER, ENGINE, NO.1

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.13.5 Tool,Engine,Fuel - MANIFOLD(1701) - 5




177632

PNC	Original P/N	Description
1702		Ref to 1702
17141	SU00301135	MANIFOLD, EXHAUST
17167	SU00301156	INSULATOR, EXHAUST MANIFOLD HEAT, NO.1
17168	SU00301148	INSULATOR, EXHAUST MANIFOLD HEAT, NO.2
17169	SU00301152	INSULATOR, EXHAUST MANIFOLD HEAT, NO.3
25586	SU00301160	INSULATOR, MANIFOLD CONVERTER, NO.1
25587	SU00301162	INSULATOR, MANIFOLD CONVERTER, NO.2
25588	SU00301163	INSULATOR, MANIFOLD CONVERTER, NO.3
SU00300008	SU00300008	** Std part
SU00300051	SU00300051	** Std part
SU00301117	SU00301117	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.13.6 Tool,Engine,Fuel - MANIFOLD(1701) - 6




177634

PNC	Original P/N	Description
1702		Ref to 1702
17173	SU00301111	GASKET, EXHAUST MANIFOLD TO HEAD
17173A	SU00301111	GASKET, EXHAUST MANIFOLD TO HEAD, LH
8401		Ref to 8401
SU00302872	SU00302872	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.14 MOUNTING(1107)

5.14.1 Tool,Engine,Fuel - MOUNTING(1107) - 1




117485

PNC	Original P/N	Description
12311	SU00301006	BRACKET, ENGINE MOUNTING, FRONT NO.1 RH
12315	SU00301007	BRACKET, ENGINE MOUNTING, FRONT NO.1 LH
SU00302834	SU00302834	** Std part
SU00302839	SU00302839	** Std part
SU00302890	SU00302890	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.14.2 Tool,Engine,Fuel - MOUNTING(1107) - 2




117486

PNC	Original P/N	Description
12371	SU00301005	INSULATOR, ENGINE MOUNTING, REAR NO.1
12372	SU00301004	INSULATOR, ENGINE MOUNTING, REAR NO.2
SU00300017	SU00300017	** Std part
SU00300019	SU00300019	** Std part
SU00300050	SU00300050	** Std part
SU00302876	SU00302876	** Std part
SU00302901	SU00302901	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.15 OIL FILTER(1502)

5.15.1 Tool,Engine,Fuel - OIL FILTER(1502) - 1




151937

PNC	Original P/N	Description
1106		Ref to 1106
15601	SU00300311	FILTER SUB-ASSY, OIL

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.15.2 Tool,Engine,Fuel - OIL FILTER(1502) - 2




151941

PNC	Original P/N	Description
1105		Ref to 1105
1106		Ref to 1106
15600A	SU00300302	UNION(FOR OIL FILTER)
8401		Ref to 8401

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.16 RADIATOR & WATER OUTLET(1603)

5.16.1 Tool,Engine,Fuel - RADIATOR & WATER OUTLET(1603) - 1



164785A


PNC	Original P/N	Description
16361	SU00301174	FAN
16361B	SU00301173	FAN, NO.2
16363	SU00301181	MOTOR, COOLING FAN
16363A	SU00301180	MOTOR, COOLING FAN, NO.2
16400	SU00301172	RADIATOR ASSY
16400B	SU00301179	PLUG, RADIATOR DRAIN COCK
16400F	SU00301196	PACKING(FOR RADIATOR DRAIN COCK)
16401	SU00301184	CAP SUB-ASSY, RADIATOR
16465	SU00301192	PACKING, RADIATOR
16465A	SU00301193	PACKING, RADIATOR, NO.1
16465B	SU00301195	PACKING, RADIATOR, NO.2
16468	SU00301194	PACKING, RADIATOR
16470	SU00301185	TANK ASSY, RADIATOR RESERVE
16470A	SU00301191	HOSE OR PIPE(FOR RADIATOR RESERVE TANK)
16471	SU00301187	CAP SUB-ASSY, RESERVE TANK
16502	SU00303939	FILLER SUB-ASSY, WATER
16522	SU00301178	BRACKET, WATER FILLER
16523A	SU00301182	CUSHION, RADIATOR SUPPORT
16533D	SU00301176	SUPPORT, RADIATOR, RH
16534A	SU00301177	SUPPORT, RADIATOR, LH
16535	SU00301183	SUPPORT, RADIATOR, LOWER
16571	SU00301190	HOSE, RADIATOR, INLET
16571A	SU00302996	CLAMP OR CLIP, HOSE(FOR RADIATOR INLET)
16571C	SU00301188	HOSE, RADIATOR, NO.1
16571D	SU00302996	CLIP, RADIATOR HOSE, NO.1
16572	SU00301189	HOSE, RADIATOR, OUTLET

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

16572A	SU00302996	CLAMP OR CLIP, HOSE(FOR RADIATOR OUTLET NO.1)
16711	SU00301175	SHROUD, FAN
1709		Ref to 1709
5304		Ref to 5304
7403		Ref to 7403
SU00300002	SU00300002	** Std part
SU00300070	SU00300070	** Std part
SU00302882	SU00302882	** Std part
SU00302912	SU00302912	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views


5.16.2 Tool,Engine,Fuel - RADIATOR & WATER OUTLET(1603) - 2



PNC	Original P/N	Description
16261N	SU00300404	HOSE, WATER BY-PASS, NO.2
16261P	SU00302173	CLIP(FOR WATER BY-PASS HOSE NO.2)
16264	SU00300406	HOSE, WATER BY-PASS, NO.2
16267	SU00300405	HOSE, WATER BY-PASS, NO.3
16322	SU00300296	PIPE, WATER INLET
16322A	SU00302189	RING, O(FOR WATER INLET)
16323	SU00304082	HOUSING, WATER INLET
16323A	SU00304125	GASKET(FOR WATER INLET HOUSING)
16331A	SU00300407	THERMOSTAT
2211		Ref to 2211
3514		Ref to 3514
8404		Ref to 8404
8716		Ref to 8716
SU00300023	SU00300023	** Std part
SU00300079	SU00300079	** Std part
SU00303453	SU00303453	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.16.3 Tool,Engine,Fuel - RADIATOR & WATER OUTLET(1603) - 3





164789

PNC	Original P/N	Description
1601		Ref to 1601
16261	SU00303434	HOSE, WATER BY-PASS
16261A	SU00302172	CLAMP OR CLIP, HOSE(FOR WATER BY-PASS HOSE)
16261G	N/A	HOSE, WATER BY-PASS, NO.1
16261H	N/A	CLIP(FOR WATER BY-PASS HOSE NO.1)
16268	SU00300293	PIPE, WATER BY-PASS, NO.1
16331	SU00300113	OUTLET, WATER
16331A	SU00300407	THERMOSTAT
16346	SU00300409	GASKET, THERMOSTAT
3514		Ref to 3514
8716		Ref to 8716
SU00302196	SU00302196	** Std part
SU00302198	SU00302198	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.17 SHORT BLOCK ASSEMBLY(1102)

5.17.1 Tool,Engine,Fuel - SHORT BLOCK ASSEMBLY(1102) - 1




117487

PNC	Original P/N	Description
1105		Ref to 1105
11400	SU00300093	BLOCK ASSY, SHORT
1301		Ref to 1301

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.18 STANDARD TOOL(0901)

5.18.1 Tool,Engine,Fuel - STANDARD TOOL(0901) - 1




090660

PNC	Original P/N	Description
09110	SU00303401	JACK ASSY
09113	SU00303402	HANDLE, JACK
09119	SU00303403	LABEL, JACK CAUTION
09120	SU00304285	BAG, TOOL
09135	SU00301988	DRIVER, SCREW
09150	SU00303400	WRENCH, HUB NUT BOX
44890D	SU00304282	COMPRESSOR ASSY, AIR
5104		Ref to 5104
6403		Ref to 6403
C6048	SU00304283	REPAIR SET, TIRE
C6048A	SU00304284	SEALANT, REPAIR TIRE

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.18.2 Tool,Engine,Fuel - STANDARD TOOL(0901) - 2




090646

PNC	Original P/N	Description
51960	SU00301544	HOOK ASSY, FRONT
5304		Ref to 5304
5305		Ref to 5305
6101		Ref to 6101

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.19 STARTER(1904)

5.19.1 Tool,Engine,Fuel - STARTER(1904) - 1



※1 SU003-00482は使用個数1で1台分になります。
※1 SU003-00482 are the set-items for one vehicle respectively


193878

PNC	Original P/N	Description
28011	SU00300456	CLUTCH SUB-ASSY, STARTER
28100	SU00300451	STARTER ASSY
28110	SU00300457	HOUSING ASSY, STARTER DRIVE
28113	SU00300460	LEVER, STARTER PINION DRIVE
28120	SU00300452	YOKE ASSY, STARTER
28140	SU00300478	HOLDER ASSY, STARTER BRUSH
28150	SU00300471	SWITCH ASSY, MAGNET STARTER
28160	SU00300454	ARMATURE ASSY, STARTER
28160A	SU00300458	BEARING, STARTER ARMATURE
28160B	SU00300459	BEARING, STARTER ARMATURE, NO.2
28199	SU00300465	COVER, STARTER
28209	SU00300461	SHAFT SUB-ASSY, STARTER
28252	SU00300462	GEAR, STARTER IDLE
28256	SU00300464	GEAR, STARTER INTERNAL
SU00300418	SU00300418	** Std part
SU00300467	SU00300467	** Std part
SU00300473	SU00300473	** Std part
SU00300480	SU00300480	** Std part
SU00300482	SU00300482	** Std part
SU00302145	SU00302145	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.20 TIMING GEAR COVER & REAR END PLATE(1106)

5.20.1 Tool,Engine,Fuel - TIMING GEAR COVER & REAR END PLATE(1106) - 1




117469

PNC	Original P/N	Description
1105		Ref to 1105
11301G	SU00302183	RING, O(FOR TIMING GEAR CASE, UPPER)
11301H	SU00302186	RING, O(FOR TIMING GEAR CASE, LOWER)
11302	SU00300186	COVER SUB-ASSY, TIMING CHAIN OR BELT
11302A	SU00302180	SEAL, OIL(FOR TIMING CHAIN OR BELT COVER)
11322G	SU00300332	RING, O(FOR TIMING GEAR COVER)
12108C	SU00302160	GASKET
12108D	SU00304083	CAP ASSY, OIL FILLER
1502		Ref to 1502
15330	SU00300096	VALVE ASSY, CAM TIMING OIL CONTROL
8401		Ref to 8401
SU00300022	SU00300022	** Std part
SU00300024	SU00300024	** Std part
SU00300032	SU00300032	** Std part
SU00300033	SU00300033	** Std part
SU00302195	SU00302195	** Std part
SU00302196	SU00302196	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.21 V

5.21.1 Tool,Engine,Fuel - V-BELT(1605) - 1




164786

PNC	Original P/N	Description
1105		Ref to 1105
1106		Ref to 1106
1601		Ref to 1601
16361A	SU00302202	BELT, V(FOR FAN & ALTERNATOR)
1903		Ref to 1903

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.22 VACUUM PIPING(1708)

5.22.1 Tool,Engine,Fuel - VACUUM PIPING(1708) - 1




177629

PNC	Original P/N	Description
1104		Ref to 1104
1701		Ref to 1701
17650	SU00300314	VALVE ASSY, VACUUM SWITCHING
8202		Ref to 8202
8401		Ref to 8401
8404		Ref to 8404
SU00300051	SU00300051	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.22.2 Tool,Engine,Fuel - VACUUM PIPING(1708) - 2




177638

PNC	Original P/N	Description
1701		Ref to 1701
17308B	SU00303442	HOSE SUB-ASSY, VACUUM
2211		Ref to 2211

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
 Parts List and Exploded Views

5.23 VACUUM PUMP(1905)

5.23.1 Tool,Engine,Fuel - VACUUM PUMP(1905) - 1




193880

PNC	Original P/N	Description
1104		Ref to 1104
29300	N/A	PUMP ASSY, VACUUM
4703		Ref to 4703
SU00300026	SU00300026	** Std part
SU00302184	SU00302184	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.24 VENTILATION HOSE(1201)

5.24.1 Tool,Engine,Fuel - VENTILATION HOSE(1201) - 1




120845

PNC	Original P/N	Description
12204	SU00300132	VALVE SUB-ASSY, VENTILATION
12261	SU00303441	HOSE, VENTILATION
12262	SU00300133	HOSE, VENTILATION, NO.2
12262A	SU00300080	CLIP(FOR VENTILATION HOSE NO.2)
1701		Ref to 1701
1703		Ref to 1703

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.25 WATER PUMP(1601)

5.25.1 Tool,Engine,Fuel - WATER PUMP(1601) - 1




164778

PNC	Original P/N	Description
1603		Ref to 1603
16100	SU00300401	PUMP ASSY, ENGINE WATER
16173	SU00300403	PULLEY, WATER PUMP
16271	SU00300402	GASKET, WATER PUMP
3514		Ref to 3514
8716		Ref to 8716
SU00302139	SU00302139	** Std part
SU00302198	SU00302198	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.25.2 Tool,Engine,Fuel - WATER PUMP(1601) - 2




164779

PNC	Original P/N	Description
1105		Ref to 1105
1106		Ref to 1106
12511H	SU00300131	BRACKET, ALTERNATOR
1605		Ref to 1605
16603	SU00300500	PULLEY SUB-ASSY, IDLER, NO.1
16604	SU00300501	PULLEY SUB-ASSY, IDLER, NO.2
16620	SU00300498	TENSIONER ASSY, V-RIBBED BELT
16649B	SU00300504	PLATE, IDLER PULLEY COVER
16659	SU00300505	PLATE, IDLER PULLEY COVER, NO.2
1903		Ref to 1903
27029A	SU00300507	COVER, BELT ALTERNATOR
SU00300022	SU00300022	** Std part
SU00300031	SU00300031	** Std part
SU00300318	SU00300318	** Std part
SU00300502	SU00300502	** Std part
SU00300503	SU00300503	** Std part
SU00302135	SU00302135	** Std part

GT86 ZN6 ALE8 FA20 HI MTM 6F LHD EUR
Parts List and Exploded Views

5.25.3 Tool,Engine,Fuel - WATER PUMP(1601) - 3



PNC	Original P/N	Description
16630G	N/A	PULLEY ASSY, IDLER
16631	N/A	BRACKET, IDLER PULLEY
16659C	N/A	PLATE, IDLER PULLEY COVER, NO.1
8719		Ref to 8719
SU00300502	SU00300502	** Std part